Bajaj BI 1

Bajaj Popular Ace 1400-Watt Induction Cooker User Manual

Model: BI 1

Introduction

Thank you for choosing the Bajaj Popular Ace 1400-Watt Induction Cooker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

To reduce the risk of fire, electric shock, injury, or damage, always follow basic safety precautions when using electrical appliances. This appliance is for household use only.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children.
- Always place the appliance on a stable, heat-resistant surface.
- Do not block the ventilation openings.
- Use only induction-compatible cookware.
- **Notice: The ceramic plate is hot after cooking; please don't touch with your hand.**



Image: Angled view of the Bajaj Popular Ace Induction Cooker, showing the control panel and cooking surface. Note the warning about the hot ceramic plate.

Setup and First Use

1. Unpack the induction cooker and remove all packaging materials.
2. Place the cooker on a flat, stable, and heat-resistant surface, ensuring adequate ventilation around the unit.
3. Ensure the power cord is not damaged and plug it into a suitable electrical outlet.
4. Before first use, wipe the ceramic plate with a damp cloth.
5. Place an induction-compatible vessel centrally on the ceramic plate.

Operating Instructions

The Bajaj Popular Ace Induction Cooker features a user-friendly control panel with various pre-set functions and manual controls.



Image: Top-down view of the Bajaj Popular Ace Induction Cooker, highlighting the control panel with various function buttons.

Control Panel Functions:

- **Power:** Press to turn the unit ON or OFF.
- **Manual:** Allows for manual adjustment of heating power.
- **Milk/Tea:** Pre-set function for heating milk or making tea.
- **Roti/Dosa:** Pre-set function optimized for cooking rotis or dosas.
- **Fry:** Pre-set function for frying.
- **Pressure Cook:** Pre-set function for pressure cooking.
- **Warm:** Keeps food warm at a low temperature.
- **Noodles/Soup:** Pre-set function for cooking noodles or soup.
- **Time:** Use to set cooking duration.
- **Up/Down:** Adjusts power levels or time settings.

General Operation Steps:

1. Place an induction-compatible vessel containing food or liquid on the center of the ceramic plate.
2. Plug the power cord into a suitable electrical outlet.
3. Press the **Power** button to turn on the cooker.
4. Select a desired pre-set function (e.g., Milk/Tea, Fry) or press **Manual** to set the power level manually using the **Up/Down** buttons.
5. If desired, use the **Time** button and **Up/Down** buttons to set a cooking timer.
6. The cooker will begin heating. Monitor the cooking process.

7. Once cooking is complete, press the **Power** button to turn off the cooker and unplug it from the wall outlet.
8. Allow the ceramic plate to cool down completely before cleaning.

Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your induction cooker.

- Always unplug the cooker and allow it to cool completely before cleaning.
- Wipe the ceramic plate with a soft, damp cloth. For stubborn stains, use a mild detergent specifically designed for ceramic cooktops.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Clean the exterior housing with a soft, damp cloth.
- Ensure no water enters the internal components.
- Never immerse the cooker in water or any other liquid.
- Regularly check the power cord for any signs of damage.

Troubleshooting

If you encounter an issue with your Bajaj Popular Ace Induction Cooker, refer to the table below for common error codes and their solutions.

Error Code	Reason	Actionable Solution
E0	No vessel / Unsuitable vessel	Please place an induction-compatible vessel at the center of the plate.
E1	Abnormal supply voltage less than 140V	Please switch on the unit after power supply is back to normal (i.e., 230V).
E5	Abnormal supply voltage more than 280V	Please switch on the unit after power supply is back to normal (i.e., less than 230V).
E6	Temperature under the glass is too high.	Please allow the induction cooktop to cool down, then resume operation.
E2	Sensor under IGBT has opened	Please contact Bajaj customer care.
E3	Sensor under glass has shorted	Please contact Bajaj customer care.
E4	Sensor under glass is open	Please contact Bajaj customer care.
E7	Sensor under IGBT is short	Please contact Bajaj customer care.

Specifications

- **Brand:** Bajaj
- **Model Number:** BI 1
- **Power:** 1400-Watt
- **Color:** Black
- **Heating Elements:** 1

- **Controls Type:** Knob
- **Burner Type:** Radiant (*Note: While listed as 'Radiant' in product data, this is an induction cooker which uses electromagnetic fields for heating.*)
- **Item Weight:** 2.17 kg
- **ASIN:** B00YKLD61A

Customer Support

For further assistance, warranty information, or service requests, please contact Bajaj customer care.
Customer Service Number: 18001025963
Please have your model number (BI 1) and purchase details ready when contacting support.

© 2023 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question