

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [SYLVANIA](#) /

› SYLVANIA Portable Speaker with Bluetooth User Manual

SYLVANIA PSP328-SILVER_CP1_AMZ

SYLVANIA Portable Speaker with Bluetooth User Manual

Model: PSP328-SILVER_CP1_AMZ | Brand: SYLVANIA

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your SYLVANIA Portable Speaker with Bluetooth. Please read this manual thoroughly before using the product to ensure proper function and longevity.

WHAT'S IN THE BOX

- SYLVANIA Portable Speaker
- USB Recharge Cable
- 3.5 mm AUX Audio Cable (50 cm)

PRODUCT OVERVIEW

The SYLVANIA Portable Speaker is designed for robust audio performance with its double subwoofer and heavy bass capabilities, making it suitable for various events. It features Bluetooth connectivity for seamless pairing with smartphones, tablets, and other Bluetooth-enabled devices, along with an AUX input for wired connections.

Key Features

- **SUPER SOUND:** Features a huge stereo sound with 2 X 4-Inch Hi-Fi speakers, offering adjustable treble, bass, and volume controls.
- **STYLISH:** Equipped with cool blue LED lights around the speakers for enhanced visual appeal.
- **ACCESSIBILITY:** Easily connects to iPhone, iPad, Android, and any Bluetooth-enabled device. AUX Input is available for non-Bluetooth devices.
- **EASY SETUP:** Simply turn on the speaker to enter pairing mode, then select it from your device's Bluetooth

menu to start streaming music.

Product Dimensions


The speaker measures approximately 8 inches (Depth) x 7 inches (Width) x 15 inches (Height) and weighs 1 pound.



This image displays the front of the SYLVANIA Portable Bluetooth Speaker in silver, featuring two large speaker grilles with illuminated blue LED lights, and control knobs for bass and treble at the top.



T



This image provides a side and front view of the SYLVANIA Portable Bluetooth Speaker, clearly indicating its dimensions: approximately 15.5 inches in height, 8.2 inches in width, and 7 inches in depth, highlighting its portable design.

SETUP

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB Recharge Cable to the DC 5V port on the speaker and plug the other end into a compatible USB charging block (not included). The Charging LED will indicate the charging status.

Powering On/Off

Locate the ON/OFF switch on the top panel of the speaker. Slide the switch to the 'ON' position to power on the device. Slide it to the 'OFF' position to power off.

Bluetooth Pairing

1. Ensure the speaker is powered on. The Working Mode LED (blue) will flash, indicating it is in Bluetooth pairing mode.
 2. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.
 3. Search for available devices and select 'SYLVANIA' (or similar name) from the list.
 4. Once connected, the Working Mode LED will stop flashing and remain solid blue. You are now ready to stream audio.
-

OPERATING INSTRUCTIONS

Audio Playback

The speaker supports audio playback via Bluetooth and AUX input.

- **Bluetooth Mode:** After successful pairing, play audio directly from your connected device. Use the play/pause, next/previous track buttons on the speaker or your device.
- **AUX Input Mode:** Connect an external audio device using the 3.5mm AUX Audio Cable to the 'AUX IN' port. Press the 'MODE' button on the speaker until the Working Mode LED turns red, indicating AUX mode. Play audio from your connected device.

Controls

- **Volume Control:** Use the '+VOLUME-' slider on the top panel to adjust the overall volume.
 - **Bass Control:** Rotate the 'BASS' knob to increase or decrease the bass output.
 - **Treble Control:** Rotate the 'TREBLE' knob to increase or decrease the treble output.
 - **Mode Button:** Press the 'MODE' button to switch between Bluetooth and AUX input modes.
-

MAINTENANCE

To ensure optimal performance and longevity of your speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

- **Water Exposure:** This speaker is NOT waterproof. Avoid exposing it to water, rain, or excessive moisture.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Connect the speaker to a power source using the USB Recharge Cable and allow it to charge.
Cannot connect via Bluetooth.	Speaker is not in pairing mode or device Bluetooth is off.	Ensure the speaker is powered on and the blue Working Mode LED is flashing. Turn off and on your device's Bluetooth. Move closer to the speaker.
Sound is distorted or unclear.	Volume too high or audio source quality is low.	Reduce the volume on both the speaker and your connected device. Adjust Bass and Treble knobs. Try a different audio source.
No sound from AUX input.	Incorrect mode selected or cable not fully inserted.	Press the 'MODE' button until the Working Mode LED is red. Ensure the AUX cable is securely connected to both the speaker and the audio device.

SPECIFICATIONS

Feature	Specification
Model Name	PSP328-SILVER_CP1_AMZ
Speaker Type	Outdoor
Connectivity Technology	Bluetooth, USB
Compatible Devices	Smartphone, Tablet
Subwoofer Diameter	4 Inches
Audio Output Mode	Stereo
Color	Silver
Product Dimensions	8"D x 7"W x 15"H
Item Weight	1 Pounds
Is Waterproof	FALSE
Battery Capacity	1200 mAh

Feature	Specification
Bluetooth Range	10 Meters
Manufacturer	CURTIS INTERNATIONAL LTD
Country of Origin	China
UPC	058465795931

WARRANTY INFORMATION

This product comes with a 90-day limited warranty. For specific details regarding warranty coverage and claims, please refer to the documentation included with your purchase or contact SYLVANIA customer support.

SUPPORT

For further assistance or to download the official User Manual in PDF format, please visit the following link [User Manual \(PDF\)](#)