

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Timex](#) /
- › [Timex Men's Easy Reader Watch User Manual](#)

Timex TW2P75600

Timex Men's Easy Reader Watch

USER MANUAL

Product Overview

The Timex Men's Easy Reader Watch (Model TW2P75600) is designed for clear readability and classic style. This timepiece features a durable silver-tone brass case, a white dial with full Arabic numerals, and a comfortable black genuine leather strap. It incorporates Timex's signature Indiglo light-up dial for visibility in low-light conditions and is water-resistant up to 30 meters.





Figure 1: Front view of the Timex Men's Easy Reader Watch, showcasing its clear white dial, black Arabic numerals, and black leather strap.



Figure 2: The Timex 'analog life' brand image, reflecting the philosophy behind the watch design.



EASY READER

Simplicity & Effortless Style

Figure 3: The Timex Easy Reader watch, highlighting its simple and effortless design.

Setup

1. Setting Time:

Pull the crown (the small knob on the side of the watch) out to the furthest position. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time. Push the crown back in to start the watch.

2. Setting Date:

For models with a date window, pull the crown out to the first click position. Rotate the crown (usually counter-clockwise) to adjust the date. If the date changes at noon, advance the time by 12 hours. Push the crown back in when finished.

3. Adjusting the Strap:

The genuine leather strap is adjustable to fit various wrist sizes. Use the buckle to secure the watch comfortably on your wrist. Ensure it is snug but not too tight to allow for proper circulation.



Figure 4: The Timex Easy Reader watch on a wrist, emphasizing its clear dial for quick time reading.

Operating Instructions

- **Indiglo Night-Light:**

To activate the Indiglo night-light, simply press and hold the crown. The entire dial will illuminate, allowing you to read the time in the dark. Release the crown to turn off the light.

- **Water Resistance:**

This watch is water resistant to 30 meters (100 feet). This means it is suitable for splashes or brief immersion in water, such as washing hands or light rain. It is **not** suitable for swimming, bathing, or diving. Avoid pressing the crown while the watch is wet.



Figure 5: Visual representation of the watch's key features: an easy-to-read dial, the Indiglo backlight in action, and its classic aesthetic.

Maintenance

- **Cleaning:**

Wipe the watch case and crystal with a soft, damp cloth. For the leather strap, use a dry cloth to remove dirt. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or strap.

- **Strap Care:**

Leather straps can wear over time. Avoid prolonged exposure to direct sunlight, extreme temperatures, and excessive moisture to preserve the strap's life and appearance. If the strap becomes stiff or cracked, consider replacing it.

- **Battery Replacement:**

The watch uses 1 Lithium Metal battery (included). When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not running	Battery depleted; crown pulled out.	Push crown in fully. Replace battery (professional service recommended).
Indiglo not working	Battery low or depleted.	Replace battery.
Date not changing correctly	Date set at wrong time (AM/PM).	Advance time by 12 hours and reset date.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Timex customer support.

Specifications

- Model Number:** TW2P75600
- Case Diameter:** 38mm
- Case Material:** Brass (Silver-tone)
- Crystal Material:** Mineral Glass
- Strap Material:** Genuine Leather (Black)
- Strap Width:** 20mm
- Water Resistance:** 30m (100ft)
- Light Feature:** Indiglo Night-Light
- Movement:** Quartz
- Battery:** 1 Lithium Metal battery (included)
- Product Dimensions:** 2.99 x 4.17 x 3.23 inches; 1.6 ounces

Warranty Information

Timex watches are manufactured to the highest quality standards and are warranted against manufacturing defects. For detailed warranty terms and conditions, please refer to the official Timex website or the warranty card included with your purchase. Keep your proof of purchase for warranty claims.

Support

For further assistance, frequently asked questions, or to download the full user manual in PDF format, please visit the official Timex support page or their brand store.

- [Download User Manual \(PDF\)](#)
- [Visit the Timex Brand Store](#)