

EdgeStar BR2001SS

EdgeStar BR2001SS Refrigerator for Kegerator Conversion

Model: BR2001SS | Brand: EdgeStar

1. OVERVIEW

The EdgeStar BR2001SS is an ultra-low temperature stainless steel refrigerator specifically designed for conversion into a kegerator. This unit provides efficient cooling for beverages, maintaining temperatures from the low 30s to the mid 40s Fahrenheit. It features a durable stainless steel door and ample capacity to store up to a half-shell Sankey standard keg. Included casters ensure easy mobility, allowing for flexible placement. Please note that this unit is not compatible with Coors or Miller rubberized kegs or other oversized kegs.

Key Features:

- Refrigerator Only:** Designed for use with existing kegerator hardware and components.
- Temperature Range:** Capable of cooling beverages from the low 30s to the mid 40s Fahrenheit.
- Stainless Steel Door:** Durable and aesthetically pleasing stainless steel door.
- Ample Capacity:** Accommodates up to a full-sized, half-shell Sankey standard keg.
- Easy Mobility:** Equipped with casters for convenient relocation.
- Convertible:** Can be used as a standard refrigerator with included tower hole cap.
- UL Listed:** Certified for electrical safety.

2. SAFETY INFORMATION

For your safety and to reduce the risk of fire, electric shock, or injury, please read and follow all instructions and warnings carefully before operating this appliance.

- Ensure the unit is connected to a properly grounded electrical outlet.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended for freestanding use only.
- Proposition 65 Warning: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. SETUP

3.1 Unpacking

Carefully remove all packaging materials. Retain packaging for future transport or storage. Inspect the unit for any shipping damage. If damage is found, contact your retailer immediately.

3.2 Placement

Place the unit on a flat, stable surface away from direct sunlight or heat sources. Ensure adequate air circulation around the unit. Allow at least 5 inches of space between the back and sides of the unit and any adjacent walls to ensure proper ventilation.



Figure 3.2.1: Front view of the EdgeStar BR2001SS refrigerator, showcasing its stainless steel door and overall design.



Figure 3.2.2: Angled view of the EdgeStar BR2001SS refrigerator, highlighting its compact design and casters for mobility.



Figure 3.2.3: Diagram showing the dimensions of the EdgeStar BR2001SS refrigerator: 35 inches height, 20 inches width, and 26.5 inches depth.

3.3 Electrical Connection

Connect the appliance to a dedicated, grounded 115V/60Hz electrical outlet. Do not use extension cords or adapter plugs. Ensure the electrical supply matches the requirements listed on the appliance's rating label.

3.4 Door Reversal

The door of the BR2001SS is reversible, allowing it to open from either the left or right side. Refer to the detailed instructions in the full product manual for the step-by-step process of reversing the door swing.

3.5 Caster Installation

The unit comes with casters for enhanced mobility. To install, carefully tilt the unit and secure the casters into the designated slots at the bottom corners of the refrigerator. Ensure all casters are firmly attached before returning the unit to an upright position.



Figure 3.5.1: Close-up view of one of the durable caster wheels, designed for easy movement of the unit.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator's temperature is controlled by a dial located inside the unit. Turn the dial to adjust the cooling level. Lower numbers indicate warmer temperatures, while higher numbers indicate colder temperatures. For optimal beverage cooling, set the dial to achieve temperatures in the low 30s to mid 40s Fahrenheit.



Figure 4.1.1: Interior view of the refrigerator, highlighting the manual temperature control dial with settings from "Warmer" to "Colder".

4.2 Keg Installation (for Kegerator Conversion)

This unit is designed to accommodate up to a full-sized, half-shell Sankey standard keg. To convert to a kegerator, you will need to install your own kegerator hardware and components (not included). The unit features a pre-cut tower hole for easy integration of a draft tower. Ensure proper sealing and connection of all components to prevent leaks and maintain optimal pressure.




Figure 4.2.1: Visual guide illustrating the types and capacities of kegs that can be stored, including full-size, pony, slim-pony, sixth barrel, and Cornelius kegs. Note that oversized kegs are not compatible.



Figure 4.2.2: Close-up of the pre-drilled tower hole on the top surface of the refrigerator, which comes with a cap for use when not converting to a kegerator.

4.3 Using as a Refrigerator Only

If you wish to use the BR2001SS solely as a refrigerator, ensure the included tower hole cap is securely in place. The unit comes with wire rack shelving for organizing beverages or other items. The protective floor plate adds durability for various uses.



Figure 4.3.1: Interior view of the refrigerator, showing the two wire shelves and the spacious compartment suitable for various beverages or food items.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain the efficiency and appearance of your refrigerator. Unplug the unit before cleaning. Use a soft cloth with a mild detergent and warm water to clean the interior and exterior surfaces. Avoid abrasive cleaners or solvents. For the stainless steel door, use a stainless steel cleaner to prevent streaks and maintain its luster.

5.2 Defrosting

This unit features an automatic defrost system, minimizing the need for manual defrosting. However, if excessive ice buildup occurs, unplug the unit and allow the ice to melt naturally. Do not use sharp objects to remove ice.

5.3 Long-Term Storage

If the unit will not be used for an extended period, unplug it, empty its contents, and clean it thoroughly. Leave the door slightly ajar to prevent odors and mold growth. Store the unit in a dry, well-ventilated area.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not operate	No power supply; tripped circuit breaker/blown fuse; power cord not fully plugged in.	Check power connection; reset circuit breaker or replace fuse; ensure plug is securely inserted.
Unit is not cold enough	Temperature setting is too warm; door is not closed properly; excessive door openings; unit is near a heat source; poor ventilation.	Adjust temperature to a colder setting; ensure door is sealed; reduce frequency of door openings; relocate unit away from heat; ensure adequate clearance for ventilation.
Excessive vibration	Unit is not level; casters are loose.	Adjust unit to be level; tighten casters.
Noise from unit	Normal operating sounds (refrigerant flow, fan motor); unit not level.	These sounds are normal; ensure unit is level.

7. SPECIFICATIONS

Feature	Detail
Brand Name	EdgeStar
Model Info	BR2001SS
Item Weight	98 pounds
Product Dimensions	20 x 26.5 x 35 inches (D x W x H)
Capacity	2 Cubic Feet (Refrigerator Fresh Food Capacity)
Annual Energy Consumption	270 Kilowatt Hours
Installation Type	Freestanding

Feature	Detail
Form Factor	Tower
Special Features	Compact
Color	Stainless-steel
Voltage	115 Volts
Wattage	105 watts
Defrost System	Automatic
Door Hinges	Reversible
Door Material Type	Stainless Steel
Shelf Type	Wire
Number Of Shelves	2
With Casters	Yes
Certification	UL

8. WARRANTY AND SUPPORT

EdgeStar products typically come with a limited manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official EdgeStar website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact EdgeStar customer service. Contact information can usually be found on the manufacturer's website or in your product documentation.

© 2024 EdgeStar. All rights reserved.


Documents - EdgeStar – BR2001SS

[\[pdf\]](#) [Specifications](#) [Dimension Guide](#) [Guide](#) [Warranty](#)

BR2001BL BR2001SS Dimensional Guide V2 0 10072019 Administrator edgestar br2001 specification sheet s1 img b build mediabase specifications 1167674 |||

Document Type: Dimensional Drawing Model: BR2001BL, **BR2001SS** Version: 2.0 01012019 20 3/16 512 mm Exterior Dimensions 25 11/16 652 mm 24 9/16 624 mm 20 1/2 520 mm 35 1/8 892mm 33 1/8 841 mm 8 1/8 206 mm 2 3/4 70 mm Front View Side View EdgeStar, 8606 Wall St, S...

lang:en **score:51** filesize: 347.15 K page_count: 3 document date: 2019-10-07






[pdf] User Manual Owner's Manual Specifications Warranty Label

EdgeStar BR2001 User Manual V3 1 09162021 edgestar br2001 owners manual s1 img b kegerator mediabase specifications 1167674 |||

Freestanding Kegerator www.edgestar.com BR2001BL **BR2001SS** Owner's Manual V3.1-09162021 Important Safety Information Improper handling can cause serious damage to the EdgeStar kegerator and / or injury to the user. This kegerator is designed for domestic indoor use only. Do not use the unit for ...

lang:en score:39 filesize: 781.18 K page_count: 19 document date: 2021-11-08




[pdf] Specifications Guide Label

BR2001BL SS Energy Guide V1 1 12072022 EdgeStar Kegerators Beverage Appliances

KC2000TWINCAFE br2001xx energy guide s1 img b compactappliance mediabase specifications edgestar 1525911 |||

U.S. Government Federal law prohibits removal of this label before consumer purchase. Refrigerator Automatic Defrost Ferguson Enterprises Models BR2001BL , **BR2001SS** Capacity: 4.9 Cubic Feet Compare ONLY to other labels with yellow numbers. Labels with yellow numbers are based on the same test pr...

lang:es score:36 filesize: 95.75 K page_count: 1 document date: 2022-12-07




[pdf] Specifications Guide Label

BR2001BL SS Energy Guide V1 1 12072022 EdgeStar KC2000KOM 20 Inch Wide Single Tap Kombucha Kegerator with Reversible Door Ferguson Homebr2001xx energy guides1 img b build mediabase specifications edgestar 1300673 br2001xx guide |||

U.S. Government Federal law prohibits removal of this label before consumer purchase. Refrigerator Automatic Defrost Ferguson Enterprises Models BR2001BL , **BR2001SS** Capacity: 4.9 Cubic Feet Compare ONLY to other labels with yellow numbers. Labels with yellow numbers are based on the same test pr...

lang:es score:33 filesize: 95.75 K page_count: 1 document date: 2022-12-07




[pdf] Dimension Guide Warranty

BR2001BL BR2001SS Drawing V1 0 08092018 Administrator 2931312 secure img1 fg wfcdn docresources 293

Document Type: Dimensional Drawing Model: BR2001BL **BR2001SS** Version: V1.0 08092018 20 3/16 512 mm Exterior Dimensions 25 11/16 652 mm 24 9/16 624 mm 20 1/2 520 mm 35 1/16 890 mm 33 1/8 841 mm 8 1/8 206 mm 2 3/4 70 mm Front View Side View EdgeStar, 8606 Wall St, ...

lang:en score:33 filesize: 356.51 K page_count: 3 document date: 2018-08-09



[\[pdf\] Label](#)

EDGESTAR BR2001BL BR2001SS UL PC140 DQ 1856413 secure img1 fg wfcdn docresources 0 185

|||

U.S. Government Federal law prohibits removal of this label before consumer purchase. Refrigerator Automatic Defrost Living Direct, Inc. Model: BR2001BL
BR2001SS Capacity: 4.9 Cubic Feet Compare ONLY to other labels with yellow numbers. Labels with yellow numbers are based on the same test proce...

lang:es score:26 filesize: 163.96 K page_count: 1 document date: 2019-09-04