

[Manuals.plus](#) /

› [Dorman](#) /

› [Dorman 90132 Front Driver Side Interior Door Handle Bezel Instruction Manual](#)

Dorman 90132

Dorman 90132 Front Driver Side Interior Door Handle Bezel Instruction Manual

Model: 90132

PRODUCT OVERVIEW

This Dorman 90132 interior door handle bezel is engineered as a direct replacement part, designed to match the fit, appearance, and function of the original bezel on specified Chevrolet vehicles. It is manufactured from quality materials to ensure reliable performance and a long service life, restoring the aesthetic and functional integrity of your vehicle's interior door handle assembly. This part is compatible with Chevrolet Trailblazer (2002-2009) and Chevrolet Trailblazer EXT (2002-2006) models.

PACKAGE CONTENTS

- One (1) Dorman 90132 Interior Door Handle Bezel - Front Driver Side, Textured Gray

INSTALLATION INSTRUCTIONS (SETUP)

The Dorman 90132 door handle bezel is designed for direct replacement. Basic hand tools may be required for removal of the old part and installation of the new one. Always refer to your vehicle's specific service manual for detailed instructions and safety precautions.

1. **Preparation:** Ensure the vehicle is parked on a level surface with the engine off. Gather necessary tools, which may include a flat-head screwdriver, Phillips-head screwdriver, or trim removal tools.
2. **Remove Old Bezel:** Carefully pry off the existing door handle bezel. This may involve gently prying around the edges with a trim removal tool to release retaining clips. Be cautious not to damage the surrounding door panel.
3. **Inspect Mounting Area:** Once the old bezel is removed, inspect the mounting area for any broken clips, debris, or damage that might prevent proper seating of the new bezel. Clean the area if necessary.
4. **Install New Bezel:** Align the new Dorman 90132 bezel with the opening on the door panel. Press firmly around the edges until the retaining clips snap securely into place. Ensure the bezel is flush with the door panel and does not wobble.
5. **Test Functionality:** Verify that the door handle operates smoothly and without obstruction after the new bezel is installed.



Figure 1: Front view of the Dorman 90132 bezel, showing the handle opening and control cutouts.



Figure 2: Rear view of the bezel, highlighting the mounting clips and manufacturer markings.



Figure 3: Angled perspective of the bezel, illustrating its three-dimensional form.

OPERATING THE BEZEL

The door handle bezel serves as a decorative and functional frame for the interior door handle and associated controls (such as window switches, if applicable to your vehicle's configuration). Once installed, it requires no specific operation beyond its passive role in securing and presenting the door handle assembly. Ensure that the door handle and any integrated switches move freely within the bezel's opening.

MAINTENANCE

To maintain the appearance and integrity of your Dorman 90132 door handle bezel, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the bezel regularly with a soft, damp cloth to remove dust and grime. For more stubborn dirt, use a mild automotive interior cleaner applied to the cloth, not directly to the bezel. Avoid abrasive cleaners or solvents, as these can damage the textured finish.
- **Inspection:** Periodically check the bezel for any signs of looseness, cracks, or damage. Address any issues promptly to prevent further deterioration or potential safety hazards.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bezel does not fit flush or is loose.	Broken or bent retaining clips on the bezel or door panel. Incorrect alignment during installation. Debris obstructing the mounting area.	Inspect clips; if broken, the bezel may need replacement. Re-align and firmly press the bezel into place. Remove bezel and clean the mounting area thoroughly.
Door handle or switches are obstructed.	Bezel not seated correctly. Internal components of the door handle assembly are misaligned.	Ensure the bezel is fully snapped into place. Remove bezel and check the door handle mechanism for proper alignment.
Color mismatch (if applicable).	Product received is a different shade than expected.	Verify the part number and color description against your order. Contact the seller if incorrect. Note: This product is described as "Textured Gray".

PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	Dorman
Model Number	90132
Part Type	Interior Door Handle Bezel
Side	Front Driver Side
Color/Finish	Textured Gray
Item Weight	2.61 ounces
Product Dimensions	3.7 x 3.7 x 11.8 inches
Manufacturer Part Number	90132
OEM Part Number	25894592
Special Features	Durable, Easy to Install
First Available Date	June 8, 2015

WARRANTY AND SUPPORT

For detailed warranty information regarding your Dorman product, please refer to the official warranty document available from the manufacturer.

Warranty Document: [Download PDF](#)

For additional product support, technical assistance, or to explore other Dorman products, please visit the official Dorman store:

Dorman Store: [Visit Dorman Store on Amazon](#)



© 2024 Dorman Products. All rights reserved.

This manual is for informational purposes only. Always consult a qualified professional for vehicle repairs.