

Northlight 31450614

Northlight 6.5' Northern Pine Full Artificial Christmas Tree Instruction Manual

Model: 31450614

PRODUCT OVERVIEW

The Northlight 6.5' Northern Pine Full Artificial Christmas Tree features perfectly shaped tapered tips with a medium green color, offering a natural, lush appearance. This unlit tree is designed for indoor use only and comes with a black metal tree stand.

Key Features:

- **Height:** 6.5 feet (from base of stand to tree top)
- **Base Diameter:** 50 inches (at widest point)
- **Tips:** 1838 tips, 1.75 inches wide
- **Profile:** Full
- **Construction:** Hinged branch
- **Material:** Polyvinyl Chloride (PVC) / Metal
- **Special Feature:** Flame retardant
- **Included:** Black metal tree stand



Image: Northlight 6.5' Northern Pine Full Artificial Christmas Tree.




Figure is 6 ft. tall

Image: Diagram illustrating the tree's dimensions (6.5 feet tall, 50-inch base diameter).

SAFETY INFORMATION

- For indoor use only.
- Keep away from open flames or direct heat sources.
- Ensure the tree stand is properly assembled and tightened to prevent tipping.
- Keep small children and pets away during assembly to avoid injury from sharp parts.

PARTS LIST

Before assembly, ensure all parts are present:

- Tree Sections (typically labeled A, B, C)
- Metal Tree Stand
- Eye Bolts (for stand)

SETUP INSTRUCTIONS

Assembling the Stand:

1. Unfold the metal tree stand into an X-shape on a level surface.
2. Insert the eye bolts into the designated holes on the stand, but do not fully tighten them yet.

Assembling the Tree Sections:

1. Identify the bottom section of the tree (usually marked 'C' or the largest section).
2. Carefully insert the bottom section into the tree stand.
3. Once the bottom section is securely in place, fully tighten the eye bolts on the stand to hold the tree firmly.
4. Identify the middle section (usually marked 'B'). Insert it into the top of the bottom section.
5. Identify the top section (usually marked 'A' or the smallest section). Insert it into the top of the middle section.

Fluffing the Branches:

Fluffing is crucial for achieving a full and natural appearance. This process may take some time.

1. Starting from the bottom of the tree, gently pull down and spread out each branch tip.
2. Work your way up the tree, separating individual branch tips to create a full, natural appearance.
3. Adjust branches to fill any gaps and achieve the desired fullness.

Video: General instructions on how to set up an unlit artificial Christmas tree, including stand assembly and section placement.

Video: Detailed guide on how to properly fluff the branches of an artificial Christmas tree for a fuller look.

MAINTENANCE

- Regularly check the tree stand for stability.
- Dust the branches as needed with a soft cloth or duster.

STORAGE

- Carefully remove all ornaments and lights.
- Disassemble the tree sections in reverse order of assembly.

- Compress the branches of each section.
- Store the tree sections and stand in their original box or a suitable storage bag in a cool, dry place.

TROUBLESHOOTING

- **Tree is wobbly:** Ensure all eye bolts on the stand are fully tightened. Check that the tree sections are securely inserted into each other.
- **Branches are not full:** Continue fluffing and adjusting individual branch tips. This process is crucial for achieving a lush look.

SPECIFICATIONS

- **Brand:** Northlight
- **Model Number:** 31450614
- **Dimensions:** 6.5' high (78 inches) x 50" base diameter
- **Item Weight:** 44 pounds
- **Material:** Polyvinyl Chloride (PVC) / Metal
- **Tip Count:** 1838
- **Tip Width:** 1.75 inches
- **Special Features:** Unlit, Full profile, Flame retardant, Hinged branch construction
- **UPC:** 191296056045, 009312846528

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Northlight directly.