Beautyrest BR54-0524

Beautyrest Heated Electric Blanket

Instruction Manual

Model: BR54-0524

Important Safeguards

Please read all instructions carefully before using your Beautyrest Heated Electric Blanket. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Do not use with a damaged cord or plug. If damaged, do not attempt to repair. Contact customer support.
- Do not use with pointed objects.
- Do not use if the blanket is folded, bunched, or tucked in. Ensure the blanket is spread out evenly.
- Do not lay on top of the blanket to prevent damage to internal coils.
- Keep the controller uncovered and away from other heat sources.
- Ensure the cord is loose and not twisted or pinched.
- This blanket is designed for household use only.
- Unplug the blanket when not in use.



Image: Illustrates Beautyrest's commitment to quality and safety compared to other brands.




Image: Highlights the rigorous safety testing and UL certification of the blanket.

Product Overview

The Beautyrest Heated Electric Blanket provides luxurious warmth and comfort with advanced features for a restful sleep. It is crafted from 100% Microlight Plush fabric, offering exceptional softness and coziness.

- **Secure Comfort Technology:** Designed to virtually eliminate Electromagnetic Field (EMF) emissions for peace of mind.
- **Material:** Ultra-soft microlight plush fabric with flexible wires for comfort.
- **Heat Settings:** Features 20 different temperature settings for customizable warmth, ranging from 85°F to 105°F (temperature may vary based on ambient room temperature).
- **Auto Shut-Off:** Includes a 10-hour auto shut-off feature for safety and energy saving.
- **Pre-Heat Feature:** A 1-hour pre-heat function to quickly warm the blanket before use.
- **Dual Controllers:** Queen and King sizes come with two controllers, allowing individual temperature control for each side of the bed. Twin and Full sizes include one controller.



Image: The Beautyrest Heated Electric Blanket in Ivory, shown on a bed with its dual controllers.




Image: Visual representation of key features: soft & cozy fabric, virtually zero EMF, fast heating, and machine washable.




Image: Cross-section diagram illustrating the construction of the blanket, including the flexible heating wires.

Setup

1. **Unpack:** Carefully remove the heated blanket from its packaging.
2. **Placement:** Lay the blanket flat on your bed, ensuring it is spread out evenly without any folds, bunches, or tucks. The connectors should be positioned at the foot of the bed.
3. **Connect Controller(s):**
    - For Twin/Full sizes: Connect the single controller cord to the blanket connector.
    - For Queen/King sizes: Connect each of the two controller cords to their respective blanket connectors. Ensure each controller is connected to the correct side of the blanket if dual control is desired.
4. **Plug In:** Plug the power cord(s) from the controller(s) into a 110-120V AC wall outlet. Ensure the outlet is easily accessible.



Image: Illustrates the correct setup for different blanket sizes, showing controller and cord placement.

Operating Instructions

Your Beautyrest Heated Electric Blanket is designed for easy and intuitive operation.



Image: Detailed diagram of the controller, highlighting its features and power specifications.

Frequently Asked Questions

Q:Why is my light blinking?

A: Unplug and reconnect, ensuring the controller is properly connected. If the issue persists, contact us—we're here to help.

Q: Why does my blanket not heat well?

A: Ensure the blanket is powered on and set to the maximum level. Allow time for it to heat up.

Q: Only parts of my blanket are getting warm.

A: This is usually caused by a bunched or pinched heating element. Lay the blanket flat, untucked, and free from heavy objects. Straighten the heating wires as needed to restore function. Lay the blanket flat and run your fingers along the wire, paying special attention to the top and bottom of the blanket where the wire bends. If any portion of the wire is twisted on itself, manually twist it back.

Image: Close-up of the controller, showing the LCD screen and various function buttons.

1. **Power On/Off:** Press the power button on the controller to turn the blanket on or off. The LED indicator will

illuminate when on.

2. **Adjust Heat Setting:** Use the temperature up/down buttons to select your desired heat level from 1 to 20.
3. **Pre-Heat Function:** Press the "Pre-Heat" button to activate a 1-hour rapid warming cycle. The blanket will automatically return to your last selected heat setting after 1 hour.
4. **Set Auto Shut-Off Timer:** Press the "Timer" button to cycle through auto shut-off options from 1 to 10 hours in 1-hour increments. The blanket will automatically turn off after the selected time.
5. **Dual Control (Queen/King):** If your blanket has two controllers, each controller operates its respective side of the blanket independently.

Care and Maintenance

Proper care will extend the life of your Beautyrest Heated Electric Blanket.

- **Machine Washable:** The blanket is machine washable for easy care.
- **Before Washing:** Always disconnect the controller(s) from the blanket and the wall outlet before washing.
- **Washing Instructions:**
  - Machine wash cold on a gentle cycle.
  - Do not bleach.
  - Do not dry clean.
- **Drying Instructions:**
  - Tumble dry on low heat or line dry.
  - Ensure the blanket is completely dry before reconnecting to power.
  - Do not iron.
- **Storage:** When not in use, store the blanket neatly folded in a cool, dry place. Avoid placing heavy objects on top of the blanket during storage.



Image: Visual guide on proper usage and handling to ensure longevity and safety.

Troubleshooting

If you experience issues with your heated blanket, refer to the common problems and solutions below.

Problem	Possible Cause / Solution
My light is blinking.	Unplug and reconnect, ensuring the controller is properly connected. If the issue persists, contact customer support.

Problem	Possible Cause / Solution
My blanket does not heat well.	Ensure the blanket is powered on and set to the maximum level. Allow time for it to heat up.
Only parts of my blanket are getting warm.	This is usually caused by a bunched or pinched heating element. Lay the blanket flat, untucked, and free from heavy objects. Straighten the heating wires as needed to restore function. Lay the blanket flat and run your fingers along the wire, paying special attention to the top and bottom of the blanket where the wire bends. If any portion of the wire is twisted on itself, manually twist it back.



Image: Common troubleshooting questions and their solutions as provided by the manufacturer.

Specifications

- **Model Name:** Plush Electric Blanket Throw For Cold Weather
- **Model Number:** BR54-0524
- **Material:** 100% Microlight Plush Polyester
- **Color:** Ivory (King size)
- **Product Dimensions:** 100"L x 90"W (King size)
- **Power Input:** 110-120V @ 60Hz (Max 160W)
- **Controller Cord Length:** 12.5 ft
- **Power Cord Length:** 6 ft
- **Safety Certification:** UL Certified
- **EMF:** Virtually Zero EMF

- **Care:** Machine Washable
- **Item Weight:** 9.53 Pounds



Image: Illustrates the construction of the power cord, emphasizing safety and durability features.



Image: Displays the range of available colors and a size chart for different blanket dimensions.

Warranty and Support

Your Beautyrest Heated Electric Blanket is backed by a 5-year manufacturer's warranty, ensuring quality comfort and wellness.

For warranty claims, technical support, or any questions not covered in this manual, please refer to the official user manual or contact Beautyrest customer service.

Official User Manual (PDF): Download Here

Certificate of Compliance (PDF): Download Here

© 2025 Beautyrest. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question