Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- MaxiAids /
- > Universal Earphones Powerful Bass Response User Manual

MaxiAids B00ZPJ3M7O

Universal Earphones User Manual

Model: B00ZPJ3M7O Brand: MaxiAids

INTRODUCTION

Thank you for choosing the MaxiAids Universal Earphones. These earphones are designed to provide a high-quality audio experience in a compact and portable form factor. Featuring class-leading proprietary transducer technology, dual earphones with an elegant ergonomic design, and a great soundstage, they are suitable for a wide range of audio applications.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your earphones to ensure optimal performance and longevity.



An image showing the MaxiAids Universal Earphones, featuring the black earbud units, the coiled black cable, the 3.5mm stereo jack, and two translucent pink silicone ear tips.

SETUP

Follow these steps to set up your MaxiAids Universal Earphones:

- 1. **Unpack the Earphones:** Carefully remove the earphones and any included accessories from their packaging. Ensure the cable is not tangled.
- 2. **Select Ear Tips:** The earphones come with different sized ear tips (as shown in the product image). Choose the ear tips that provide the most comfortable and secure fit for your ears. A good seal is crucial for optimal sound quality and bass response. To change, gently pull off the existing ear tips and push on the desired size.
- 3. **Connect to Audio Source:** Locate the 3.5mm stereo jack at the end of the earphone cable. Insert this jack firmly into the headphone port of your audio device (e.g., smartphone, tablet, computer, MP3 player).
- 4. **Insert Earphones:** Gently insert the earbud units into your ears. Ensure they are seated comfortably and securely. The left earbud is typically marked with an 'L' and the right with an 'R'.

OPERATING INSTRUCTIONS

Once connected, operating your earphones is straightforward:

- Audio Playback: Begin playing audio from your connected device. The sound will be routed through the earphones.
- Volume Control: Adjust the volume directly on your audio source device. These earphones do not feature inline volume controls.
- Comfort and Fit: If the sound quality seems poor or there is a lack of bass, re-adjust the earphones in your ears or try a different size of ear tips to achieve a better seal.

MAINTENANCE

Proper care will extend the life of your earphones:

- Cleaning:
 - Gently wipe the earbud units and cable with a soft, dry, lint-free cloth.
 - For ear tips, remove them from the earphones and clean with a mild soap and water solution. Rinse thoroughly and allow them to dry completely before reattaching.
 - Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Storage: When not in use, store your earphones in a clean, dry place, preferably in a small pouch or case to prevent tangling and damage to the cable or jack.
- Cable Care: Avoid sharply bending or twisting the cable, especially near the jack and earbud connections, as this can cause internal wire damage. Do not pull the cable to disconnect the earphones; always grasp the plug itself.

TROUBLESHOOTING

If you encounter issues with your earphones, try the following solutions:

Problem	Possible Cause	Solution
No sound or sound from only one earbud	Loose connection, incorrect audio output setting, damaged cable/jack	Ensure the 3.5mm jack is fully inserted. Check your device's volume and audio output settings. Test with another audio device to rule out device issues. Inspect the cable for visible damage.
Poor sound quality (muffled, low bass)	Improper ear tip fit, dirty ear tips/grilles, low-quality audio source	Adjust earbud position or try different sized ear tips for a better seal. Clean ear tips and earbud grilles. Ensure your audio source is of good quality.
Static or crackling sound	Loose connection, interference, damaged cable	Re-insert the 3.5mm jack. Move away from potential sources of electromagnetic interference. Inspect the cable for damage.

SPECIFICATIONS

• Frequency Range: 20-20,000Hz

• Impedance: 32 Ohm

Maximum Power Input: 60mw
Sensitivity: 108dB S.P.L. at 1KHz

Jack: 3.5mm StereoLength of Cord: 1.2m

• Color: Black

Ear Placement: In EarForm Factor: In Ear

• Product Dimensions: 5 x 3 x 0.71 inches

• Product Weight: 1.66 ounces

WARRANTY AND SUPPORT

MaxiAids products are manufactured to high-quality standards. For specific warranty information regarding your Universal Earphones, please refer to the documentation included with your purchase or visit the official MaxiAids website. For technical support or further assistance, please contact MaxiAids customer service through their official channels.

© 2025 MaxiAids. All rights reserved.



MaxiAids 2024/25 Catalog: Products for Independent Living

Explore the MaxiAids 2024/25 Catalog, your comprehensive guide to assistive products designed to enhance independent living. Discover a wide range of solutions for low vision, blindness, hearing loss, seniors, and individuals with special needs, including talking watches, magnifiers, and communication aids.



Full HD 5.0 Portable Digital Video Magnifier User Manual

Comprehensive user manual for the Full HD 5.0 Portable Digital Video Magnifier, covering product features, technical specifications, setup, operation, menu functions, and troubleshooting.



MaxiAids Order Form and Product Information

Official order form and customer testimonials for MaxiAids, a provider of assistive products for low vision, blindness, deafness, seniors, and special needs. Includes contact information and catalog details.