

EVEREADY 1012 AAA

Eveready AAA Heavy Duty Batteries - 10 Pieces Instruction Manual

Model: 1012 AAA

PRODUCT OVERVIEW

The Eveready 1012 Carbon Zinc AAA Battery pack provides reliable power for various household devices. This pack contains 10 AAA batteries designed for consistent performance in compatible electronics.

Key features include:

- **Reliable & Versatile:** Suitable for a wide range of devices such as remote controls, toys, and flashlights.
- **Leak-Resistant Design:** Engineered to help protect devices from potential damage caused by leaks.
- **Economical Value:** A 10-piece pack provides a convenient power source for everyday use.
- **Convenient Storage:** Each battery is individually wrapped to maintain freshness until use.

SETUP AND INSTALLATION

Follow these steps to correctly install Eveready AAA batteries into your devices:

1. **Identify Battery Compartment:** Locate the battery compartment on your electronic device. This is typically found on the back or bottom of the device and may be secured with a cover or screw.
2. **Open Compartment:** Open the battery compartment cover. If secured with a screw, use an appropriate screwdriver.
3. **Observe Polarity:** Inside the compartment, you will see markings indicating the correct orientation for the batteries (+ and - symbols).
4. **Insert Batteries:** Insert the Eveready AAA batteries according to the polarity markings. The positive (+) end of the battery should align with the positive terminal in the compartment, and the negative (-) end with the negative terminal.
5. **Close Compartment:** Securely close the battery compartment cover.



Image: Proper insertion of an Eveready AAA battery into a device, demonstrating correct polarity alignment.

OPERATING INSTRUCTIONS

Once installed, Eveready AAA batteries provide power to your devices. These batteries are designed for single use and are compatible with a wide range of low to medium drain devices.

- **Device Compatibility:** Use these batteries in devices requiring AAA size, such as TV remotes, small toys, flashlights, and alarm clocks.
- **Performance:** Expect consistent power output for the lifespan of the battery in appropriate devices.
- **Replacement:** Replace all batteries in a device at the same time to ensure optimal performance and prevent issues.



Image: Eveready AAA batteries are suitable for common household electronics like remotes, toys, and clocks.

MAINTENANCE AND STORAGE

Proper handling and storage can extend the shelf life and ensure the safety of your batteries.

- **Storage Conditions:** Store batteries in a cool, dry place at room temperature. Avoid extreme temperatures, direct sunlight, and high humidity.
- **Original Packaging:** Keep unused batteries in their original packaging until ready for use to prevent accidental short-circuiting.
- **Avoid Mixing:** Do not mix new and used batteries, or different types/brands of batteries, in the same device.
- **Remove from Device:** If a device will not be used for an extended period, remove the batteries to prevent potential leakage and damage.



Image: Eveready AAA batteries are individually wrapped for convenient storage and to maintain freshness.

SAFETY INFORMATION AND DISPOSAL

Adhere to the following safety guidelines to prevent injury or damage:

- **Do Not Recharge:** These are primary (single-use) batteries and are not designed to be recharged. Attempting to recharge may cause leakage, fire, or explosion.
- **Do Not Disassemble:** Do not disassemble, crush, puncture, or modify batteries.
- **Avoid Short Circuits:** Do not short-circuit the battery terminals. Keep batteries away from metal objects like coins, keys, or jewelry.
- **Keep Away from Children:** Store batteries out of reach of small children. If swallowed, seek immediate medical attention.
- **Proper Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in household waste or by incineration. Many communities offer battery recycling programs.
- **Leakage:** If a battery leaks, avoid contact with the fluid. If contact occurs, wash affected areas thoroughly with soap and water.

TROUBLESHOOTING

If your device is not functioning correctly with new Eveready AAA batteries, consider the following:

- **Check Polarity:** Ensure batteries are inserted with the correct positive (+) and negative (-) orientation as indicated in the device's battery compartment.
- **Verify Battery Contact:** Make sure the battery terminals are clean and making proper contact with the device's contacts. Gently clean contacts if necessary.
- **Replace All Batteries:** If using multiple batteries, replace all of them simultaneously with new ones. Mixing old and new batteries can reduce overall performance.

- **Device Functionality:** Test the device with another set of known good batteries to rule out a device malfunction.

SPECIFICATIONS

Brand	EVEREADY
Model Number	1012 AAA
Battery Cell Composition	Zinc Carbon
Voltage	1.5 Volts
Amperage	1.5 Amps
Reusability	Single Use
Number of Batteries	10 AAA batteries
Battery Weight	7.85 Grams (per battery)
Item Dimensions (L x W x H)	19.6 x 12 x 1.4 Centimeters (packaging)
Recommended Uses	TV Remote, Toys, Flashlights, Alarm Clocks

WHAT'S IN THE BOX

Your Eveready AAA Heavy Duty Batteries package includes:

- 10-Piece Eveready AAA Battery Pack



Image: The Eveready AAA Heavy Duty Batteries 10-piece pack as supplied.

WARRANTY AND SUPPORT

Warranty: This product comes with No Warranty as per manufacturer specifications.

Manufacturer Contact Information:

Eveready Industries India Limited
2 Rainey Park, Kolkata - 700 019
West Bengal, India

For further assistance, please refer to the contact information provided on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question