

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› **WOLTU** /

› **WOLTU BH23rt-2 Adjustable Bar Stool Instruction Manual**

WOLTU BH23rt-2

WOLTU BH23rt-2 Adjustable Bar Stool Instruction Manual

Model: BH23rt-2



Image: Two WOLTU BH23rt-2 adjustable bar stools in a kitchen environment.

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your WOLTU BH23rt-2 adjustable bar stools. Please read these instructions carefully before assembly and use to ensure safe and correct operation.

SAFETY INSTRUCTIONS

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Assemble the stool on a soft, clean surface to prevent scratches.
- **Important: Remove the protective cap from the gas lift before installation.** Failure to do so will prevent height adjustment.
- Do not stand on the stool. Use it only for seating.

- Do not exceed the maximum load capacity of 150 kg (330 lbs).
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Regularly check all screws and connections to ensure they are tight. Retighten if necessary.
- Avoid exposing the stool to direct sunlight or extreme temperatures to prevent material damage.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

Part	Quantity (per stool)
Seat with backrest	1
Gas lift cylinder	1
Base	1
Footrest ring	1
Mounting plate (pre-attached to seat)	1
Screws and Allen key	1 set

HIGH QUALITY COMFY SEAT

Wear-resistant

Water-repellent



High resilience sponge



High Quality Faux Leather



Image: Exploded view showing all components required for assembly.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your bar stool:

1. **Prepare the Base:** Place the large round base on a flat, stable surface. Ensure the anti-slip rubber ring is correctly positioned on the underside of the base to protect your floor.
2. **Insert the Gas Lift:** Insert the gas lift cylinder into the central hole of the base. **Remember to remove the protective cap from the top of the gas lift before inserting it.**
3. **Attach the Footrest:** Slide the footrest ring over the gas lift cylinder. Ensure it rests securely on the designated groove or support.
4. **Mount the Seat:** Align the mounting plate (usually pre-attached to the underside of the seat) with the top of the gas lift cylinder. Carefully lower the seat onto the gas lift, ensuring it is firmly seated. You may need to apply slight pressure.
5. **Secure the Seat:** If the mounting plate is separate, attach it to the underside of the seat using the provided screws

and Allen key. Then, place the assembled seat onto the gas lift.

6. **Final Check:** Once assembled, sit on the stool to ensure all connections are secure and the gas lift functions correctly.

360° SWIVEL AND HEIGHT ADJUSTABLE

- 360° Swivel Seat

- Seat Height Adjustable within 61-82cm



Image: Illustration of the 360° swivel and height adjustment mechanism.





Image: Close-up of the practical footrest and the anti-slip rubber ring on the base.

OPERATING INSTRUCTIONS

- **Height Adjustment:** To raise the seat, lift the lever located under the seat while standing up. To lower the seat, lift

the lever while seated. Release the lever at the desired height.

- **Swivel Function:** The seat can rotate 360 degrees freely. Simply turn the seat to face your desired direction.

MAINTENANCE

- **Cleaning:** For the faux leather seat, wipe with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Frame and Base:** Clean the metal frame and base with a soft, dry cloth. If necessary, use a slightly damp cloth and dry thoroughly.
- **Regular Checks:** Periodically check all screws and bolts to ensure they are tight. Retighten as needed to maintain stability and safety.
- **Avoid Damage:** Do not drag the stool across the floor; lift it to move to prevent damage to the base and floor.



COMFY SEAT

Padded with high density and resilience sponge, soft and comfortable.

ERGONOMIC BACKREST

It conforms to the curve of your back, protecting your spine and relieving fatigue.



Image: Close-up of the high-quality faux leather seat with resilience sponge filling.

PRACTICAL FOOT REST



Maximum load
capacity of 150kg



Anti-slip Rubber Ring



Image: Illustration highlighting the ergonomic design of the backrest.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Seat does not adjust height.	Protective cap still on gas lift.	Remove the protective cap from the top of the gas lift cylinder.
Stool is wobbly.	Screws are loose; gas lift not fully inserted.	Check and tighten all screws. Ensure the gas lift is fully inserted into the base and seat mechanism.
Difficulty swiveling.	Mechanism obstruction or damage.	Check for any obstructions. If the issue persists, contact customer support.
Noise during use.	Loose connections; friction.	Tighten all screws. Ensure the anti-slip ring is properly seated on the base.

SPECIFICATIONS

Model Number: BH23rt-2

Material: Faux Leather (seat), Metal (frame and base)

Color: Red (for this variant)

Total Height: Approx. 83-104 cm (32.7-40.9 inches)

Seat Height: Approx. 61-82 cm (24-32.3 inches)

Seat Dimensions: Approx. 47 cm (Width) x 38 cm (Depth) (18.5 x 15 inches)

Base Diameter: Approx. 39 cm (15.4 inches)

Maximum Load Capacity: 150 kg (330 lbs)

Weight per Stool: Approx. 6.9 kg (15.2 lbs)



Image: Detailed diagram showing the dimensions of the bar stool.

WARRANTY AND SUPPORT

WOLTU products are designed for quality and durability. For any questions, missing parts, or issues not covered in this manual, please contact WOLTU customer support through your purchase platform or the official WOLTU website. Please have your model number (BH23rt-2) and purchase details ready when contacting support.

For more information, visit the official WOLTU store:[WOLTU Store](#)

