



[Manuals.plus](#) /

› [ESPRIT](#) /

› [ESPRIT ES Tyler Analog Blue Dial Men's Watch - ES108391004 User Manual](#)

ESPRIT ES108391004

ESPRIT ES Tyler Analog Blue Dial Men's Watch - ES108391004 User Manual

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your ESPRIT ES Tyler Analog Blue Dial Men's Watch, model ES108391004. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image: Front view of the ESPRIT ES Tyler Analog Blue Dial Men's Watch, showcasing its blue dial, black leather strap, and silver-tone case.

SETUP

Setting the Time

1. Pull the crown (the knob on the side of the watch) out to position 2.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown back to position 0 (normal operating position) to start the watch.

Setting the Date

1. Pull the crown out to position 1.
2. Turn the crown clockwise or counter-clockwise to set the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back to position 0 (normal operating position).

Operating the Chronograph (Stopwatch)

1. **Start/Stop:** Press the upper pusher button (located above the crown) to start the chronograph. Press it again to stop the timing.

2. **Reset:** With the chronograph stopped, press the lower pusher button (located below the crown) to reset all chronograph hands to the zero position.



Image: Side view of the watch, illustrating the crown and the two pusher buttons used for time/date setting and chronograph operation.

OPERATING YOUR WATCH

Water Resistance

Your ESPRIT ES Tyler watch is water resistant up to 30 meters (3 ATM). This rating indicates the watch is suitable for everyday use and can withstand splashes, rain, or brief immersion in water. It is **not** designed for swimming, showering, or diving. To prevent water ingress, avoid operating the crown or pusher buttons when the watch is wet or submerged.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, regularly wipe the case and crystal with a soft, dry, lint-free cloth. For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. If

cleaning is necessary, gently wipe with a slightly damp cloth and mild soap, then dry thoroughly.

Battery Replacement

This watch is powered by a quartz movement, which operates on a battery. When the watch stops running, it typically indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure the watch's water resistance and proper function are maintained.

Leather Strap Care

Leather straps are natural materials and are susceptible to wear and tear from moisture, sweat, and direct sunlight. To prolong the life of your leather strap, avoid exposing it to excessive moisture and clean it regularly. Replace the strap if it becomes significantly worn, cracked, or damaged.



Image: Back view of the watch, showing the stainless steel case back with engraved details, and the black leather strap with its buckle.

TROUBLESHOOTING

Watch Not Running

- Ensure the crown is fully pushed in to position 0.
- If the watch still does not run, the battery may need replacement. Consult a qualified watch technician.

Date Not Changing

- Verify that the time is set correctly, especially past midnight for the automatic date change mechanism.
- Adjust the date manually as described in the "Setting the Date" section.

SPECIFICATIONS

Feature	Detail
Model Number	ES108391004
Brand	ESPRIT
Movement Type	Quartz
Display Type	Analog
Dial Color	Blue
Case Shape	Round
Case Diameter	44 Millimetres
Case Thickness	12 Millimetres
Band Material	Leather
Band Color	Black
Band Width	21 Millimetres
Clasp Type	Tang Buckle
Crystal Material	Crystal
Water Resistance Depth	30 Metres (3 ATM)
Item Weight	46 Grams

WARRANTY AND SUPPORT

Your ESPRIT ES Tyler watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions regarding coverage and duration. For technical support, service, or warranty claims, please contact your authorized ESPRIT retailer or the official ESPRIT customer service.

Always retain your purchase receipt or proof of purchase, as it is required for warranty validation.

