

Surtek 130567

Surtek 130567 Yarn Construction 65m Instruction Manual

Model: 130567

1. INTRODUCTION

This manual provides essential instructions for the proper use, setup, maintenance, and troubleshooting of your Surtek 130567 Yarn Construction 65m. Please read this manual thoroughly before using the product to ensure safe and effective operation.

2. PRODUCT OVERVIEW

The Surtek 130567 is a durable cotton yarn designed for various construction and general-purpose applications. It comes in a convenient 65-meter length, suitable for tasks requiring strong, reliable string.



This image displays the Surtek 130567 Yarn, presented as a large, cylindrical spool of white cotton thread. The yarn is tightly wound and encased in a transparent plastic film, indicating it is new and protected. The texture of the twisted cotton fibers is visible through the wrapping.

3. SETUP

1. **Unpackaging:** Carefully remove the yarn spool from its packaging. Retain any labels or information for future reference.
2. **Initial Inspection:** Inspect the yarn for any visible damage or defects. Do not use if the yarn appears compromised.
3. **Dispensing:** Locate the free end of the yarn. It is typically secured to prevent tangling during transit. Gently pull the yarn from the spool as needed, ensuring it unwinds smoothly.

4. OPERATING

The Surtek 130567 Yarn is versatile and can be used for various applications:

- **Marking Lines:** Ideal for establishing straight lines in construction, gardening, or DIY projects. Secure one end and stretch the yarn taut to create a visual guide.
- **Tying and Bundling:** Use the yarn to tie objects together, secure bundles, or create temporary fasteners.
- **Crafts and Hobbies:** Suitable for various crafting activities where a strong cotton thread is required.

Always ensure the yarn is securely fastened at both ends when used for marking or tension-bearing applications to prevent snapping or shifting.

5. MAINTENANCE

- **Storage:** Store the yarn in a cool, dry place away from direct sunlight and moisture. Prolonged exposure to damp conditions can weaken cotton fibers.
- **Protection:** Keep the yarn away from sharp objects or abrasive surfaces that could fray or cut the fibers.
- **Cleaning:** If the yarn becomes soiled, gently wipe it with a damp cloth. Avoid harsh chemicals.

6. TROUBLESHOOTING

- **Yarn Tangling:** If the yarn tangles during dispensing, gently unwind it. Avoid pulling forcefully, which can worsen knots. Ensure the spool is stable when pulling yarn.
- **Yarn Breakage:** If the yarn breaks frequently, inspect it for frayed sections or excessive tension. Ensure the application does not exceed the yarn's strength capacity.

7. SPECIFICATIONS

Feature	Detail
Brand	Surtek
Model Number	130567
Material	Cotton
Length	65 meters
Product Dimensions	2.05 x 2.05 x 4.13 inches
Item Weight	2.12 ounces
Manufacturer	SURTEK
First Available	June 23, 2015

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Surtek 130567 Yarn, please refer to the product

packaging or contact Surtek customer service directly. Contact details can typically be found on the manufacturer's official website or on the product's original purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question