

Behringer XR16

Behringer X Air XR16

TABLET-CONTROLLED DIGITAL MIXER USER MANUAL

Model: XR16

Introduction

The Behringer X Air XR16 is a 16-input digital mixer designed for live and studio applications, controllable via tablet or computer. It features 8 programmable MIDAS preamps, an integrated Wi-Fi module, and a USB stereo recorder, offering a compact yet powerful solution for audio mixing.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your XR16 digital mixer.

Setup

Unpacking and Initial Inspection

Carefully unpack your XR16 mixer and inspect it for any signs of damage during transit. Retain the original packaging for future transport or storage.

The box should contain:

- Behringer X Air XR16 Digital Mixer
- Power Cable
- Rack Ears
- Integrated Wi-Fi Module and USB Stereo Recorder (built-in)

Physical Connections

Familiarize yourself with the input and output connections on the XR16. Ensure all connections are secure before powering on the device.



Figure 1: Top view of the XR16 showing the various input and output ports, including XLR/TRS combo jacks, auxiliary outputs, main outputs, MIDI I/O, USB port, and Ethernet port.

- **Inputs 1-8 (XLR/TRS Combo Jacks):** Connect microphones or line-level instruments. These inputs feature programmable MIDAS preamps.
- **Inputs 9-16 (TRS Jacks):** Connect line-level instruments or devices. Inputs 15 and 16 are Hi-Z compatible for direct instrument connection.
- **AUX 1-4 Outputs (XLR):** Used for sending monitor mixes or effects sends to external devices.
- **MAIN L/R Outputs (XLR):** Connect to your main PA system or studio monitors.
- **PHONES Output (1/4" TRS):** For headphone monitoring with dedicated level control.
- **MIDI In/Out (5-pin DIN):** For connecting MIDI controllers or other MIDI devices.
- **USB (Type A):** For connecting a USB flash drive for stereo WAV recording and playback.
- **ETHERNET (RJ45):** For wired network connection to a computer or external router.
- **REMOTE (Wi-Fi Client/Access Point Switch):** Selects the Wi-Fi mode.



Figure 2: Angled view of the XR16, providing a clearer perspective of the rear panel connections and the Wi-Fi antenna.

Power Connection

Connect the supplied power cable to the XR16's power input and then to a suitable AC power outlet. Ensure the power switch is in the OFF position before connecting. Once all audio and network connections are made, you can switch the unit ON.

Wi-Fi and Network Setup

The XR16 features a built-in tri-mode Wi-Fi router. You can operate the mixer directly via its internal Wi-Fi or connect it to an external router for enhanced stability and range, especially in busy environments.

- **Access Point Mode:** The XR16 acts as its own Wi-Fi hotspot. Connect your tablet or computer directly to the XR16's Wi-Fi network. This is suitable for small, controlled environments.
- **Wi-Fi Client Mode:** The XR16 connects to an existing Wi-Fi network (e.g., your home router or an external dedicated router). This provides more reliable connectivity and allows multiple devices to connect to the same network.
- **Ethernet Mode:** For the most stable connection, connect the XR16 directly to a computer or an external router via an Ethernet cable.

Note: For optimal performance, particularly in live sound environments, it is highly recommended to use a high-speed, dual-band (5G) external Wi-Fi router connected via the Ethernet port. This can significantly improve connection stability and responsiveness compared to the internal Wi-Fi module.

Operating Instructions

Connecting and Controlling with the App

The XR16 is controlled wirelessly via a dedicated app available for tablets (iOS/Android) and computers

(Windows/Mac/Linux). Download the appropriate X AIR app from your device's app store or the Behringer website.

1. Ensure your tablet/computer is connected to the XR16's Wi-Fi network (or the external network the XR16 is connected to).
2. Launch the X AIR app.
3. The app should automatically detect the XR16. If not, manually select it from the list of available mixers.
4. Once connected, you will have full control over all mixer functions, including input levels, EQ, dynamics, effects, and routing.

Input Channel Management

Each of the 16 input channels can be individually adjusted within the app:

- **Gain Control:** Adjust the input sensitivity for each channel.
- **Phantom Power:** Enable +48V phantom power for condenser microphones on inputs 1-8.
- **EQ:** Utilize the 4-band parametric EQ for tone shaping.
- **Dynamics:** Apply gates and compressors to control signal dynamics.
- **Sends:** Route signals to auxiliary outputs (for monitors) or internal effects processors.
- **Mute/Solo:** Mute or solo individual channels for isolation.

Auxiliary and Main Outputs

The XR16 provides 4 auxiliary outputs and a stereo main output, all controllable from the app:

- **Aux Sends:** Create independent monitor mixes for performers or send signals to external effects units.
- **Main Mix:** Control the overall stereo output level and apply master processing.

USB Recording and Playback

The USB Type-A port allows for uncompressed stereo WAV recording and playback directly to/from a USB flash drive.

1. Insert a formatted USB flash drive into the USB port.
2. Access the USB recorder section within the X AIR app.
3. Select record or playback functions as needed.

MIDI Control

The MIDI In/Out ports enable external MIDI devices to control certain parameters of the XR16, or for the XR16 to send MIDI data. Refer to the X AIR app's MIDI implementation chart for detailed control options.

Maintenance

Cleaning

To maintain the appearance and functionality of your XR16, regularly clean the exterior with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or waxes, as these can damage the finish and internal components. Ensure the unit is powered off and disconnected from all cables before cleaning.

Storage

When not in use for extended periods, store the XR16 in a cool, dry place, away from direct sunlight, extreme temperatures, and excessive dust. It is recommended to store the unit in its original packaging or a protective case to prevent damage.

Firmware Updates

Behringer periodically releases firmware updates to improve performance, add features, or fix bugs. Check the Behringer website for the latest firmware versions and instructions on how to update your XR16. Always follow the update instructions carefully to avoid damaging the unit.

Troubleshooting

No Power

- Ensure the power cable is securely connected to both the XR16 and a working power outlet.
- Verify that the power switch on the XR16 is in the ON position.
- Check the power outlet with another device to confirm it is supplying power.

No Audio Output

- Verify that the main output levels in the X AIR app are not muted or turned down.
- Check all cable connections from the XR16's main outputs to your PA system or monitors.
- Ensure individual input channels are not muted or have their gain set too low.
- Confirm that the correct input sources are selected and active in the app.

Wi-Fi Connection Issues

- Ensure the XR16's Wi-Fi/Remote switch is set to the correct mode (Access Point or Wi-Fi Client).
- If using Access Point mode, ensure your tablet/computer is connected directly to the XR16's Wi-Fi network.
- If using Wi-Fi Client mode, ensure the XR16 is successfully connected to your external router's network, and your tablet/computer is on the same network.
- Try restarting both the XR16 and your controlling device.
- Consider using an external 5GHz Wi-Fi router connected via Ethernet for more stable performance, especially in environments with many other Wi-Fi signals.

App Not Connecting to Mixer

- Confirm your device is connected to the correct Wi-Fi network (either the XR16's internal network or the external network it's connected to).
- Ensure the X AIR app is updated to the latest version.
- Check if the XR16's firmware is up to date.
- Temporarily disable any firewalls on your controlling device that might be blocking the connection.

Specifications

Model	XR16
Brand	Behringer
Number of Channels	16
Item Weight	9.01 pounds (4.09 kg)
Product Dimensions	13.11 x 5.87 x 5.51 inches (33.3 x 14.9 x 14 cm)
Connectivity Technology	USB, Wi-Fi, Ethernet
Hardware Interface	USB


Power Source	Corded Electric
Color Name	Black

Warranty and Support

For detailed warranty information and technical support, please refer to the official Behringer website or contact their customer service. Keep your proof of purchase for warranty claims.

You can find additional resources, FAQs, and software downloads on the [Behringer official website](#).

Documents - Behringer – XR16




[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide

uick Start Guide the manual Caution To reduce risk of electric shock do not remove top cover or rear section No user serviceable parts inside Refer servicing to qualified personnel fire expose this appliance rain and moisture The apparatus shall be exposed dripping splashing XR16 XR12 QSG WW media63 music group media PLM data docs P0BI6 Quick X AIR These service instructions are for use by only perform any other than that P0BI7 manuals plus Terminals marked with symbol carry electrical current sufficient magnitude constitute Use high quality

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder V 4.0 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current ...

lang:en **score:40** filesize: 3.76 M page_count: 25 document date: 2020-02-17




[\[pdf\]](#) User Manual Instructions Warranty

BEHRINGER X AIR XR16 01 MANUAL Manual Hub drive google file d 1azvpQiYE9TpVwWSsTPYv XMRzL7v1myZ preview |||

Product Manual X AIR XR18/X18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wi Module and USB

<https://manual-hub.com/> 2 X AIR User Manual Table of Contents Important Safety Instructions 3 Legal Disclaimer ...

lang:en **score:37** filesize: 6.77 M page_count: 46 document date: 2024-01-27



[\[pdf\]](#) Quick Start Guide Instructions Guide

Quick Start Guide X AIR XR16 XR12 QSG BE 0605 AAB WW mediadl musictribe media PLM data docs P0BI6 |||

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable Midas Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder V 6.0 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current ...

lang:en **score:37** filesize: 2.66 M page_count: 48 document date: 2023-08-25




[\[pdf\]](#) User Manual

EXPE Mult Prin PH Approval P0BI7 XR16 PID 2015 01 26 Rev 1 indd jaypeeplaton The BEHRINGER X32 completely changed the game by rethinking what is possible from a digital mixer and over 100,000 users are enjoying results Now Manual Behringer X AIR Product Information Document media djmania net manuales behringer assets

Product Information Document Digital Mixers 9 *3 93 16-Input Digital Mixer for iPad/Android Tablets ... hat will forever change both the way you record and the way you play live music. The revolutionary **XR16** is a powerhouse 16 input portable/rack-mountable mixer for iPad and Android tablets, and is ide...

lang:en **score:36** filesize: 11.6 M page_count: 22 document date: 2015-02-05



[\[pdf\]](#) User Manual Instructions Warranty

Behringer X AIR XR16 User Manual EN recordcase de media 4f 22 83

Product Manual X AIR XR18/XR16/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wifi Module and USB 2 X AIR User Manual Table of Contents Important Safety Instructions..... 3 Legal Disclaimer.....

lang:en **score:35** filesize: 14.22 M page_count: 46 document date: 2019-05-15



[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide

FEEL Prod Grap PH Artwork P0BI6 QSG Prin BEH Template WW A5 2017 01 25 Rev 0 indd gil vegerano

See Behringer XR16 Manual X Air 16 Input Digital Mixer for iPad Android Tablets markertek Attachments Manuals |||

Quick Start Guide 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current of sufficient magnitude to constitute risk of electric shock. Use only high-quality professional speaker cables with TS or twist-locking plugs pre-installed. All other in...

lang:en **score:34** filesize: 3.92 M page_count: 25 document date: 2018-02-15



[\[pdf\]](#) Quick Start Guide Instructions Guide

HYPE Grap PH Artwork P0BI6 QSG WW A5 2018 01 29 Rev 1 indd kristienebaquiran Download

Behringer X AIR XR16 Quick Start Guide DE EN FR ES PT » Online kopen in de Recordcase DJ Shop recordcase media 36 75 |||

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current of suf...

lang:en **score:34** filesize: 3.77 M page_count: 25 document date: 2019-07-05



[\[pdf\]](#)

BEHRINGER XR16 P0BI7 Product Information Document behringer assets |||

Product Information Document Digital Mixers 9 *3 93 16-Input Digital Mixer for iPad/Android Tablets ... hat will forever change both the way you record and the way you play live music. The revolutionary **XR16** is a powerhouse 16 input portable/rack-mountable mixer for iPad and Android tablets, and is ide...

lang:en **score:33** filesize: 14.64 M page_count: 24 document date: 2015-06-16




[\[pdf\] User Manual Quick Start Guide Instructions Guide](#)

HYPE Grap PH Artwork P0BI6 QSG WW A5 2018 01 29 Rev 1 indd kristienebaquiran X AIR XR16 XR12

Controls Heliart Quick Start Guide control software visit the product page on behringer to full manual 20 21 XR12 Caution To reduce risk of electric shock do not remove top cover or rear section No user serviceable parts inside Refer servicing qualified personnel fire expose this appliance rain and moisture The apparatus shall be exposed dripping splashing Behringer 8849962336286 heliart ee static custom File Tooteinfo quick start mediadl musictribe media sys master h5c h59

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current of suf...

lang:en score:33 filesize: 3.82 M page_count: 25 document date: 2018-04-04



[Behringer X AIR XR16/XR12 Quick Start Guide](#)

This guide provides a quick start for setting up and using the Behringer X AIR XR16 and XR12 digital mixers, covering essential information for initial use, safety, and network connectivity.

lang:en score:32 filesize: 3.14 M page_count: 39 document date: 2021-02-10



[\[pdf\] User Manual Instructions Guide Warranty](#)

Product Manual MIDAS MR18 MR12 User Guide eviaudio fr 2020 07 |||

MR18 18-Input Digital Mixer for iPad/Android Tablets with 16 MIDAS PRO Preamps, Integrated Wifi Modu ... IEXREBRUSBESUSES PRPREE-D-DEEFFIINNEEDDAASSSSUUBGBRGORUOPUS*PS* MRXR1122::BBUUSESSE3S/43/5//46/5/6 **XR16**: BUSES 5/6 AUDIO OUTPUTS PHONES STEREO DACs LEVEL MAIN OUT L-R DACs DACs AUX SEND 1-2 4 S4TST...

lang:en score:31 filesize: 15.06 M page_count: 48 document date: 2017-05-19



[pdf]

Behringer X AIR XR16 Product Information recordcase de media 27 15 3f

Product Information Document Digital Mixers X AIR **XR16** 16-Input Digital Mixer for iPad/Android Tablets with 8 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder ## iPad*/Android* tablet controlled 16-input digital mixer for studio and live application ## 8 awa...

lang:en **score:31** filesize: 12.76 M page_count: 27 document date: 2019-06-13



[pdf] Quick Start Guide Instructions Guide

HYPE Grap PH Artwork P0BI6 QSG WW A5 2018 01 29 Rev 1 indd kristienebaquiran Quick Start Guide

Recordcase de X AIR XR16 XR12 16 12 Input Digital Mixer for iPad Android Tablets with 8 4

Programmable MIDAS Preamps Line Inputs Integrated Wifi Module and USB Stereo Recorder Behringer DE EN FR ES PT recordcase media 93 fc 96

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry electrical current of suf...

lang:en **score:31** filesize: 3.77 M page_count: 25 document date: 2019-08-05



[pdf] Datasheet

Behringer XR16 P0BI7 Product Information Document Data Sheet 16 input Digital Mixer for iPad and Android Tablets Truth Seeker Productions GearTechs behringer xr16 cdn shopify s files 1 0290 4132

8221 t 5 assets |||

Product Information Document Digital Mixers 9 *3 93 16-Input Digital Mixer for iPad/Android Tablets ... hat will forever change both the way you record and the way you play live music. The revolutionary **XR16** is a powerhouse 16 input portable/rack-mountable mixer for iPad and Android tablets, and is ide...

lang:en **score:30** filesize: 2.09 M page_count: 24 document date: 2016-01-16




[\[pdf\]](#) User Manual Instructions Warranty

BEHRINGER X AIR XR18 01 MANUAL Manual Hub drive google file d

1IHtiKm3eslQoNIXYtBnemmhMNjt0mYz preview |||

Product Manual X AIR XR18/XR18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wi Module and USB
<https://manual-hub.com/> 2 X AIR User Manual Table of Contents Important Safety Instructions 3 Legal Disclaimer ...

lang:en **score:30** filesize: 6.77 M page_count: 46 document date: 2024-01-27




[\[pdf\]](#) User Manual Instructions Warranty

BEHRINGER X AIR XR18 01 MANUAL Manual Hub drive google file d 14V3Ggz4KjTobnOV3TTqZY

LicRMngS4P preview |||

Product Manual X AIR XR18/XR18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wi Module and USB
<https://manual-hub.com/> 2 X AIR User Manual Table of Contents Important Safety Instructions 3 Legal Disclaimer ...

lang:en **score:30** filesize: 6.77 M page_count: 46 document date: 2024-01-27




[\[pdf\]](#) User Manual Instructions Warranty

BEHRINGER X AIR XR12 01 MANUAL Manual Hub drive google file d 1yeAahfKDQvnBy6bL

iNBkv6kQe65Y9t preview |||

Product Manual X AIR XR18/XR18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wi Module and USB
<https://manual-hub.com/> 2 X AIR User Manual Table of Contents Important Safety Instructions 3 Legal Disclaimer ...

lang:en **score:30** filesize: 6.77 M page_count: 46 document date: 2024-01-27




[\[pdf\]](#) Quick Start Guide Instructions Guide

FACE-GRAP-PH1_QSG_BE_P0BI6_XR16-XR12_A5_WW_2021-04-07_Rev 5 indd uick Start Guide m media-amazon Quick< b> Start< Guide< 3 are subject to change without notice All trademarks the property of their respective owners Midas 2021< Reservados todos los derechos Si quiere conocer detalles y condiciones aplicables de la garantía así como información adicional sobre B1w9G0ZLdMS images I Quick 2021

Quick Start Guide X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable Midas Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder V 5.0 A54-00002-87595 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this symbol carry elec...

lang:en **score:29** filesize: 2.48 M page_count: 76 document date: 2021-04-07




[\[pdf\]](#) User Manual Owner's Manual Quick Start Guide Instructions Guide

937XR12 BEHRINGER XR12 CRUTCHFIELD COM JOSH N X AIR XR16 AdoramaThe XR18 uses XLR connectors while the X18 balanced 1/4 jacks 16 Inputs 17 and 18 only accept cables for connecting line level BEXR12adorama col productManuals BEXR12 Behringer Air owner s manualX AdoramaBehringer channel remote controlled digital mixer with Wi Fi® at CrutchfieldThe level v1crutchfieldonline ImageBank v20160515095300 Manuals 937 937XR12adorama |||

Quick Start Guide Visit behringer.com for Full Manual X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder 2 X AIR **XR16**/XR12 Important Safety Instructions Terminals marked with this ...

lang:en **score:28** filesize: 15.99 M page_count: 71 document date: 2016-05-15




[\[pdf\]](#) User Manual Owner's Manual Quick Start Guide Instructions Guide

937XR18 Behringer XR18 CRUTCHFIELD COM JOSH N X Air owner s manual 18 channel remote controlled digital mixer with Wi Fi® at Crutchfield crutchfieldonline ImageBank v20161226120900 Manuals 937 |||

Quick Start Guide Visit behringer.com for Full Manual X AIR X18/XR18 18-Channel, 12-Bus Digital Mi ... visions of Directive 1999/5/EC. Quick Start Guide 47 We Hear You Product Manual X AIR XR18/X18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated ...

lang:en **score:28** filesize: 31.59 M page_count: 97 document date: 2016-12-26



[pdf] User Manual Instructions Warranty

Behringer X AIR XR12 User Manual EN recordcase de media d3 57 4a

Product Manual X AIR XR18/X18**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wifi Module and USB 2 X AIR User Manual Table of Contents Important Safety

Instructions..... 3 Legal Disclaimer.....

lang:en score:28 filesize: 14.22 M page_count: 46 document date: 2019-05-22



[pdf] Datasheet Declaration of Conformity

BEHRINGER X Air XR16 B Stock Strumenti Musicali Produttore Behringer Cod Art 85639 MIXER

DIGITALE XAIR WIFI 16 CANALI 8 PREAMP MIDAS PROGRAMMABILI USB PER IPAD ANDROID doc
strumentimusicali net datasheet products id |||

Mixer Mixer Digitali a Rack BEHRINGER X Air **XR16** B-Stock mercoled 06 agosto, 2025 Produttore : Behringer Cod.Art. : 85639 MIXER DIGITALE XAIR WIFI 16

CANALI, 8 PREAMP MIDAS PROGRAMMABILI, USB PER IPAD/ANDROID li.n II

Behringer X32 ha cambiato completamente il gioco ripensando ci che possibile f...

lang:it score:27 filesize: 20.39 K page_count: 2 document date: 2025-08-06



[pdf] Specifications

X AIR XR16 Audio y video shop TECSA 8 mar 2021 — The revolutionary is a powerhouse 16 input

portable rack mountable mixer for iPad and Android tablets ideally suited both live Specifications

markertek Attachments Behringer |||

Product Information Document Digital Mixers X AIR**XR16** 16-Input Digital Mixer for iPad/Android Tablets with 8 Programmable MIDAS Preamps, 8 Line Inputs, Integrated


Wifi Module and USB Stereo Recorder ## iPad*/Android* tablet controlled 16-input digital mixer for studio and live application ## 8 awa...

lang:en score:27 filesize: 12.79 M page_count: 27 document date: 2017-03-27




[pdf]

EXPE Mult Prin PH Approval P0BI7 XR16 PID 2015 01 26 Rev 1 indd jaypeeplaton X AIR Pult ru If your application requires a computer for BEHRINGER mixer remote control the EDIT was made just you Simply copy and launch free software 06e0d9eec2596222921431c5cb4def35 pult upload iblock 06e Product Information Document Digital Mixers 9 *3 93 16-Input Digital Mixer for iPad/Android Tablets ... hat will forever change both the way you record and the way you play live music. The revolutionary **XR16** is a powerhouse 16 input portable/rack-mountable mixer for iPad and Android tablets, and is ide...
lang:en score:26 filesize: 11.6 M page_count: 22 document date: 2015-04-15




[pdf]

Microsoft Word BEHRINGER X AIR XR12 6 lorenzo XR16 Lucky Music I terminali contrassegnati da questo simbolo portano corrente elettrica di ampiezza sufficiente costituire il rischio scosse elettriche XAIR 12 luckymusic img cms |||
BEHRINGER X AIR XR12 / XR16 Per le immagini fare riferimento alla guida in inglese:
https://mediadl.musictribe.com/media/sys_master/hc9/h8a/8849618108446.pdf I terminali contrassegnati da questo simbolo portano corrente elettrica di ampiezza sufficiente costituire il rischio di scosse elettriche. Ut...
lang:it score:24 filesize: 284.06 K page_count: 19 document date: 2021-05-18



[pdf] User Manual Instructions Warranty


Untitled Product Manual Adorama B215D active loudspeakers MP3 Player BUGERA V22 XM8500 HPS3000 Keyboard TRS product page on behringer for details You can however choose to BEXR16 adorama col productManuals |||
Product Manual X AIR XR18/XR16/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wi Module and USB 2 X AIR User Manual Table of Contents Important Safety Instructions
3 Legal Disclaimer
lang:en score:24 filesize: 6.16 M page_count: 46 document date: 2022-12-09



[\[pdf\]](#) Quick Start Guide Warranty


XR16 XR12 QSG CN Index of media PLM data docs P0BI7 media63 music group |||

X AIR **XR16**/XR12 16/12-Input Digital Mixer for iPad/Android Tablets with 8/4 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder V 4.0 2 X AIR **XR16**/XR12 , TS , , , , , , , 1. 2. 3. 4. 5. 6. 7. 8. , , ...
lang:en score:24 filesize: 2.07 M page_count: 11 document date: 2020-02-12




[Behringer X AIR XR16/XR12 Digital Mixer Quick Start Guide](#)

A quick start guide for the Behringer X AIR XR16/XR12 digital mixer, detailing its features, connectivity, and basic operation. This guide covers setup, network connections, and control options for iPad/Android tablets and computers.
lang:en score:23 filesize: 1.78 M page_count: 11 document date: 2023-08-23



[\[pdf\]](#) User Manual Quick Start Guide Guide


X AIR XR16 XR12 BEHRINGER Controls Cyc Electronica cloudfront net Parts Express Please read the manual Caution To reduce risk of electric shock do not remove top cover or rear section Quick Start Guide Visit behringer for Full Manual 16 12 Input Digital Mixer iPad Android Tablets with 8 4 Programmable MIDAS Preamps Line Inputs Integrated Wifi Module and USB Stereo Recorder No user serviceable parts inside Refer servicing to qualifi ed personnel fi re expose this appliance rain moisture The apparatus shall be exposed QSG WW 208356 248 6878 xr16 air input rack mount digital ipad tablet mixer quick start guide 361342 multi 208368 media music group PLM data docs P0BI7 d1aeri3ty3izns 20 express pedocs manuals images static thomann de pics atg atgdata document im 80 P0BI6
...
lang:en score:22 filesize: 2.92 M page_count: 25 document date: 2015-03-10



[\[pdf\]](#) User Manual

Manual de uso X AIR 45 pages M BE 0605 AAA ES mediadl musictribe media PLM data docs |||
Manual de uso X AIR XR18/X18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wifi Module and USB V 1.0
2 X AIR Manual de uso indice Instrucciones de seguridad.....
3 Negacin Legal.....


lang:es **score:21** filesize: 20.14 M page_count: 45 document date: 2023-03-27



[\[pdf\]](#) User Manual

Manual de Instruções X AIR IIS Windows Server 2023 03 28 — Behringer Bugera Aston Microphones e
Coolaudio são marcas ou registradas do Music Tribe Global Brands Ltd © 2022 45 puslapiai M BE 0605
AAA PT mediadl musictribe media PLM data docs |||
Manual de Instrues X AIR XR18/X18/**XR16**/XR12 Digital Mixer Series for iPad/Android Tablets with Programmable MIDAS Preamps, Integrated Wifi Module and USB V 1.0
2 X AIR Manual de Instrues ndice Instrues de Segurana Importantes.....
3 Legal Renunciante.....


lang:pt **score:21** filesize: 20.25 M page_count: 45 document date: 2022-05-30



[\[pdf\]](#) Release Notes

X AIR EDIT V1 5 Releasenotes music group 80 software behringer XAIR
X AIR EDIT for PC/Mac/Linux/Rpi Version 1.5 - 30 January 2017 BEHRINGER X AIR
EDIT Application for X AIR Digital Mixer Series BEHRINGER s X AIR EDIT version
1.5 software app provides full control over all mixing, processing and effects functions
of X AIR X18, XR18, **XR16** and XR12 digital mixers rig...

lang:en **score:21** filesize: 209.12 K page_count: 3 document date: 2017-01-30



[pdf]

Behringer sound 16 03 2016 invask ru filesertif BEHRINGER

TAMO ITEHHbIR COIO3 AEKIAPAIIAfi O CO OTBET CT BVrVr Saqnureru, O6ulecro c rll,rqo, KoHrpaKr lb 1 ... T-TP X32 CORE, X32 PRODUCER, X32 PRODUCER-TP, X32 RACK, X32-TP, XD3OO, XL1600, XI24OO,XL32OO, XR12, **XR16**, XR18, XR2OOO, XR44OO, zux8210 t e 3aseilrens Cxorvropox CeernaHa Bna4nuupoeHa uH 4quanbt, S...


lang:es **score:20** filesize: 227.69 K page_count: 3 document date: 2015-03-17



[pdf] Release Notes

PowerPoint Presentation jan duwe@behringer BRAN CATE BE02 MX Mix v1 5 release notes mediadl musictribe software MIX |||

Application Software Release Version for Android and iOS tablets MX-Mix V1.5 Remote and offline edi ... MX-Mix app allows control of Behringer and Midas digital mixers. Compatible with: Behringer XR12, **XR16**, X18, XR18, XR12W, **XR16W**, XR18V2, X32, X32 Compact, X32 Rack, X32 Producer Midas MR12, MR18, M... lang:en **score:20** filesize: 213.28 K page_count: 4 document date: 2024-04-08




[pdf]

X AIR mixer firmware Version 1 17 24 April 2018 musictri be behringer © MUSIC Group IP Ltd All rights reserved information in this document is subject to change without any further notice mediadl musictribe software XAIR music group 80

X AIR mixer firmware Version 1.17 - 24 April 2018 X AIR Mixer Firmware V 1.17 for BEHRINGER X AIR ... updating your X AIR mixer s firmware. Download and unpack the X18/XR18 firmware update file or the **XR16** firmware update file, if you have an XR12/**XR16** from behringer.com, and connect your PC with yo...

lang:en **score:20** filesize: 328.71 K page_count: 1 document date: 2018-04-23




[pdf] User Manual Quick Start Guide Guide

behringerXR12manual Accounts 01234 67897 12 2 27 92 9 3 1 8 18 Warehouse Sound XR12 AUX SEND ETHERNET Hi Z XR16 CH 15 16 11 X AIR Network Connection on behringer to the warehousesound r

0123467897 12 227 92 9391818 # 3 74 / 99*8 7 ,98177-2288278 1 2.- 0896/999 2/688:6, 07 593 962;2 31 89,1 7795227 8 X AIR **XR16**/XR12 X AIR **XR16**/XR12 Hook-up EN Step 1: Hook-Up ES Paso 1: Conexin FR tape 1 : Connexions DE Schritt 1: Verkabelung PT Passo 1: Conexes Laptop ...

lang:en **score:20** filesize: 2.49 M page_count: 8 document date: 2017-08-20




[pdf]

EXPE Mult Prin PH X AIR Android app V1 1 2015 01 21 Rev 2 indd tinedimaculangan 0 3 behringer de 80
XAIR |||

X AIR Android app for X AIR Digital Mixer Series Version 1.0 21 January 2015 X AIR allows you to c ... roid tablet or smartphone. X AIR version 1.0 delivers comprehensive control features for X18, XR18, **XR16**, and XR12 mixers. The user interface is providing either a simplified access or expert level ed...

lang:en score:20 filesize: 404.24 K page_count: 1 document date: 2015-01-21



[pdf] Quick Start Guide Instructions Guide


Quick Start Guide MR12 QSG MI 0605 AAE WW mediadl musictribe media PLM data docs P0C8G |||
Quick Start Guide MR12 12-Input Digital Mixer for iPad/Android Tablets with 4 Midax PRO Preamps, 8 L ... IEXREBRUSBESUSES PRPREE-D-
DEEFFIINNEEDDAASSSSUUBGBRGORUOPUS*PS* MRXR1122::
BBUUSESSSE3S/43/5//46/5/6 **XR16**: BUSES 5/6 AUDIO OUTPUTS PHONES
STEREO DACs LEVEL MAIN OUT L-R DACs DACs AUX SEND 1-2 4 S4TST...
lang:en score:19 filesize: 2.27 M page_count: 29 document date: 2023-08-14



[MIDAS MR18 & MR12 M AIR Series Digital Mixer Product Manual](#)

Explore the comprehensive user manual for the MIDAS MR18 and MR12 M AIR series digital mixers. Learn about their features, setup, operation, and software control for live sound and recording applications.

lang:en score:19 filesize: 14.54 M page_count: 48 document date: 2017-05-19




[pdf]

FEEL Prod Grap PH Artwork X TOUCH Firmware Ver 1 15 2016 02 19 Rev 4 indd catheryn hagonoy

BEHRINGER music group 80 software ReleaseNotes

X-TOUCH Firmware V 1.15 - January 2016 Behringer X-TOUCH Universal Control Surface Firmware V 1.15 ... TOUCH firmware version 1.15, the X-TOUCH is able to remotely control the X AIR series mixers: XR12, **XR16**, X18, and XR18. The connection between the X-TOUCH and the mixer can be made via Ethernet conne... lang:en score:19 filesize: 639.02 K page_count: 15 document date: 2016-02-19




[pdf]

EXPE Mult Prin PH Artwork X32 Edit for PC Public Beta Ver 0 5 2015 02 18 Rev 1 indd tine

dimaculangan X AIR V0 5beta music group 80 software behringer XAIR

X AIR EDIT for PC public beta Version 0.5 - 18th February 2015 BEHRINGER X AIR EDIT Application for X AIR Digital Mixer Series BEHRINGER s X AIR version 1.0 software app provides unprecedented control over all mixing, processing and effects functions of X AIR X18, XR18, **XR16** and XR12 digital mix...

lang:en score:19 filesize: 37.26 K page_count: 2 document date: 2015-02-18



[pdf]

EXPE Mult Prin PH Artwork X32 Edit Public Beta Ver 0 5 1 2015 02 26 Rev indd tine dimaculangan X AIR

EDIT beta music group 80 software behringer XAIR

X AIR EDIT for PC/Mac/Linux public beta Version 0.5.1 - 26th February 2015 BEHRINGER X AIR EDIT Application for X AIR Digital Mixer Series BEHRINGER s X AIR EDIT version 0.5.1 beta software app provides unprecedented control over all mixing, processing and effects functions of X AIR X18, XR18, X...

lang:en score:19 filesize: 38.1 K page_count: 2 document date: 2015-02-26



[pdf] User Manual Documentation

FEEL Prod Grap PH Artwork X TOUCH Firmware Ver 1 15 2016 02 19 Rev 4 indd catheryn hagonoy
music group 3 behringer Direct MIDI Connection Between AIR Mixer and Control Surface Steps
Preparation a Make sure your is switched on b Connect any remote control application with as usual
DHCP OFF requires manual setup of my IP address only choose if you have preferred valid for in network
c Use the CH03 encoder to specify an mixer wish select Slv d Enter modify slave by turning CH04 CH07
encoders Documentation mediadl musictribe software

Behringer X-TOUCH Universal Control Surface MIDI Documentation Music Tribe
Global Brands Ltd. All ... X-TOUCH rmware version 1.15, the X-TOUCH is able to
remotely control the X AIR series mixers: XR12, **XR16**, X18, and XR18. The
connection between the X-TOUCH and the mixer can be made via Ethernet conne...
lang:en score:19 filesize: 350.02 K page_count: 15 document date: 2016-02-19



[pdf] Recall

EXPE Mult Prin PH Artwork X AIR Mixer Series XR12 XR16 2015 06 30 Rev 2 indd tine dimaculangan
MIDI Implementation behringer assets

X AIR Mixer Series MIDI Implementation **XR16**/XR12 30 June 2015 MIDI RX/TX
Snapshot Snapshots Channel 1 Fader CH Faders 1 CH Faders 1 CH Faders 1 Send
Faders 1 Send Faders 1 Main Fader 1 DCA Fader 1 Mute CH Mutes 2 CH Mutes 2
CH Mutes 2 Send Mutes 2 Send Mutes 2 Main M...
lang:en score:18 filesize: 32.9 K page_count: 1 document date: 2015-06-30



[pdf] Recall

EXPE Mult Prin PH Artwork X AIR Mixer Series XR12 XR16 2015 06 30 Rev 2 indd tine dimaculangan
MIDI Implementation behringer assets |||

X AIR Mixer Series MIDI Implementation **XR16**/XR12 30 June 2015 MIDI RX/TX
Snapshot Snapshots Channel 1 Fader CH Faders 1 CH Faders 1 CH Faders 1 Send
Faders 1 Send Faders 1 Main Fader 1 DCA Fader 1 Mute CH Mutes 2 CH Mutes 2
CH Mutes 2 Send Mutes 2 Send Mutes 2 Main M...
lang:en score:18 filesize: 32.77 K page_count: 1 document date: 2015-07-24

Digital Mixers

X AIR
XR16

16-Input Digital Mixer for
iPad/Android Tablets with 8 Programmable
MIDAS Preamps, 8 Line Inputs, Integrated WiFi
Module and USB Stereo Recorder



- iPad/Android* tablet controlled 16-input digital mixer for studio and live application
- Award-winning MIDAS-designed, fully programmable mic preamps for ultimate sound quality
- Built-in 10-Mbps Wi-Fi module for direct operation – no need for external routers
- Revolutionary "finger" app: easy sharing automatically manages mix between your devices
- USB connection for uncompressed stereo WAV recording and playback
- Award-winning 128-effects rack featuring 64-bit/192 kHz sampling high-end simulators such as vintage REAR and PARRY Distortion and Quattro DPO etc.
- 100-band real-time analyzer (RTA) for all channel and bus EQs
- Rack ears and protective bumpers included for flexible rack and stage applications
- 6 aux buses and main L/R with stereo, full dynamics processing, auto level parameters or 15-band graphic EQ
- 4 XLR aux outputs and 2 XLR main outputs plus stereo connector
- 40-bit floating-point DSP keeps "vintage" sounding range with no internal overload and near-zero thermal latency

The BEHRINGER X32 completely changed the game by redefining what is possible from a digital mixer – and over 100,000 users are enjoying the results. Now, that same incredible technology has been incorporated into a small, but incredibly powerful, rack-mountable mixer that will forever change both the way you record – and the way you play live music.



The revolutionary XR16 is a powerhouse 16-input portable/rack-mountable mixer for iPad and Android tablets, and is ideally suited for both live and studio applications. Thanks to its award-winning MIDAS-designed mic preamps, convenient integrated WiFi module for wireless control, plus USB connectivity for file storage, system updates and uncompressed stereo recordings via the USB Stereo Recorder. We've also included the rack ears and protective bumpers for added flexibility in your studio and stage applications.

The freedom to move around and manipulate all parameters of your mix with the free iOS and PC apps lets you dial in the perfect sound from anywhere in the venue – or the tracking room! Advanced engineering and meticulous design deliver stellar sonic performance at an extremely affordable price – changing the game once again.



[pdf]

Untitled muztorgservis by 7ee98146853900c952ebc6964cfb653e upload iblock 7ee |||

Product Information Document Digital Mixers X AIR**XR16** 16-Input Digital Mixer for iPad/Android Tablets with 8 Programmable MIDAS Preamps, 8 Line Inputs, Integrated Wifi Module and USB Stereo Recorder ## iPad*/Android* tablet controlled 16-input digital mixer for studio and live application ## 8 awa...

lang:en **score:18** filesize: 7.4 M page_count: 27 document date: 2021-06-28