

iLive Electronics ITB295B

iLive ITB295B 37-Inch Wireless Bluetooth Sound Bar User Manual

Model: ITB295B

1. INTRODUCTION

Thank you for purchasing the iLive ITB295B 37-Inch Wireless Bluetooth Sound Bar. This manual provides essential information for setting up, operating, and maintaining your new sound bar. Please read it thoroughly before use and retain it for future reference.

Package Contents

- iLive ITB295B 37-Inch Wireless Bluetooth Sound Bar
- Remote Control (requires 2 AAA batteries, included)
- AC/DC Power Adapter
- Removable Stand (for tower configuration)
- Wall Mount Hardware
- Optical Audio Cable
- User Manual

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the unit to rain or moisture.
- Do not block ventilation openings.
- Ensure proper power supply as indicated on the AC/DC adapter.
- Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. FEATURES

- Bluetooth wireless connectivity with a range of up to 60 feet.
- 2-channel stereo sound with built-in speakers.
- Multiple input options: Optical, RCA, and 3.5mm auxiliary.
- Subwoofer output for enhanced bass (subwoofer sold separately).
- LED pairing, source, and power indicators.
- Digital volume control.
- Includes a remote control for convenient operation.
- Versatile placement options: wall-mountable or free-standing with removable tower stand.

4. CONTROLS AND INDICATORS

Familiarize yourself with the sound bar's controls and indicators for optimal use.



Figure 1: Front view of the iLive ITB295B Sound Bar, showcasing its sleek black design and cloth speaker grill.

Sound Bar Controls (typically on the side or rear)

- **Power Button:** Turns the sound bar on or off.
- **Source Button:** Cycles through input sources (Bluetooth, Optical, RCA, AUX).
- **Volume Up/Down Buttons:** Adjusts the master volume level.
- **Bluetooth Pairing Button:** Initiates Bluetooth pairing mode.

LED Indicators

- **Power Indicator:** Illuminates when the unit is powered on.
- **Source Indicators:** Lights up to show the currently selected input source (e.g., Blue for Bluetooth, Green for Optical).
- **Bluetooth Pairing Indicator:** Flashes during pairing mode, solid when connected.

Rear Panel Connections

- **DC IN:** Connects to the AC/DC power adapter.
- **OPTICAL IN:** For connecting to a TV or other device via optical cable.
- **RCA IN (L/R):** For connecting to audio devices via RCA cables.
- **AUX IN (3.5mm):** For connecting to audio devices via a 3.5mm audio cable.
- **SUBWOOFER OUT:** For connecting an external powered subwoofer.

5. SETUP

5.1 Power Connection

1. Connect the AC/DC power adapter to the DC IN port on the sound bar.
2. Plug the power adapter into a standard wall outlet.

5.2 Mounting Options

The sound bar offers flexible placement options: wall-mounted or as a tower speaker using the included stand.



Figure 2: The iLive ITB295B Sound Bar shown in both horizontal (sound bar) and vertical (tower) configurations with its removable stand.

Wall Mounting

1. Determine the desired location on the wall, ensuring it is sturdy and can support the sound bar's weight.
2. Use the included wall mount hardware and template (if provided) to mark and drill pilot holes.
3. Secure the mounting brackets to the wall.
4. Carefully attach the sound bar to the mounted brackets.

Tower Configuration (with Removable Stand)

1. Attach the removable stand base to the sound bar according to the instructions provided with the stand.
2. Ensure the stand is securely fastened and the sound bar is stable before placing it on a flat surface.

5.3 Audio Connections

Choose the appropriate connection method for your audio source.

Optical Connection (Recommended for TVs)

1. Connect one end of the included optical cable to the OPTICAL OUT port on your TV or audio source.
2. Connect the other end of the optical cable to the OPTICAL IN port on the sound bar.
3. On your TV's audio settings, ensure the audio output is set to 'Optical' or 'PCM'.

RCA Connection

1. Connect an RCA audio cable (not included) to the AUDIO OUT (L/R) ports on your TV or audio source.
2. Connect the other end of the RCA cable to the RCA IN (L/R) ports on the sound bar.

AUX (3.5mm) Connection

1. Connect a 3.5mm audio cable (not included) to the headphone jack or AUX OUT port on your audio source.
2. Connect the other end of the 3.5mm cable to the AUX IN port on the sound bar.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **Power** button on the sound bar or the remote control to turn the unit on or off.

6.2 Source Selection

Press the **Source** button on the sound bar or the remote control repeatedly to cycle through the available input sources: Bluetooth, Optical, RCA, and AUX. The corresponding LED indicator will illuminate.

6.3 Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the sound bar or the remote control to adjust the audio output level.

6.4 Bluetooth Pairing

1. Turn on the sound bar and select the Bluetooth source. The Bluetooth indicator LED will flash, indicating it is in pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for available devices and select "ITB295B" (or similar) from the list.
4. Once connected, the Bluetooth indicator LED will become solid, and you can begin streaming audio.

6.5 Equalizer Settings (via Remote Control)

The remote control allows you to select pre-set equalizer modes to optimize audio for different content types:

- **Movie Mode:** Enhances audio for cinematic experiences.
- **Music Mode:** Optimizes sound for music playback.
- **Dialog Mode:** Clarifies spoken words, ideal for news or talk shows.

Refer to your remote control's specific buttons for these functions.

7. MAINTENANCE

Cleaning

- Unplug the sound bar from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, abrasive cleaners, or solvents.
- Keep the speaker grill free of dust and debris.

8. TROUBLESHOOTING

If you encounter issues with your sound bar, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power adapter is securely connected to both the sound bar and a working power outlet.
No sound	Check that the correct input source is selected on the sound bar. Increase the volume on both the sound bar and the connected audio source. Verify that audio cables are securely connected. If using Optical, ensure your TV's audio output is set to PCM.
Bluetooth not connecting	Ensure the sound bar is in Bluetooth pairing mode (flashing LED). Make sure Bluetooth is enabled on your device and it is within 60 feet of the sound bar. Forget the device from your Bluetooth list and try pairing again. Turn off and on both the sound bar and your Bluetooth device.
Sound distortion or static	Reduce the volume level. Check for interference from other electronic devices. Ensure audio cables are not damaged and are properly connected.
Remote control not working	Replace the batteries (2 AAA). Ensure there are no obstructions between the remote and the sound bar's sensor.

9. SPECIFICATIONS




Figure 3: Dimensions of the iLive ITB295B Sound Bar, measuring approximately 37.08 inches in width, 3.35 inches in depth, and 3.39

inches in height.

Feature	Detail
Model Number	ITB295B
Speaker Type	Sound Bar
Connectivity Technology	Bluetooth, Optical, RCA, 3.5mm AUX
Bluetooth Range	Up to 60 feet (18 meters)
Audio Output Mode	Stereo (2.0 Channel)
Speaker Maximum Output Power	25 Watts
Product Dimensions (L x D x H)	37.08" x 3.35" x 3.39" (94.18 cm x 8.51 cm x 8.61 cm)
Item Weight	5.06 pounds (2.3 kg)
Power Source	Corded Electric (AC/DC Adapter)
Remote Control Batteries	2 x AAA (included)
Mounting Type	Wall Mount, Removable Stand
Color	Black

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official iLive Electronics website. Do not attempt to repair this unit yourself, as it may void your warranty. For further assistance, you may contact iLive Electronics customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question