

JBL FBA_JBLFLIP3BLK

JBL FLIP3 Bluetooth Speaker User Manual

Model: FBA_JBLFLIP3BLK

1. INTRODUCTION

Thank you for purchasing the JBL FLIP3 Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The JBL FLIP3 is a full-featured portable Bluetooth speaker that delivers surprisingly powerful, room-filling stereo sound everywhere. This ultra-compact speaker is powered by a 3000mAh rechargeable Li-ion battery, offering 10 hours of continuous playtime. Featuring a durable, splashproof fabric material, the FLIP3 is the all-purpose, all-weather companion that takes the party everywhere.

2. SAFETY INFORMATION

Please read these safety instructions carefully before using your JBL FLIP3 speaker. Keep this manual for future reference.

- Do not expose the speaker to dripping or splashing. Do not place objects filled with liquids, such as vases, on the speaker.
- Do not expose the speaker to excessive heat such as direct sunlight, fire, or similar.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- The speaker is splashproof, meaning it can withstand splashes and light rain. Do not submerge the speaker in water.

3. WHAT'S IN THE BOX

- 1 x JBL FLIP3 Flip Bluetooth Speaker Black

4. PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your JBL FLIP3 speaker.





Figure 4.1: Front view of the JBL FLIP3 Bluetooth Speaker. The speaker features a cylindrical design with a textured fabric grille and a red JBL logo.

Controls and Ports:

- **Power Button:** Press to turn the speaker on/off.
- **Bluetooth Button:** Press to enter Bluetooth pairing mode.
- **Volume Down Button:** Decreases the volume.
- **Volume Up Button:** Increases the volume.
- **Play/Pause/Speakerphone Button:** Controls music playback and answers/ends calls.
- **JBL Connect Button:** Connects to other JBL Connect enabled speakers.
- **Micro USB Port:** For charging the speaker.
- **Aux-in Port:** For wired audio connection (3.5mm cable, not included).

5. SETUP

5.1 Charging the Battery

Before first use, fully charge the speaker's battery. The JBL FLIP3 is powered by a built-in rechargeable Li-ion battery.

1. Connect the Micro USB cable to the Micro USB port on the speaker.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator lights will show the charging status. When fully charged, all LEDs will be lit.

A full charge takes approximately 3 hours. The speaker provides up to 10 hours of continuous playtime, depending on volume level and audio content.



Figure 5.1: Visual representation of the JBL FLIP3's 10-hour playtime capability.

5.2 Power On/Off

- To turn on the speaker, press the Power button. You will hear an audible tone.
- To turn off the speaker, press the Power button again.

6. OPERATING

6.1 Bluetooth Pairing

The JBL FLIP3 can wirelessly connect to up to three smartphones or tablets simultaneously.

1. Turn on the JBL FLIP3 speaker.
2. Press the Bluetooth button on the speaker. The Bluetooth LED will flash blue, indicating it's in pairing mode.
3. On your smartphone or tablet, go to the Bluetooth settings and select "JBL FLIP3" from the list of available devices.
4. Once connected, the Bluetooth LED will glow solid blue, and you will hear a confirmation tone.

The speaker will automatically reconnect to the last paired device when in range. If the last device is not found, it will enter pairing mode.

VOICE ASSISTANT & Speakerphone



BLUETOOTH

Figure 6.1: The JBL FLIP3 supports Bluetooth connectivity for wireless audio streaming and integrates with voice assistants.

6.2 Speakerphone Function

The JBL FLIP3 features a built-in noise and echo-cancelling speakerphone for crystal clear calls.

- **To answer a call:** Press the Play/Pause/Speakerphone button once.
- **To end a call:** Press the Play/Pause/Speakerphone button once during a call.
- **To reject a call:** Press and hold the Play/Pause/Speakerphone button for 2 seconds.

6.3 JBL Connect

Wirelessly link multiple JBL Connect enabled speakers together to amplify the listening experience.

1. Ensure both JBL Connect enabled speakers are powered on.
2. Press the JBL Connect button on the first speaker.
3. Press the JBL Connect button on the second speaker.
4. The speakers will connect automatically, and you will hear a confirmation tone.

Once connected, audio played through one speaker will be synchronized across all connected speakers.



Figure 6.2: The JBL Connect feature allows pairing two JBL speakers for a stereo sound experience.

6.4 Wired Connection (Aux-in)

You can connect an audio device directly to the JBL FLIP3 using a 3.5mm audio cable (not included).

1. Connect one end of the 3.5mm audio cable to the Aux-in port on the speaker.
2. Connect the other end to the headphone jack or audio output of your device.
3. The speaker will automatically switch to Aux-in mode when a cable is detected.

7. MAINTENANCE

7.1 Cleaning

To keep your JBL FLIP3 speaker in optimal condition:

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- The speaker is splashproof and can be cleaned with running tap water. Ensure the charging port cover is securely closed before rinsing.



SPLASH PROOF

Figure 7.1: The JBL FLIP3 is designed to be splashproof, making it suitable for outdoor use and easy to clean.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the speaker using the provided USB cable.
No sound	Volume is too low or muted. Device not paired.	Increase volume on speaker and source device. Ensure Bluetooth is connected or Aux cable is properly inserted.
Bluetooth connection unstable	Device is out of range. Interference.	Move device closer to the speaker (within 10 meters). Avoid obstacles between speaker and device. Try re-pairing.

Problem	Possible Cause	Solution
Cannot connect to another JBL Connect speaker	Speakers are not in pairing mode or too far apart.	Ensure both speakers are powered on and the JBL Connect button is pressed on both. Move speakers closer.

9. SPECIFICATIONS

Model Name	FBA_JBLFLIP3BLK
Output Power	16 Watts
Frequency Response	20 KHz
Signal-to-Noise Ratio	>80 dB
Battery Type	Lithium-ion Polymer (3.7V, 3000mAh)
Battery Charge Time	3 Hours
Music Play Time	10 Hours
Dimensions (H x W x D)	6.3"H x 2.6"W x 2.6"D
Weight	450 Grams (15.9 ounces)
Impedance	4 Ohm
Bluetooth Range	10 Meters
Audio Driver Size	40 Millimeters
Connectivity Technology	Bluetooth
Audio Output Mode	Bluetooth
Water Resistance	Splashproof (Is Waterproof: False)

Note: Specifications are subject to change without notice.

10. WARRANTY AND SUPPORT

JBL products are designed to provide years of trouble-free operation. In the unlikely event that your JBL FLIP3 requires service, please refer to the warranty information provided with your product or visit the official JBL support website.

- **Warranty Type:** Limited Warranty.
- For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the [JBL Support Website](#).
- For technical support or customer service, please contact JBL customer support through their official channels.

© 2024 JBL. All rights reserved.

JBL is a trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries.