

## China YLQ-3188

# Moto Fashion Electrica YLQ-3188 Rechargeable Battery Motorcycle User Manual

Model: YLQ-3188 | Brand: China

## INTRODUCTION

Thank you for purchasing the Moto Fashion Electrica YLQ-3188 Rechargeable Battery Motorcycle. This manual provides important information for the safe assembly, operation, maintenance, and troubleshooting of your new ride-on toy. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

- Always supervise children during operation.
- Ensure the child wears appropriate safety gear, including a helmet and protective pads.
- Do not operate the motorcycle on public roads, near motor vehicles, or on steep inclines.
- Only one rider at a time.
- Keep hands, hair, and clothing away from moving parts.
- Do not modify the electrical system or components.
- The maximum weight capacity for this product is approximately 30 kg (66 lbs).

## PARTS LIST

Before assembly, ensure all parts are present:

- Main Motorcycle Body
- Front Wheel
- Handlebars
- Windshield
- Rearview Mirrors (2)

- Charger
- Rechargeable Battery (pre-installed or separate)
- Assembly Hardware (screws, washers, nuts)
- User Manual

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your Moto Fashion Electrica YLQ-3188:

1. **Attach the Front Wheel:** Slide the front wheel onto the axle. Secure it with the provided washers and nut. Ensure it spins freely.
2. **Install the Handlebars:** Insert the handlebar stem into the designated opening on the main body. Align the holes and secure with the provided screw and nut.
3. **Mount the Windshield:** Snap or screw the windshield into place on the front of the motorcycle body.
4. **Attach Rearview Mirrors:** Insert the rearview mirrors into their respective slots on the handlebars. They may click into place or require a small screw.
5. **Connect the Battery:** If the battery is not pre-connected, locate the battery compartment (usually under the seat). Connect the red wire from the battery to the red terminal on the motorcycle, and the black wire to the black terminal. Ensure connections are secure.



Image: Assembled Moto Fashion Electrica YLQ-3188 motorcycle in black. This image illustrates the general appearance of the product after assembly, highlighting the main body, wheels, and handlebar configuration.

## CHARGING THE BATTERY

---

The motorcycle is powered by a rechargeable battery. For optimal performance and battery life, follow these charging instructions:

1. **Initial Charge:** Before first use, charge the battery for 8-12 hours. Do not overcharge for more than 18 hours.
2. **Regular Charging:** When the motorcycle's speed decreases significantly, it's time to recharge. A typical recharge takes 8-12 hours.

### 3. Charging Procedure:

- Turn off the motorcycle.
- Locate the charging port (usually near the battery compartment or under the seat).
- Plug the charger into the charging port, then plug the charger into a standard wall outlet.
- The charger may have an indicator light (red for charging, green for fully charged).
- Unplug the charger once charging is complete.

4. **Battery Care:** Recharge the battery at least once a month, even if the motorcycle is not in use, to maintain battery health.

## OPERATING INSTRUCTIONS

---

Once assembled and charged, the motorcycle is ready for use:

1. **Power On:** Locate the power switch (usually on the dashboard or near the seat) and switch it to the 'ON' position.
2. **Start Riding:** Press the foot pedal (accelerator) to move forward. Release the pedal to stop.
3. **Steering:** Use the handlebars to steer the motorcycle left or right.
4. **Reverse (if applicable):** Some models may have a forward/reverse switch. If present, select 'R' for reverse and press the foot pedal.
5. **Lights and Sounds:** Operate any integrated lights or sound features using the buttons on the dashboard.
6. **Power Off:** When finished riding, switch the power button to the 'OFF' position.



Image: Moto Fashion Electrica YLQ-3188 motorcycle in yellow. This image provides an alternative view of the product, showcasing the design and features from a different angle, including the rear storage box.

## MAINTENANCE

---

Regular maintenance ensures the longevity and safe operation of your motorcycle:

- **Cleaning:** Wipe the motorcycle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery:** Follow charging instructions carefully. Store the battery in a cool, dry place when not in use for extended periods.
- **Wheels:** Periodically check the wheels for wear and tear. Ensure they are free of debris and spin smoothly.
- **Connections:** Regularly check all electrical connections and assembly hardware (screws, nuts) to ensure they are tight and secure.
- **Storage:** Store the motorcycle indoors in a dry area when not in use. Protect it from direct sunlight and extreme

temperatures.

## TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

| Problem                         | Possible Cause                                                                                      | Solution                                                                                                                                            |
|---------------------------------|-----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Motorcycle does not move        | Battery is low or dead<br>Power switch is off<br>Loose battery connection<br>Foot pedal malfunction | Charge the battery<br>Turn the power switch to 'ON'<br>Check and secure battery terminals<br>Contact customer support if pedal is faulty            |
| Motorcycle moves slowly         | Battery is low<br>Overloaded<br>Operating on rough terrain                                          | Recharge the battery<br>Ensure rider weight is within limits<br>Operate on smooth, flat surfaces                                                    |
| Motorcycle makes unusual noises | Loose parts<br>Debris in wheels/motor                                                               | Check all screws and connections<br>Inspect wheels and motor area for obstructions                                                                  |
| Battery does not charge         | Charger not plugged in correctly<br>Faulty charger or battery<br>Charging port issue                | Ensure charger is fully plugged into outlet and motorcycle<br>Test charger/battery if possible, contact support<br>Inspect charging port for damage |

## SPECIFICATIONS

- **Model:** YLQ-3188
- **Power Source:** Rechargeable Battery (e.g., 6V 4.5Ah)
- **Motor:** (e.g., 1 x 15W)
- **Speed:** Approximately 2-3 km/h (1.2-1.8 mph)
- **Charging Time:** 8-12 hours (initial charge 8-18 hours)
- **Run Time:** Approximately 1-2 hours (depending on use)
- **Max Load Capacity:** 30 kg (66 lbs)
- **Recommended Age:** 3-6 years
- **Dimensions (Approx.):** 80 cm (L) x 35 cm (W) x 50 cm (H)

*Note: Specifications are approximate and may vary slightly.*

## DISPOSAL

When the product reaches the end of its life, do not dispose of it with general household waste. The battery contains materials that should be recycled. Please take the product and battery to an authorized recycling center for proper disposal in accordance with local regulations.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question