

[Manuals.plus](#) /

› [SpyX](#) /

› SpyX Lazer Trap Alarm Instruction Manual - Model 10278

SpyX 10278

SpyX Lazer Trap Alarm Instruction Manual

Model: 10278

INTRODUCTION

The SpyX Lazer Trap Alarm is designed to create an invisible infrared beam barrier to protect your belongings. This set includes a receiver and two light beam senders, allowing for customizable security setups. Choose between a sound alert or a silent flashing light to signal intruders.



Image: SpyX Lazer Trap Alarm product packaging and individual units.

WHAT'S INCLUDED

- 1 x Receiver Unit
- 2 x Light Beam Sender Units
- Instruction Manual (this document)

Battery Requirements: 6 AAA batteries are required (not included).



Image: Contents of the SpyX Lazer Trap Alarm package, highlighting the receiver, two transmitters, and battery requirements.

SETUP INSTRUCTIONS

1. **Install Batteries:** Insert 2 AAA batteries into each of the three units (receiver and two senders). Ensure correct polarity.
2. **Position Units:** Place the receiver and the two light beam sender units up to 4 feet (1.2 meters) apart to create your desired laser barrier. The units can be adjusted up to 360 degrees to customize the trap's layout.
3. **Align Beams:** Ensure the infrared beams from the sender units are directed towards the receiver unit. The beams create an invisible barrier.
4. **Connect Multiple Sets (Optional):** For securing a larger area, additional SpyX Lazer Trap Alarm sets can be connected. Refer to the specific instructions for connecting multiple sets if applicable.



Image: A child setting up the SpyX Lazer Trap Alarm units to create an invisible barrier around an object.



Image: A close-up of the SpyX Lazer Trap Alarm units in a triangular setup, demonstrating the invisible laser beams.

Your browser does not support the video tag.

Video: A brief demonstration of the SpyX Lazer Trap Alarm being set up and triggered by a cat, showcasing its functionality.

OPERATING INSTRUCTIONS

Selecting Alert Mode:

The SpyX Lazer Trap Alarm offers two alert modes:

- **Sound Alert:** When the invisible beam is broken, the alarm will emit an audible sound.
- **Flashing Light Alert:** When the invisible beam is broken, the alarm will activate a silent flashing light.

To switch between modes, locate the mode selection switch on the receiver unit and select your preferred alert type.

Activating the Trap:

Once the units are positioned and the beams are aligned, turn on all units. The system is now active. Any movement that breaks the invisible infrared beam will trigger the selected alert mode.

Your browser does not support the video tag.

Video: A demonstration of the SpyX Lazer Trap Alarm in action, showing how the invisible beam triggers an alert when crossed.

MAINTENANCE

- **Cleaning:** Wipe the units with a dry, soft cloth. Do not use abrasive cleaners or immerse in water.
- **Battery Replacement:** Replace all 6 AAA batteries when the unit's performance diminishes or the lights/sounds become weak. Always use fresh batteries.
- **Storage:** Store the units in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for extended periods to prevent leakage.

TROUBLESHOOTING

- **Units not turning on:**
 - Ensure batteries are correctly installed with proper polarity.
 - Replace with fresh AAA batteries.
- **Alarm not triggering:**

- Verify that the light beams from the senders are directly aligned with the receiver. Adjust the angle of the units as needed.
 - Check the distance between units; they should be no more than 4 feet apart for optimal performance.
 - Ensure the chosen alert mode (sound or flashing light) is correctly selected.
- **Weak or inconsistent alert:**
 - Replace all batteries in the units.
 - Ensure no obstructions are partially blocking the infrared beams.

SPECIFICATIONS

- **Product Dimensions:** 4.06 x 2.87 x 2.36 inches
- **Item Weight:** 6.3 ounces
- **Model Number:** 10278
- **Recommended Age:** 6 - 12 years
- **Battery Type:** 6 AAA batteries (2 per unit, not included)
- **Maximum Beam Range:** Up to 4 feet (1.2 meters)
- **Manufacturer:** MukikiM

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official SpyX website. Keep your purchase receipt as proof of purchase.

© 2025 SpyX. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question