Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HQRP 887774407031562

HQRP Universal A/C Remote Control User Manual

Compatible with Mitsubishi Air Conditioner Models: E12A54426, KM07J, MSZ-A09NA, MSZ-A12NA, MSZ-A15NA, MSZ-A17NA, MSZ-A09NA-1, MSZ-A12NA-1

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your HQRP Universal A/C Remote Control. This remote is designed to be compatible with various Mitsubishi air conditioner models, offering a convenient replacement or secondary control unit.



Figure 1: HQRP Universal A/C Remote Control in its retail packaging.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries for operation. Ensure correct polarity when inserting the batteries.

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
3. Close the battery compartment cover securely.



Figure 2: Back of the remote control packaging indicating AAA battery requirement.

2.2 Programming the Remote Control

The HQRP Universal A/C Remote Control features a digital automatic code searching function for quick setup. It also supports manual code input.

Automatic Code Search:

1. Ensure your air conditioner unit is plugged in and powered on.
2. Point the remote control towards the air conditioner.
3. Press and hold the 'Set' button (or equivalent code search button) for approximately 6 seconds until the code on the remote's LCD display starts flashing.
4. Release the button. The remote will now automatically cycle through codes.
5. When your air conditioner responds (e.g., turns on, off, or changes mode), immediately press the 'OK' button to confirm the code.
6. Test all functions to ensure proper operation. If not all functions work, repeat the process to find a more suitable code.



Figure 3: Illustrative image of the remote control being used for quick setup with an air conditioner.

Manual Code Input:

If automatic search is unsuccessful or you know the specific code for your Mitsubishi unit, you can input it manually.

1. Plug in the air conditioner.
2. Refer to the code list provided with your remote (if available) to find the code for your Mitsubishi model (e.g., 594 for some Mitsubishi Mr. Slim units).
3. Press and hold the 'Set' button for approximately 6 seconds until the code in the window flickers.
4. Use the temperature up/down buttons (▲/▼) to adjust the code until the desired code appears.
5. When the correct code is displayed and the air conditioner responds, press the 'OK' button to confirm.
6. Test the remote control functions. If not working correctly, repeat steps 2-3 with a different code.




Manually input code
1. Manually plug-in the air conditioner, find the type of the air conditioner in the "Code Table", and find the first code, for example: Haier
2. Hold SET button (for about three seconds) until the conditioner type code flickers in the window, press Temperature "▲" or "▼" buttons until the desired code flickers in the window. When the code is right, the air conditioner will start.
3. Press OK button and the selected conditioner type code will stop flickering.
4. Test whether the remote control button has been effectively set. If yes, setting completes. And if no, repeat steps 2-3.
CODE:
CE



Figure 4: Back of the remote control showing the label with manual code input instructions.

2.3 Temperature Unit Selection (Fahrenheit/Celsius)

To switch between Fahrenheit (°F) and Celsius (°C) temperature display:

- With the remote powered on, press and hold the 'OK' button for approximately 6 seconds.
- The temperature unit on the LCD display will switch between °F and °C.

3. Operating Instructions

Familiarize yourself with the buttons and their functions on your HQRP Universal A/C Remote Control.



Figure 5: Angled view of the remote control.



Figure 6: Top view of the remote control.

3.1 Button Functions

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲/▼:** Adjusts the desired temperature up or down.
- **WIND (FAN):** Adjusts fan speed.
- **SWING (M.SWING / A.SWING):** Controls the vertical or horizontal swing of the air deflector.
- **LIGHT:** Activates the backlight on the remote's LCD display.
- **CLOCK:** Sets the current time.
- **TIME ON/TIME OFF:** Sets a timer for the air conditioner to turn on or off automatically.
- **SET:** Used for programming and confirming settings.
- **OK:** Confirms selections and changes temperature unit (hold for 6 seconds).

3.2 LCD Display

The LCD display shows the current settings, including:

- Operating mode icon.
- Set temperature and unit (°F/°C).
- Fan speed indicator.
- Swing function status.
- Current time.
- Timer ON/OFF status.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's display becomes dim or the remote stops responding. Always replace both batteries simultaneously with new AAA batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly and have sufficient charge. Replace if necessary.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Verify the remote is programmed to the correct code for your air conditioner. Re-program if unsure (refer to Section 2.2).
- **Temperature unit is incorrect (Celsius instead of Fahrenheit or vice-versa):**
  - Press and hold the 'OK' button for approximately 6 seconds to toggle between Fahrenheit (°F) and Celsius (°C).
- **Some functions do not work:**
  - The current programmed code may not fully support all functions of your specific air conditioner model. Try re-programming the remote using the automatic code search to find an alternative, more compatible code.

6. Specifications

Brand	HQRP
Model Number	887774407031562
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Battery Type	2 x AAA (Alkaline recommended)
Special Features	Large LCD display, Built-in clock, Timing ON/OFF function, Digital automatic code searching, Fahrenheit or Celsius temperature display option, Backlight function.
Compatible Mitsubishi Models	E12A54426, KM07J, MSZ-A09NA, MSZ-A12NA, MSZ-A15NA, MSZ-A17NA, MSZ-A09NA-1, MSZ-A12NA-1

7. Warranty and Support

7.1 Warranty Information

This HQRP remote control comes with a 100-day warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For further assistance or troubleshooting not covered in this manual, please contact HQRP customer support through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B010XQNDGS

More documents and user manuals: **https://manuals.plus/**