Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Bose /
- > Bose Solo 5 TV Soundbar Instruction Manual

Bose Solo 5

Bose Solo 5 TV Soundbar Instruction Manual

Model: Solo 5 (732522-2110)

1. Introduction

The Bose Solo 5 TV soundbar is designed to significantly enhance the audio quality of your television programs. It reproduces sound from dialogue to intricate details, featuring a dedicated dialogue mode for improved speech clarity. Its versatile design allows for various placement options, and Bluetooth connectivity enables wireless music streaming from compatible devices.



Figure 1: Bose Solo 5 TV Soundbar and Universal Remote Control. This image displays the compact soundbar unit alongside its multi-function remote control.

2. What's in the Box

Upon unboxing your Bose Solo 5 TV soundbar, verify that all the following components are present:

- Bose Solo 5 TV Soundbar
- · Universal Remote Control
- · Power Supply and Cable
- · Digital Optical Audio Cable

3. SETUP

3.1 Placement

Place the soundbar in front of your television or mount it on a wall. Ensure no objects obstruct the front of the soundbar for optimal sound projection.



Figure 2: Example placement of the Bose Solo 5 TV Soundbar. The soundbar is positioned horizontally on a TV stand, directly beneath the television screen.

3.2 Connections

Connect the soundbar to your TV using one of the following audio cables. Prioritize connections in the order listed below for best audio quality:

- 1. **Digital Optical Audio Cable:** Connect one end to the OPTICAL OUT port on your TV and the other end to the OPTICAL IN port on the soundbar.
- 2. **Digital Coaxial Audio Cable (not included):** Connect one end to the COAXIAL OUT port on your TV and the other end to the COAXIAL IN port on the soundbar.

3. **3.5mm Analog Audio Cable (not included):** Connect one end to the AUDIO OUT port on your TV and the other end to the AUX IN port on the soundbar.

After connecting the audio cable, connect the power supply to the soundbar's POWER port and then plug the power cable into a wall outlet.




Figure 3: Rear panel of the Bose Solo 5 TV Soundbar. This image highlights the various audio input ports (Optical, Coaxial, AUX) and the power input.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the **Power** button on the universal remote control to turn the soundbar on or off. The soundbar will automatically enter standby mode after a period of inactivity.

4.2 Volume Control

Adjust the volume using the Volume Up (+) and Volume Down (-) buttons on the remote. The volume indicator on

the soundbar will briefly illuminate to show the current level.

4.3 Source Selection

Press the **TV** button on the remote to select the television audio input. Press the **Bluetooth** button to switch to Bluetooth audio input.

5. Bluetooth Connectivity

The Bose Solo 5 soundbar features Bluetooth connectivity for wireless audio streaming from compatible devices such as smartphones, tablets, or computers.

5.1 Pairing a Bluetooth Device

- 1. Turn on the soundbar.
- 2. Press the **Bluetooth** button on the universal remote control. The Bluetooth indicator on the soundbar will blink blue.
- 3. On your mobile device, enable Bluetooth and select 'Bose Solo 5' from the list of available devices.
- 4. Once connected, the Bluetooth indicator on the soundbar will glow solid white.

The Bluetooth connection maintains stable operation up to approximately 9 meters (30 feet).

6. Universal Remote Control

The included universal remote control is designed to manage your TV, the Bose Solo 5 soundbar, and other connected Bluetooth devices. For detailed instructions on programming the remote for other devices, refer to the separate remote control guide or the Bose support website.

6.1 Dialogue Mode

Activate Dialogue Mode by pressing the **Dialogue** button on the remote. This feature enhances speech clarity, making conversations and vocals easier to understand, especially during movies or TV shows with complex audio mixes.

7. MAINTENANCE

7.1 Cleaning

Clean the soundbar with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the finish or internal components.

7.2 Storage

When not in use for extended periods, store the soundbar in a cool, dry place, away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

- · No Sound:
 - Ensure all audio cables are securely connected between the TV and the soundbar.

- Verify that the correct input source (TV or Bluetooth) is selected on the soundbar.
- Check if the soundbar is powered on and not muted.
- Confirm your TV's audio output settings are configured to send sound to an external speaker.

• Bluetooth Connection Issues:

- Ensure your Bluetooth device is within the 9-meter (30-foot) range of the soundbar.
- Try unpairing and then re-pairing the device with the soundbar.
- Check for potential interference from other wireless devices.

• Remote Control Not Responding:

- Replace the batteries in the universal remote control.
- Ensure there are no obstructions between the remote and the front of the soundbar.

9. Specifications

Feature	Specification
Model Name	Solo 5
Model Number	732522-2110
Dimensions (H x L x D)	7.0 cm x 54.8 cm x 8.6 cm (2.75 in x 21.5 in x 3.4 in)
Weight	1.69 kg (3.53 lbs)
Color	Black
Connectivity Technology	Bluetooth
Audio Inputs	Optical (Digital), Coaxial (Digital), 3.5mm (Analog)
Power Source	AC Adapter
Speaker Type	Soundbar
Control Method	Remote Control



Figure 4: Detailed dimensions of the Bose Solo 5 TV Soundbar. The image shows the length (54.86cm), height (8.64cm), and depth (7.11cm) of the unit.

10. WARRANTY AND SUPPORT

10.1 Manufacturer's Warranty

The Bose Solo 5 TV Soundbar is covered by a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

10.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact Bose customer support:

- Phone: 0033-806-230-000
- Website: Visit the official Bose support website for additional resources and contact options.

© 2023 Bose Corporation. All rights reserved.

Related Documents - Solo 5

EASI 1990/A. 170	Bose Bass Module 700 Setup Guide A comprehensive guide for setting up the Bose Bass Module 700 with various Bose sound systems, including the Bose Soundbar 500, 700, Smart Soundbar 300, Bose TV Speaker, and SoundTouch 300. Covers placement, app setup, wired connections, and ADAPTiQ calibration.
SOLO SOUNDBAR SERIES II	Bose Solo Soundbar Series II User Manual User guide for the Bose Solo Soundbar Series II, covering setup, safety, controls, Bluetooth, connectivity, and troubleshooting. Learn how to optimize your home audio experience with Bose.
NAMES OF TAXABLE PAGE	Bose Surround Speakers 700 Setup Guide A comprehensive guide to setting up your Bose Surround Speakers 700, including software updates, connection methods for different Bose soundbars, and ADAPTiQ audio calibration.
	Bose Surround Speakers Setup Guide with Bose Smart Soundbar Concise guide on setting up Bose Surround Speakers with Bose Smart Soundbar using the Bose Music app. Includes instructions for different Bose soundbar models and links to resources.
	Bose Bass Module 700 Installation Guide and Setup Instructions Get step-by-step installation instructions for the Bose Bass Module 700. This guide covers setup for compatible Bose soundbars including Soundbar 500, 700, Smart Soundbar 300, TV Speaker, and SoundTouch 300. Available in multiple languages.



Bose Solo Soundbar Series II Quick Start Guide

Get started with your Bose Solo Soundbar Series II. This guide provides step-by-step instructions for setup, connection, and basic operation of your soundbar.