

[Manuals.plus](#) /

› [URPOWER](#) /

› URPOWER 300ml Aromatherapy Essential Oil Diffuser Ultrasonic Air Humidifier AUTO Shut Off Scent Diffuser Night Light 7 Color Changing LED Lights and 4 Timer Settings for Bedroom Office Home A-white

URPOWER OD-301

URPOWER 300ml Aromatherapy Essential Oil Diffuser

INSTRUCTION MANUAL

Model: OD-301

Introduction

Thank you for choosing the URPOWER 300ml Aromatherapy Essential Oil Diffuser. This ultrasonic device is designed to enhance your living space by diffusing essential oils and humidifying the air. Its quiet operation, customizable lighting, and safety features make it a perfect addition to any room. Please read this manual carefully before use to ensure proper operation and maintenance.

Product Overview

Your URPOWER diffuser is a compact and efficient device. It consists of the main unit, a cover, and a power adapter. A measuring cup is also included for convenient water filling.




Figure 1: URPOWER 300ml Essential Oil Diffuser Main Unit

Setup Instructions

1. **Placement:** Place the diffuser on a flat, stable surface away from direct sunlight or heat sources.
2. **Remove Cover:** Gently remove the top cover of the diffuser.
3. **Add Water:** Using the provided measuring cup, fill the water tank with clean tap water. Do not exceed the maximum water line indicated inside the tank (300ml).



Figure 2: Proper water filling for the diffuser.

4. **Add Essential Oil:** Add 2-3 drops of your preferred 100% pure essential oil per 100ml of water directly into the water tank. Adjust the amount based on desired fragrance intensity.
5. **Replace Cover:** Carefully replace the top cover, aligning the arrows on the base and cover. Twist slightly clockwise until you hear a click, ensuring it is firmly in place. The unit will not operate if the cover is not securely attached.
6. **Connect Power:** Plug the power adapter into the DC jack at the bottom of the diffuser, then plug the adapter into a standard wall outlet.

Operating Instructions

The URPOWER diffuser features two main control buttons: **LIGHT** and **MIST**.

7 CHANGING LED LIGHT



Adjustable
Brightness



Color Auto
Cycles & Fixed



LED Light & Mist Mode
Work Separately



Figure 3: Diffuser showcasing 7 color changing LED lights.

Mist Control

- **Turn On Mist:** Press the **MIST** button for one second. The diffuser will start in continuous mist mode.
- **Set Timer:** Subsequent presses of the **MIST** button will cycle through timer settings: 60 minutes, 180 minutes, 360 minutes, and then continuous (ON). The diffuser will automatically shut off when the selected timer completes or when water runs low.
- **Turn Off Mist:** Press and hold the **MIST** button for two seconds to turn off the mist function.

4 TIMER OPTIONS

Light & Mist Works Separately
Press Mist Button for one second to turn on



Figure 4: Diffuser with 4 timer options: ON, 60 min, 180 min, 360 min.

Light Control

- **Turn On Light:** Press the **LIGHT** button. The LED lights will begin cycling through 7 colors.
- **Set Fixed Color:** Press the **LIGHT** button again when your desired color appears. The light will remain on that color.
- **Adjust Brightness/Shade:** For some colors, pressing the **LIGHT** button repeatedly while on a fixed color may cycle through different shades of that color.
- **Turn Off Light:** Press and hold the **LIGHT** button for two seconds to turn off the light function. Note that a small green indicator light may remain on to show the unit has power.

Maintenance

Regular cleaning ensures the longevity and optimal performance of your diffuser. It is recommended to clean the unit every 2-3 uses.

1. **Empty Water:** Unplug the diffuser and remove the cover. Carefully empty any remaining water from the tank. Always pour water from the side indicated by the arrow to avoid water entering the air outlet.
2. **Clean Tank:** Add a small amount of water and a few drops of mild detergent to the tank. Use a soft cloth or sponge to wipe the inside of the water tank, the ultrasonic atomizer (the middle part of the tank), and the lid.
3. **Rinse and Dry:** Rinse thoroughly with clean water. Ensure all detergent residue is removed. Dry the unit completely before storing or refilling.



Figure 5: Step-by-step guide for cleaning your diffuser.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No mist or low mist output	- Insufficient water in tank - Water level exceeds MAX line - Cover not properly installed - Ultrasonic atomizer dirty	- Add water (below MAX line) - Pour out excess water - Ensure cover is aligned and twisted securely - Clean the atomizer as per maintenance instructions
Unit turns off unexpectedly	- Water level too low (auto-off activated) - Timer setting completed - Water entered air outlet	- Refill water tank - Check timer setting - Ensure proper draining from arrow side only
Light not working	- Light function turned off - Power issue	- Press LIGHT button to turn on/cycle - Check power connection
Unusual noise	- Insufficient water - Unit not on a flat surface	- Refill water tank - Place on a stable, flat surface

Specifications

- **Brand:** URPOWER
- **Model Number:** OD-301
- **Capacity:** 300 Milliliters
- **Power Source:** Corded Electric
- **Wattage:** 12 watts
- **Material:** Polypropylene (PP)
- **Product Dimensions:** 4.33"L x 4.33"W x 6.06"H
- **Auto Shutoff:** Yes
- **Light Source Type:** LED (7 Color Changing)

Warranty & Support

URPOWER is committed to providing high-quality products and excellent customer service. For any questions, concerns, or support needs regarding your diffuser, please contact our customer support team. Refer to your product packaging or the URPOWER official website for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question