

Bissell 1544A

Bissell PowerFresh Lift-Off Pet Steam Mop (Model 1544A) Instruction Manual

Model: 1544A | Brand: Bissell

1. INTRODUCTION AND OVERVIEW

The BISSELL PowerFresh Lift-Off Pet steam mop provides a versatile cleaning solution for various surfaces. This 2-in-1 steam mop features a removable Lift-Off pod for above-floor cleaning and includes 13 versatile accessories to assist with everyday cleaning tasks. Cleaning with steam offers a chemical-free method, eliminating 99.9% of germs and bacteria when used as directed with microfiber pads.



Figure 1: Bissell PowerFresh Lift-Off Pet Steam Mop and detachable handheld unit.

2. SAFETY INFORMATION

Always follow user guide for safe use. To reduce the risk of fire and electric shock, do not immerse the appliance in water. This product is not for space heating purposes. Ensure the appliance is unplugged before performing maintenance or when not in use. Keep hands and face away from steam output during operation. Use only as directed in this manual.

3. PACKAGE CONTENTS

Your Bissell PowerFresh Lift-Off Pet Steam Mop package includes:

- PowerFresh Lift-Off Steam Mop Unit
- 1 Microfiber Soft Pad

- 1 Microfiber Scrubby Pad
- 2 Odor Eliminating Fragrance Discs
- Attachable Water Cup
- 13 Versatile Tools with a Tool Bag
- Microfiber Towel

Multiple cleaning tools

13 versatile tools included



Figure 2: Included 13 versatile cleaning tools.

3. Press the 'Steam Level' button to cycle through the available steam settings (low, medium, high) to suit your cleaning needs.

5.2 Using the Steam Mop

Once the unit is heated and the desired steam level is selected, gently push the mop across the floor surface. The steam will be released, cleaning and sanitizing as you go. The swivel steering allows for easy maneuverability around furniture.



Figure 4: Steam mop in action on a tiled floor.

5.3 Using the Handheld Steamer (Lift-Off Pod)

To use the handheld steamer, detach the Lift-Off pod from the main unit. Select the appropriate tool from the 13 included accessories and attach it to the handheld unit. The handheld steamer is ideal for cleaning surfaces above floors, such as countertops, grout, windows, pet beds, and pet bowls.

Detachable Handheld Steamer to clean surfaces above your floors



Figure 5: Detachable handheld steamer cleaning a kitchen faucet.

Cleans across:



Figure 6: Versatile cleaning applications for the handheld steamer.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Bissell PowerFresh Lift-Off Pet Steam Mop's features and use.

6. MAINTENANCE

6.1 Cleaning Microfiber Pads

The microfiber soft pad and scrubby pad are reusable and machine washable. After each use, remove the pads from the mop head and wash them according to the care instructions on the pad. Do not use bleach or fabric softeners.

6.2 Emptying the Water Tank

After each use, or when storing the unit, ensure the water tank is emptied. Unplug the unit, allow it to cool, remove the water tank, and pour out any remaining distilled water.

7. TROUBLESHOOTING

If the unit is not producing steam, ensure it is properly plugged in and the water tank is filled with distilled water. Allow sufficient time (approximately 30 seconds) for the unit to heat up. If the issue persists, refer to the full user manual for detailed troubleshooting steps or contact customer support.

8. SPECIFICATIONS

Model Number	1544A
Wattage	1500 watts
Item Weight	10.6 pounds
Water Tank Capacity	13.5 ounces
Heater Warm-Up Time	30 seconds
Power Source	Corded Electric
Product Dimensions	13.2"D x 11.14"W x 44.7"H

9. WARRANTY AND SUPPORT

This Bissell PowerFresh Lift-Off Pet Steam Mop comes with a Limited 2-Year Warranty. For warranty claims, technical support, or replacement parts, please refer to the contact information provided in your original product packaging or visit the official Bissell website.