

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Diesel](#) /
- › [Diesel Mega Chief DZ4378 Watch User Manual](#)

Diesel DZ4378

Diesel Mega Chief DZ4378 Watch User Manual

Model: DZ4378

1. PRODUCT OVERVIEW

The Diesel Mega Chief DZ4378 is a robust and stylish men's watch featuring a chronograph function and a durable black silicone strap. Designed for everyday wear and active lifestyles, it combines precision quartz movement with a distinctive aesthetic. This manual provides essential information for setting up, operating, and maintaining your watch.



Figure 1: Front view of the Diesel Mega Chief DZ4378 watch.

2. INITIAL SETUP

2.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to position 2 for setting the date, or position 3 for setting the time.
2. **Set the date:** In position 2, turn the crown clockwise or counter-clockwise until the correct date appears in the date window.
3. **Set the time:** In position 3, turn the crown to move the hour and minute hands to the desired time. Ensure to account for AM/PM if your watch has a 24-hour indicator or if setting the date.
4. **Push in the crown:** Once the time and date are set, push the crown back into its original position (position 1) to start the watch and ensure water resistance.






Figure 2: Side view showing the crown and pushers for time and chronograph adjustments.

2.2 Adjusting the Strap

The silicone strap features a buckle closure. Adjust the strap by selecting the appropriate hole for a comfortable and secure fit on your wrist. Ensure the watch is not too tight to avoid discomfort, nor too loose to prevent excessive movement.

3. OPERATING THE CHRONOGRAPH

Your Diesel Mega Chief DZ4378 watch is equipped with a chronograph function for measuring elapsed time. The chronograph features three subdials: a 60-second counter, a 30-minute counter, and a 24-hour indicator.



Figure 3: Chronograph subdials on the watch face.

1. **Start/Stop:** Press the top pusher (A) to start the chronograph. Press it again to stop the measurement.
2. **Reset:** While the chronograph is stopped, press the bottom pusher (B) to reset all chronograph hands to zero.
3. **Split Time:** Some models may feature a split-time function. Consult the detailed manual for specific instructions if applicable.

3.1 Water Resistance

This watch is water resistant up to 330 feet (10 BAR). This rating makes it suitable for showering, swimming, and snorkeling. **Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance.**

4. MAINTENANCE

4.1 Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can

be used, followed by thorough rinsing and drying.

- **Silicone Strap:** Clean the silicone strap with mild soap and water. Rinse thoroughly and dry completely before wearing. Avoid harsh chemicals or abrasive materials.

4.2 Battery Replacement

The watch is powered by a product-specific battery (included). When the battery runs low, the watch hands may stop or the chronograph may malfunction. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Date not changing:** Ensure the time is set correctly, especially past midnight, as the date typically changes between 9 PM and 3 AM. If the date is stuck, try manually advancing it using the crown in position 2.
- **Chronograph hands not resetting to zero:** If the chronograph hands do not reset to the 12 o'clock position, they may need calibration. Consult a professional watch repair service.

6. SPECIFICATIONS

Model Number:	DZ4378
Brand:	Diesel
Movement:	Quartz
Display Type:	Analog
Case Material:	Stainless Steel
Case Diameter:	51 Millimeters
Case Thickness:	12 Millimeters
Band Material:	Silicone
Band Width:	26 Millimeters
Water Resistance Depth:	330 Feet (10 BAR)
Crystal Type:	Mineral
Power Source:	Battery Powered

7. WARRANTY AND SUPPORT

Your Diesel Mega Chief DZ4378 watch comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and how to make a claim.

For further assistance, technical support, or service inquiries, please visit the official Diesel website or contact their customer service department. Keep your proof of purchase for warranty validation.



Figure 4: The watch is typically packaged in a branded box.

8. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: Overview of the Diesel Men's Mega Chief Black Silicone Watch DZ4378. This video provides a visual demonstration of the watch's design and features.

