

Manuals.plus /

› Little Tikes /

› Little Tikes Perfect Fit 4-in-1 Trike Teal - Instruction Manual

Little Tikes 638695C

Little Tikes Perfect Fit 4-in-1 Trike Teal

Model: 638695C

Manufacturer: Little Tikes

1. PRODUCT OVERVIEW

The Little Tikes Perfect Fit 4-in-1 Trike is designed to adapt and grow with your child, offering four distinct stages of use from infancy through toddlerhood. This versatile trike combines the convenience of a stroller with the fun of a tricycle, ensuring comfort and safety for your child while providing ease of use for parents.

Key Features:

- **4-Stage Design:** Grows with your child from 9 months to 5 years.
- **Full Shade Canopy:** Provides protection from the sun at various angles.
- **High-Back Seat:** Ensures comfort and safety for the child.
- **Adjustable Seat:** Easily adjusts without tools to accommodate growing children.
- **Full Foot Platform:** Protects little feet when not pedaling.
- **Parent Storage:** Includes a large storage bucket and bottle holder for convenience.
- **Safety-Bar:** Features a cup/snack holder for the child.

2. SETUP AND ASSEMBLY

Assembly of the Little Tikes Perfect Fit 4-in-1 Trike is required before first use. Please refer to the detailed Installation Manual (PDF) provided with your product for step-by-step instructions. Ensure all components are securely fastened before allowing a child to use the trike.

For a visual guide on assembly and features, please watch the official product video below:

Your browser does not support the video tag.

Official product video demonstrating the features and assembly of the Little Tikes Perfect Fit 4-in-1 Trike, provided by the seller.

A digital copy of the installation manual can be found here.

3. OPERATING INSTRUCTIONS: 4 STAGES OF GROWTH

The Perfect Fit 4-in-1 Trike is designed to evolve with your child's development, offering optimal support and engagement at each stage.

Stage 1: Stroll (9+ months)

In this stage, parents maintain full control of the trike. The child's feet rest comfortably on the full foot platform, preventing them from reaching the pedals. This mode is ideal for younger infants who are not yet ready to pedal or steer.



The trike in Stroll mode, with a parent pushing a child. The parent handle provides steering control.



The full foot platform ensures comfort and safety for the child's feet during the Stroll stage.

Stage 2: Pedal (18+ months)

As your toddler grows, they can begin to learn how to pedal. In this stage, the child can pedal, but the parent still maintains control over steering using the push bar. The foot platform can be removed or folded away to allow access to the pedals.



The pedals can be engaged or disengaged, allowing for parent-powered or child-driven modes.

Stage 3: Learn (24+ months)

At this stage, the child gains more independence. The waist bar can be removed, allowing the child to steer the trike while the parent still has the option to assist with the push bar for guidance and safety.



The trike configured for the Learn stage, with the safety bar removed to allow the child to steer.

Stage 4: Trike (30+ months)

Once the child is confident and capable, the push bar can be fully removed, transforming the unit into a traditional tricycle. Children can then ride independently with appropriate parent supervision.



The trike in its final stage, ready for independent riding.



A child enjoying the trike in its independent riding mode.

4. FEATURES IN DETAIL

Adjustable Canopy

The full shade canopy can be adjusted to protect your child from the sun at various angles, ensuring comfort during outdoor adventures.



The canopy can be easily adjusted to provide optimal shade.

Parent Handle with Storage

The ergonomic parent handle provides comfortable pushing and steering. It includes a convenient tray with a cup holder and compartments for snacks, keys, and a cell phone, making on-the-go travel easier for parents.



The parent handle features a convenient storage tray for essentials.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your Little Tikes Perfect Fit 4-in-1 Trike.

- **Cleaning:** Wipe down plastic parts with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Lubrication:** Periodically check moving parts (wheels, pedals) for smooth operation. Apply a small amount of silicone-based lubricant if needed.
- **Storage:** Store the trike in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspections:** Regularly inspect all nuts, bolts, and fasteners to ensure they are tight. Check for any signs of wear or damage to the frame, wheels, or fabric components.

6. TROUBLESHOOTING

If you encounter any issues with your trike, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Wheels not turning smoothly	Debris in axle, lack of lubrication, loose parts.	Clean axles, apply lubricant, tighten fasteners.
Pedals not engaging/disengaging	Mechanism stuck, incorrect setting.	Check pedal engagement switch, clear any obstructions.
Trike feels unstable	Loose assembly, uneven ground.	Ensure all connections are tight, use on flat surfaces.
Canopy not staying in place	Loose attachment points.	Verify canopy is securely clicked into position.

If issues persist, please contact Little Tikes customer support.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	23.25 x 16 x 11 inches
Item Weight	15.99 pounds
Country of Origin	China
Item Model Number	638695C
Manufacturer Recommended Age	9 months - 5 years
Manufacturer	Little Tikes

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your Little Tikes Perfect Fit 4-in-1 Trike. You may also visit the official Little Tikes website for further assistance or to view the full installation manual.

For additional support, you can refer to the [Installation Manual \(PDF\)](#).