

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fujitsu General](#) /
- › [Fujitsu General Air Conditioner Remote Control AR-RCC2J User Manual](#)

Fujitsu General AR-RCC2J

Fujitsu General Air Conditioner Remote Control AR-RCC2J User Manual

Model: AR-RCC2J

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Fujitsu General Air Conditioner Remote Control, model AR-RCC2J. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

SETUP

Battery Installation

The remote control requires two AAA (UM-4) alkaline batteries. Ensure correct polarity when inserting the batteries.

1. Slide the battery cover on the back of the remote control downwards to open.
2. Insert two new AAA alkaline batteries, matching the (+) and (-) terminals as indicated inside the battery compartment.
3. Close the battery cover by sliding it back into place until it clicks.

Important: Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period to prevent leakage.



Figure 1: Back of the remote control with battery compartment.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your remote control. The following section describes the function of each button.



Figure 2: Front view of the remote control.

Button Name	Function
/ (Operation/Stop)	Turns the air conditioner unit ON or OFF.
(Operation Mode)	Cycles through operation modes: Auto, Cooling, Dehumidify, Fan, Heating.
(Temperature) ▲/▼	Adjusts the desired temperature setting.
(Fan Speed)	Adjusts the fan speed: Auto, Strong, Weak, Gentle, Silent.

Button Name	Function
(Air Direction)	Adjusts the horizontal airflow direction.
(Swing)	Activates or deactivates the automatic vertical airflow swing.
(High Power)	Activates a powerful operation mode for rapid cooling or heating.
(Current Cut)	Engages an energy-saving mode by limiting current consumption.
(Signal Switch)	Used for switching signals, potentially for controlling multiple units or specific functions.
(Plasma Ion)	Activates the Plasma Ion function for air purification.
(Internal Clean)	Initiates an internal cleaning cycle for the air conditioner unit.
(Timer)	Sets or cancels the ON/OFF timer.
(Switch)	Used for navigating or confirming timer settings.
(Time Change)	Adjusts the time for timer settings.
(Reset)	Resets the remote control settings. Typically a recessed button requiring a pointed object.

MAINTENANCE

Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

Battery Replacement

Replace batteries when the display becomes dim or the remote control becomes unresponsive. Refer to the 'Battery Installation' section for detailed instructions.

TROUBLESHOOTING

- **Remote Control Not Responding:**

Check if the batteries are inserted correctly with the correct polarity. Replace with new batteries if they are old or depleted. Ensure there are no obstructions between the remote control and the air conditioner unit's receiver.

- **Display is Dim or Blank:**

This indicates low battery power. Replace both batteries with new AAA alkaline batteries. After replacing batteries, press the 'Reset' button (if available and accessible) to restore full functionality.

- **Air Conditioner Not Responding to Commands:**

Ensure the remote control is pointed directly at the air conditioner unit. Verify that the air conditioner unit is powered on. If the issue persists, try resetting the remote control by removing and reinserting the batteries, then pressing the 'Reset' button.

SPECIFICATIONS

Feature	Detail
Model Number	AR-RCC2J
Color	White
Power Source	2 x AAA Alkaline Batteries (not included)
Dimensions (approx.)	16.8 x 9 x 3.3 cm
Weight (approx.)	98 g
UPC	601209819167

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your Fujitsu General air conditioner unit or contact Fujitsu General customer service directly. This remote control is designed as a genuine replacement part.