

DELTA 9113T-DST

Delta Essa Chrome Touch Kitchen Faucet with Pull Down Sprayer

MODEL 9113T-DST INSTRUCTION MANUAL

Introduction

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Delta Essa Chrome Touch Kitchen Faucet with Pull Down Sprayer, Model 9113T-DST. Please read these instructions thoroughly before beginning installation or operation to ensure proper function and longevity of your product.

Key Features

- **Touch2O Technology:** Activates or deactivates water flow with a simple touch to the spout or handle.
- **TempSense LED Light:** Changes color to indicate water temperature, providing a visual cue for hot or cold water.
- **MagnaTite Docking:** Utilizes an integrated magnet to securely hold the pull-down spray wand in place when not in use.
- **DIAMOND Seal Technology:** Engineered to reduce leak points and ensure durable, leak-free operation.
- **Touch-Clean Spray Holes:** Allows for easy removal of mineral buildup from the spray face with a simple wipe.
- **Pull-Down Sprayer:** Offers flexibility for various kitchen tasks with a 20-inch hose and 360-degree swivel.

Setup and Installation

Before installation, ensure all necessary components are present and that water supply lines are shut off. This faucet is designed for either 1-hole or 3-hole 8-inch center installations. An optional deck plate is included to cover pre-existing holes.

Installation Requirements:

- **Hole Count:** 1 or 3 holes.
- **Hole Size:** 1.25 to 1.5 inches.
- **Water Supply Connection:** 0.375 inches.
- **Minimum Clearance to Backsplash:** 2.5 inches.

- **Batteries:** 4 AAA batteries are required and included for Touch2O functionality.

HOLES FOR INSTALLATION	DIMENSIONS
	
ADDITIONAL INFORMATION MINIMUM CLEARANCE TO BACKSPLASH 2.5 inches SUPPLY LINES Included HOLE SIZE 1.25–1.5 inches WATER SUPPLY CONNECTION .375 inches 	OPTIONAL DECK PLATE (Included) Covers pre-existing holes 10.25 inches wide 8 inches between hole centers

Image: Faucet dimensions and installation hole requirements. The diagram illustrates the faucet's height (16 inches), spout reach (9.38 inches), and requirements for 1-hole or 3-hole installation, including hole size and water supply connection details. An optional deck plate is shown for 3-hole installations.

Refer to the detailed installation guide provided in the product packaging for step-by-step instructions. Ensure all connections are secure to prevent leaks.

Operating Instructions

Touch2O Technology:

To activate or deactivate water flow, simply touch any part of the faucet spout or handle with your wrist or forearm. The water will flow at the temperature set by the manual handle position.

DELTA TOUCH₂O[®] TECHNOLOGY

A SIMPLE TOUCH ANYWHERE
ON THE SPOUT OR HANDLE
ACTIVATES THE FLOW OF WATER



TEMPSENSE[®] LED LIGHT
CHANGES COLOR AS WATER
TEMPERATURE CHANGES



Image: Delta Touch2O Technology in use. A hand is shown touching the faucet to activate water flow. The TempSense LED light at the base of the faucet changes color to indicate water temperature (blue for cold, magenta for warm, red for hot).

Manual Handle Operation:

The single lever handle controls both water flow volume and temperature. Move the handle up to increase flow and down to decrease. Move it left for hot water and right for cold water.

Pull-Down Sprayer:

Gently pull down the spray wand from the spout. The sprayer offers two modes: stream and spray. Use the toggle switch on the spray head to switch between these modes. When finished, guide the spray wand back into the spout; the MagnaTite Docking system will secure it in place.



see what Delta can do™

360°
SWIVEL

20"
HOSE



TOUCH-CLEAN®
SPRAY HOLES

Image: Pull-down sprayer features. This image highlights the 20-inch hose, 360-degree swivel capability, and the Touch-Clean spray holes on the spray head, which allow for easy cleaning of mineral buildup.

SPRAY OR STREAM



Image: Spray or Stream modes. Two images show the faucet in operation, one demonstrating the wide spray pattern and the other showing a focused stream, illustrating the versatility of the pull-down sprayer.

Maintenance

Cleaning the Faucet:

To maintain the chrome finish, clean with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes that could damage the finish. For mineral buildup on the spray holes, gently wipe them with your finger to dislodge deposits.

Battery Replacement:

The Touch2O Technology is powered by 4 AAA batteries (included). When the batteries are low, the TempSense LED light may flash intermittently or the touch function may become unreliable. Replace all 4 batteries simultaneously with new alkaline AAA batteries to ensure optimal performance.

Troubleshooting

Problem	Possible Cause	Solution
No water flow or low flow	Water supply valves are closed; aerator is clogged; kink in supply line.	Ensure water supply valves under the sink are fully open. Clean or replace the aerator. Check for kinks in the hot and cold supply lines.
Touch function not working	Low or dead batteries; loose electrical connection.	Replace all 4 AAA batteries. Check all electrical connections to the battery box and solenoid for secure fit.
Water temperature inconsistent	Incorrect handle position; issues with water heater.	Adjust the manual handle to the desired temperature. Verify your water heater is functioning correctly.
Sprayer does not retract fully	Obstruction in hose path; counterweight position.	Check under the sink for any items obstructing the sprayer hose. Ensure the counterweight is positioned correctly on the hose.
Leaks from faucet base or connections	Loose connections; damaged O-rings or seals.	Tighten all connections, ensuring not to overtighten. Inspect O-rings and seals for damage and replace if necessary.

Specifications

Feature	Detail
Brand	DELTA
Model Name	Essa®
Part Number	9113T-DST
Finish Type	Chrome
Material	Metal
Mounting Type	Deck Mount
Number of Handles	1
Hole Count	1
Maximum Flow Rate	1.8 Gallons Per Minute
Spout Height	15.75 Inches
Spout Reach	9.25 Inches
Hose Length	20 Inches
Item Weight	1 pounds (454 Grams)
Batteries	4 AAA batteries (included)

Warranty

Delta faucets are backed by a Lifetime Limited Warranty. Electronic parts, including the Touch2O Technology

components, are backed by a 5-year electronic parts warranty. This warranty covers defects in material and manufacturing. For full warranty details, please refer to the documentation included with your product or visit the official Delta Faucet website.

Support

For technical assistance, replacement parts, or warranty claims, please contact Delta Faucet customer service. Our highly trained customer care team is available to help you.

Customer Service Phone: 1-800-345-3358

Please have your model number (9113T-DST) and date of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question