

UPBRIGHT Shomi 7A DPF GiiNii SP-704P-2 Power

UpBright 5V 1A AC/DC Adapter Instruction Manual

For Shomi and GiiNii Digital Photo Frames (Models: SP-704P-2, GT-701P-1, SP-701P, SP-702P-1, SP-706P-1, SP-801P, SP-811P)

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UpBright 5V 1A AC/DC Adapter. This power supply is designed to provide reliable power to compatible Shomi and GiiNii LED Digital Photo Frames, ensuring optimal performance.

The adapter features a worldwide input voltage range (100-240VAC) and incorporates safety protections including Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.

SETUP INSTRUCTIONS

Follow these steps to properly set up your UpBright AC/DC adapter:

- Inspect the Adapter:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
- Connect to Device:** Locate the power input port on your Shomi or GiiNii digital photo frame. Insert the barrel connector of the UpBright adapter firmly into this port. Ensure a snug fit.
- Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard wall power outlet (100-240VAC, 50/60Hz). Ensure the outlet is easily accessible.
- Verify Power:** Once connected, your digital photo frame should receive power. Refer to your photo frame's manual for specific power indicator lights or startup procedures.



Image: The UpBright 5V 1A AC/DC adapter showing the main unit with a two-prong plug and the attached cable ending in a barrel connector.



Image: A different view of the UpBright 5V 1A AC/DC adapter, highlighting the coiled cable and the barrel connector.

OPERATING INSTRUCTIONS

The UpBright AC/DC adapter is designed for simple plug-and-play operation. Once connected as described in the Setup section, it will continuously supply power to your compatible digital photo frame.

- **Continuous Power:** The adapter provides a stable 5V DC output, suitable for continuous operation of your device.
- **Safety Features:** Built-in OVP, OCP, and SCP protections automatically safeguard your device against electrical irregularities.
- **Disconnection:** To disconnect power, first unplug the adapter from the wall outlet, then disconnect the barrel connector from your device.

CARE AND MAINTENANCE

Proper care ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Do not expose the adapter to water, moisture, or high humidity. Avoid dropping or subjecting it to strong impacts. Do

not attempt to open or repair the adapter yourself.

TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC adapter, try the following steps:

- **No Power to Device:**

- Ensure the adapter is securely plugged into a working wall outlet. Test the outlet with another device.
- Verify that the barrel connector is fully inserted into your digital photo frame's power port.
- Check the adapter cable for any visible damage or kinks.

- **Device Not Charging/Operating Correctly:**

- Confirm that your digital photo frame model is listed as compatible with this 5V 1A adapter. Refer to your device's specifications.
- Disconnect and reconnect the adapter from both the wall and the device.
- If the issue persists, the device itself may have a fault.

- **Adapter Overheating:**

- It is normal for adapters to feel warm during operation. However, if it becomes excessively hot to touch or emits a burning smell, immediately unplug it from the wall outlet and discontinue use.
- Ensure the adapter is not covered or placed in an area with poor ventilation.

If troubleshooting steps do not resolve the issue, please contact UpBright customer support.

PRODUCT SPECIFICATIONS



Image: Top view of the UpBright 5V 1A AC/DC adapter, clearly showing the product label with input and output specifications.

Feature	Detail
Brand	UPBRIGHT
Model Number	Shomi 7A DPF GiiNii SP-704P-2 Power (Compatible with various Shomi/GiiNii models)
Input Voltage	100-240VAC, 50/60Hz (Worldwide Use)
Output Voltage	5V DC
Output Current	1A (1000mA)
Wattage	5 Watts (5V * 1A)
Connector Type	Barrel Connector
Safety Protections	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, UL
Product Dimensions	3 x 2 x 1 inches

Feature	Detail
Item Weight	3 ounces

WARRANTY INFORMATION

UpBright products are backed by a commitment to quality. This adapter includes:

- **30-Day Refund Policy:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **24-Month Exchange Policy:** UpBright offers a 24-month exchange policy for defective units.

Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the official UpBright Limited Warranty Certificate.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order




Image: This image displays various international outlet adapters (AU, EU, UK) that may be included with international orders, alongside a graphic representation of the UpBright Limited Warranty Certificate.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact UpBright customer service through the retailer where the product was purchased or visit the official UpBright store page.

UpBright Store: [Visit the UPBRIGHT Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B012I7X8R4>

More documents and user manuals: **<https://manuals.plus/>**