

AEE S60 Plus

AEE S60 Plus Action Camera User Manual

Model: S60 Plus

1. INTRODUCTION

The AEE S60 Plus Action Camera is designed for capturing high-quality video and photos in various dynamic environments. It features Full 1080P HD video recording at 60 frames per second, 16-megapixel still image capture, and advanced shooting modes like burst and time-lapse. The camera includes a modular 2-inch TFT LCD screen for convenient viewing and playback, and is Wi-Fi enabled for seamless connectivity with mobile devices. Its robust design, complemented by an included waterproof case, makes it suitable for action sports and underwater activities.

2. PACKAGE CONTENTS

Upon opening your AEE S60 Plus Action Camera package, please verify that all the following items are included:

- AEE S60 Plus Action Camera
- Detachable 2-inch LCD TFT Screen
- IP68 Waterproof Housing
- Quick Release Buckle
- Flat 3M Adhesive Mount
- Curved 3M Adhesive Mount
- Anti-Fog Inserts
- USB Charging Cable (Mini 10-pin)
- Hand Strap
- Lithium Ion Battery (pre-installed or separate)



Image: The AEE S60 Plus Action Camera, its waterproof housing, detachable LCD screen, various mounts, cables, and documentation, all neatly arranged beside the product packaging.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your AEE S60 Plus Action Camera.



Image: Front view of the AEE S60 Plus Action Camera. Visible features include the main lens, the green power/mode button, and two small indicator lights at the top left. The "AEE S60 Plus" logo is printed on the front.



Image: An angled view of the AEE S60 Plus Action Camera, highlighting the front lens, the power button, and the top-mounted control buttons. The side of the camera reveals ports for connectivity.



Image: Rear view of the AEE S60 Plus Action Camera, showing the integrated 2-inch TFT LCD display. This screen allows for live view, playback, and menu navigation.

4. SETUP

4.1. Battery Installation and Charging

1. Locate the battery compartment on the camera.
2. Insert the included Lithium Ion battery, ensuring correct polarity.
3. Close the battery compartment securely.
4. Connect the camera to a USB power source using the provided USB charging cable. The charging indicator light will illuminate.
5. A full charge typically takes approximately 3 hours.

4.2. Micro SD Card Insertion

- The AEE S60 Plus supports Micro SD cards up to 64GB (Class 10 or higher recommended for optimal performance).
- With the camera powered off, open the Micro SD card slot cover.
- Insert the Micro SD card with the gold contacts facing down until it clicks into place.
- To remove, gently push the card in until it springs out.

4.3. Attaching the LCD Screen

The 2-inch TFT LCD screen is detachable. Align the connectors on the screen with the corresponding port on the back of the camera and gently push until it clicks into place. To remove, press the release button (if present) and slide the screen

off.

4.4. Using the Waterproof Housing

The included IP68 waterproof housing allows the camera to be used underwater up to 131 feet (40 meters).

1. Ensure the camera is clean and dry before placing it inside the housing.
2. Open the latch on the waterproof housing and carefully insert the camera.
3. Close the latch firmly, ensuring a tight seal.
4. Before first use in water, it is recommended to test the housing without the camera inside to ensure it is watertight.



Image: The AEE S60 Plus Action Camera securely mounted on a chest harness, demonstrating a typical use case for capturing point-of-view footage during activities.

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off

- To power on: Press and hold the power/mode button (green button on the front) for a few seconds until the indicator lights illuminate and the screen turns on.
- To power off: Press and hold the power/mode button again until the camera shuts down.

5.2. Mode Selection

Briefly press the power/mode button to cycle through different modes: Video Recording, Photo Capture, Burst Photo, and Time-Lapse. The current mode will be displayed on the LCD screen.

5.3. Recording Video / Capturing Photos

- In Video Recording mode, press the Shutter/OK button (top button) to start recording. Press again to stop.
- In Photo Capture mode, press the Shutter/OK button to take a single photo.
- For Burst Shooting, select the Burst mode and press the Shutter/OK button. The camera will capture multiple photos in quick succession (up to 8 photos/sec).
- For Time-Lapse, select the Time-Lapse mode and configure the interval settings in the menu. Press the Shutter/OK button to start/stop.

5.4. Wi-Fi Connectivity and Mobile App

The AEE S60 Plus features built-in Wi-Fi, allowing you to connect to a mobile device using the free AEE mobile application (available for iOS and Android).

1. Enable Wi-Fi on the camera through the settings menu.
2. On your mobile device, search for the camera's Wi-Fi network and connect to it.
3. Open the AEE mobile app. You can now preview your shot, control recording, adjust settings, and playback footage directly from your phone or tablet.

5.5. Advanced Features

- **Digital Zoom:** Utilize the zoom function through the camera's menu or mobile app to adjust your field of view.
- **180 Degree Image Flip:** This setting allows you to record footage upside down and have the camera automatically correct the orientation, useful for various mounting positions.
- **Viewing Angle:** The camera offers a wide 130-degree viewing angle, capturing more of the scene.

6. MAINTENANCE

6.1. Cleaning

- **Camera Body:** Use a soft, dry, lint-free cloth to wipe the camera body. For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals.
- **Lens:** Use a specialized lens cleaning cloth and lens cleaning solution. Gently wipe in a circular motion. Do not touch the lens with your fingers.
- **Waterproof Housing:** After use in saltwater, rinse the housing thoroughly with fresh water and allow it to air dry. Ensure no sand or debris is trapped in the seals.

6.2. Battery Care

- Store batteries in a cool, dry place.
- Avoid fully discharging the battery frequently.
- If storing for extended periods, charge the battery to about 50% capacity.

6.3. Storage

When not in use, store the camera and its accessories in a protective case or bag to prevent dust and damage. Remove the battery if storing for a long duration.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct polarity.
Cannot record video/take photos.	Micro SD card is full, corrupted, or not inserted.	Insert a Micro SD card. Format the card (this will erase all data). Delete unnecessary files to free up space.
Wi-Fi connection issues.	Wi-Fi not enabled on camera, incorrect password, or interference.	Ensure Wi-Fi is enabled on the camera. Re-enter the Wi-Fi password. Move closer to the camera. Restart both camera and mobile device.
Poor image/video quality.	Lens is dirty, low light conditions, or incorrect settings.	Clean the camera lens. Ensure adequate lighting. Check resolution and frame rate settings.
Camera freezes or becomes unresponsive.	Software glitch or battery issue.	Remove and reinsert the battery to perform a hard reset. Ensure firmware is up to date (check AEE website).

8. SPECIFICATIONS

Feature	Detail
Model	S60 Plus
Video Resolution	1080P at 60FPS, 720P at 120FPS (slow-motion)
Photo Resolution	16 MP, 12 MP, 5 MP
Viewing Angle	Up to 130 degrees
Digital Zoom	10X
Display	Detachable 2-inch TFT LCD Screen
Waterproof Depth	Up to 131 ft (40 meters) with housing
Storage	Supports Micro SD card up to 64GB
Connectivity	Wi-Fi, USB (Mini 10-pin)
Battery Capacity	1250mAh Lithium Ion
Recording Time	Up to 3 hours (approx.)
Dimensions (Camera only)	Approx. 1.25 inches thin profile
Weight (Camera only)	Approx. 0.16 lbs (72.5 grams)
Video Format	MP4




Feature	Detail
Audio Format	WAV
Photo Sensor Technology	CMOS
Maximum Aperture	F2.4




9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries regarding your AEE S60 Plus Action Camera, please refer to the warranty card included in your product packaging or visit the official AEE Technology website. You may also contact AEE customer support directly for assistance.

Please retain your proof of purchase for any warranty claims.

Related Documents - S60 Plus

	<p>AEE S60 Plus User Manual</p> <p>This user manual provides comprehensive instructions for the AEE S60 Plus action camera, covering setup, operation, video modes, photo modes, settings, and specifications. It guides users on how to effectively capture high-definition photos and videos.</p>
	<p>AEE S60 Plus Action Camera User Manual Setup, Features, and Specifications</p> <p>Explore the AEE S60 Plus action camera with its official user manual. Learn about setup, video/photo modes, settings, and accessories. Ideal for capturing adventures. Visit www.aeeusa.com for support.</p>
	<p>AEE Lyfe Silver User Manual: Features, Operation, and Specifications</p> <p>Comprehensive user manual for the AEE Lyfe Silver action camera, covering setup, operation modes, specifications, data transfer, troubleshooting, and FCC compliance.</p>

	<p>AEE Unmanned Aircraft System: Gimbal, Payload Mount, Battery, and Remote Control Installation & Removal Guide</p> <p>Detailed instructions for installing and removing the gimbal, payload mount, smart battery, and remote control for the AEE Unmanned Aircraft System. Includes step-by-step guidance and safety notes.</p>
	<p>Mokacam Alpha S Action Camera User Manual</p> <p>User manual for the Mokacam Alpha S action camera, covering setup, features, photo and video modes, settings, and troubleshooting.</p>
	<p>AEE TORUK AP10 User Manual: Comprehensive Guide to Aerial Photography</p> <p>Detailed user manual for the AEE TORUK AP10 drone, covering setup, flight operations, camera functions, safety, and troubleshooting for aerial photography enthusiasts.</p>

Documents - AEE – S60 Plus



[AEE S60 Plus Action Camera User Manual | Setup, Features, and Specifications](#)

Explore the AEE S60 Plus action camera with its official user manual. Learn about setup, video/photo modes, settings, and accessories. Ideal for capturing adventures. Visit www.aeeusa.com for support.

lang:es score:44 filesize: 13.42 M page_count: 67 document date: 2017-03-18



[\[pdf\] User Manual Accessories](#)

AEE S60 PLUS 01 MANUAL drive google uc id 1DwAeD2Ksm YGSFCKIxMSc3ccpOSNx2OV export |||

S60 Plus USER MANUAL This Manual is applicable to AEE camera**S60 Plus**.

Please note that the camera and accessories you have received may slightly vary with descriptions in this Manual due to technological innovation. If you have any question, please contact us. www.aeeusa.com L1 1 L2 ...


lang:i-klngon score:37 filesize: 13.95 M page_count: 67 document date: 2015-07-30



[AEE S60 Plus User Manual](#)

This user manual provides comprehensive instructions for the AEE S60 Plus action camera, covering setup, operation, video modes, photo modes, settings, and specifications. It guides users on how to effectively capture high-definition photos and videos.


lang:i-klngon score:36 filesize: 14.45 M page_count: 67 document date: 2023-09-07



[\[pdf\] User Manual Accessories](#)

USER MANUAL images na ssl amazon This Manual is applicable to AEE camera S40 Pro Doesn't support Wi-Fi S50 and S60 Plus Please note that the accessories you have received may slightly vary with descriptions in this due technological innovation If any question please contact us D1k4uSTYHQS I USER MANUAL This Manual is applicable to AEE camera S40 Pro Doesn't support Wi-Fi , S50 Pro and **S60 Plus**. Please note that the camera and accessories you have received may slightly vary with descriptions in this Manual due to technological innovation. If you have any question, please contact us. ...


lang:i-klngon score:30 filesize: 8.13 M page_count: 29 document date: 2015-11-11



[\[pdf\] User Manual](#)

AEE S60 PLUS 02 MANUAL drive google u 0 uc id 1XFB3zcb7CeBSGYUkJfh b0Anp0Z6BE5l export ||| 1 2 3 4 7 8 9 10 11 12 13 14 15 16 5 6 17 18 19 20 21 22 23 24 25 ...


lang:i-klngon score:23 filesize: 1.69 M page_count: 2 document date: 2015-07-24



[\[pdf\] Agent Authorization](#)


Authorization letter Shenzhen AEE Aviation Technology Co Ltd AEECAMERA01 Action Camcorder 2AGZG 2AGZGAEECAMERA01 aeecamera01
Tel: 408-526-1188 Fax: 408-526-1088 Email: TCB siemic.com 775 Montague Expressway Milpitas, CA 9503 ... e name: AEE FCC ID: 2AGZG-AEECAMERA01 Model Name: S41B, S41B ,S41B Pro,S41C,S41C ,S41C Pro, S50 Pro,**S60 Plus**, S50 Sincerely, Signature Peng Liang / Manager E-mail: plan04 aee.com Phone: 0755-295...

lang:en score:19 filesize: 214.86 K page_count: 2 document date: 2016-09-05




[pdf] Agent Authorization

Authorization letter Shenzhen AEE Aviation Technology Co Ltd AEES6070001 Action Camcorder 2AGZG 2AGZGAEES6070001 aees6070oo1
Tel: 408-526-1188 Fax: 408-526-1088 Email: TCB siemic.com 775 Montague Expressway Milpitas, CA 9503 ... corder FCC ID: 2AGZG-AEES6070001 Model Name: S77,S71,S60,S60T,S61,S71T,S72,S75, S70 Plus, S71 Plus, **S60 Plus**, S60T Plus, S61 Plus, S71T Plus, S72 Plus, S75 Plus, S70T Plus, S70T Pro,S71Touch ,S71T Pro...
lang:en score:19 filesize: 210.04 K page_count: 2 document date: 2016-09-21




[pdf] Agent Authorization

Authorization letter Shenzhen AEE Aviation Technology Co Ltd AEE70710001 Action Camcorder 2AGZG 2AGZGAE70710001 aee70710001
Tel: 408-526-1188 Fax: 408-526-1088 Email: TCB siemic.com 775 Montague Expressway Milpitas, CA 9503 ... corder FCC ID: 2AGZG-AEE70710001 Model Name: S70,S71,S60,S60T,S61,S71T,S72,S75, S70 Plus, S71 Plus, **S60 Plus**, S60T Plus, S61 Plus, S71T Plus, S72 Plus, S75 Plus, S70T Plus, S70T Pro,S71Touch ,S71T Pro...
lang:en score:19 filesize: 98.44 K page_count: 2 document date: 2017-02-21




[pdf] Declaration of Conformity

Family models declaration letter junexie model Shenzhen AEE Aviation Technology Co Ltd AEES6070001 Action Camcorder 2AGZG 2AGZGAEES6070001 aees6070oo1
Shenzhen AEE Aviation Technology Co.,Ltd. Family models declaration letter. 2016-9-21 We Shenzhen AE ... corder FCC ID: 2AGZG-AEES6070001 Model Name: S77,S71,S60,S60T,S61,S71T,S72,S75, S70 Plus, S71 Plus, **S60 Plus**, S60T Plus, S61 Plus, S71T Plus, S72 Plus, S75 Plus, S70T Plus, S70T Pro,S71Touch ,S71T Pro...
lang:tl score:19 filesize: 159.84 K page_count: 1 document date: 2016-09-21




[pdf] Decleration of Conformity

Family models declaration letter junexie model Shenzhen AEE Aviation Technology Co Ltd AEE70710001
Action Camcorder 2AGZG 2AGZGAEE70710001 aee70710001
Shenzhen AEE Aviation Technology Co.,Ltd. Family models declaration letter. 2017-02-21 We Shenzhen A ... corder FCC ID: 2AGZG-AEE70710001 Model Name: S70,S71,S60,S60T,S61,S71T,S72,S75, S70 Plus, S71 Plus, **S60 Plus**, S60T Plus, S61 Plus, S71T Plus, S72 Plus, S75 Plus, S70T Plus, S70T Pro, S71Touch ,S71T Pr...
lang:tl score:19 filesize: 116.27 K page_count: 1 document date: 2017-02-21




[pdf] Decleration of Conformity

Family models declaration letter junexie model Shenzhen AEE Aviation Technology Co Ltd
AEECAMERA01 Action Camcorder 2AGZG 2AGZGAEECAMERA01 aeecamera01
Shenzhen AEE Aviation Technology Co.,Ltd. Family models declaration letter. 2016-9-12 We TRI PLUS GRUPA D.O.O. Of Shenzhen AEE Aviation Technology Co.,Ltd. Product: Action Camcorder FCC ID: 2AGZG-AEECAMERA01 Model Name: S41B ,S41B ,S41B Pro,S41C,S41C ,S41C Pro, S50 Pro,**S60 Plus**, S50 Trade mark: AEE ...
lang:tl score:18 filesize: 163.56 K page_count: 1 document date: 2016-09-12



[pdf] User Manual Accessories

camera video pentru sportivi aee s40 pro spy shop ro media custom upload |||
USER MANUAL This Manual is applicable to AEE camera S40 Pro Doesn t support Wi-Fi , S50 Pro and **S60 Plus**. Please note that the camera and accessories you have received may slightly vary with descriptions in this Manual due to technological innovation. If you have any question, please contact us. ...
lang:i-klnglon score:18 filesize: 7.17 M page_count: 28 document date: 2015-08-12



[pdf] Declaration of Conformity

Microsoft Word Model difference letter doc Administrator Family models Shenzhen AEE Technology CO


LTD AEECAMERA01 Action Camcorder YVV YVVAEECAMERA01 aeecamera01

Shenzhen AEE Technology Co., Ltd. Model Difference FCC ID: YVV-AEECAMERA01

Model : S41B ,S41B ,S41B Pro,S41C,S41C ,S41C Pro,S50 Pro,**S60 Plus** All the model are the same circuit and RF module, except the model name and colour.

Regards, Client s signature Signature Client s name / title : Leo chen / Se...

lang:i-klngon **score:18** filesize: 74.63 K page_count: 1 document date: 2015-07-08



[pdf] Declaration of Conformity


Microsoft Word Model difference letter doc Administrator Family Models Letter Shenzhen AEE

Technology CO LTD AEES6070001 Action Camcorder YVV YVVAEES6070001 aeess6070oo1

Shenzhen AEE Technology Co., Ltd. Model Difference FCC ID: YVV-AEES6070001

Model : S70, S71,S60,S60T,S61,S71T,S72,S75, S70 Plus, S71 Plus, **S60 Plus**, S60T Plus, S61 Plus, S71T Plus, S72 Plus, S75 Plus, S70T Plus, S70T Pro, S71Touch ,S71T Pro All the model are the same circuit and RF module, except th...

lang:nl **score:18** filesize: 53.38 K page_count: 1 document date: 2015-08-05



[pdf] Declaration of Conformity Agent Authorization

Microsoft Word SCS F18 Product Certification Representative Auth Letter Ver 5 0 doc Administrator POA

Shenzhen AEE Technology CO LTD AEECAMERA01 Action Camcorder YVV YVVAEECAMERA01

aeecamera01


775 Montague Expressway Milpitas, CA 95035 Tel: 408-526-1188 Fax: 408-526-1088

Email: TCB siemic.com ... n Camcorder Trade Name AEE Model Name S41B Serial

Model S41B ,S41B Pro,S41C,S41C ,S41C S50 Pro,**S60 Plus** Pro, FCC ID YVV-

AEECAMERA01 Sincerely, Signature Client s name / title : Leo chen / Sen...


lang:en **score:18** filesize: 43.98 K page_count: 2 document date: 2015-07-08



[pdf] Declaration of Conformity Agent Authorization

Microsoft Word SCS F18 Product Certification Representative Auth Letter Ver 5 0 doc Administrator
Authorization Shenzhen AEE Technology CO LTD AEES6070001 Action Camcorder YVV
YVVAEES6070001 aeess60700o1

775 Montague Expressway Milpitas, CA 95035 Tel: 408-526-1188 Fax: 408-526-1088
Email: TCB siemic.com ... AEE Model Name S70 S71,S60,S60T,S61,S71T,S72,S75,
Serial Model S70 S61 Plus, Plus, S71 Plus, **S60 Plus**, S60T S71T Plus, S72 Plus,
S75 Plus, Plus, S70T Plus, S70T Pro,S71Touch ,S71T Pro FCC ID...
lang:en score:18 filesize: 44.13 K page_count: 2 document date: 2015-08-05



[pdf] Declaration of Conformity Test Report

Microsoft Word Test report FCC 247 WIFI doc Administrator Shenzhen AEE Technology CO LTD
AEECAMERA01 Action Camcorder YVV YVVAEECAMERA01 aeecamera01

FCC RADIO TEST REPORT FCC ID: YVV-AEECAMERA01 Product Action
Camcorder Trade Name AEE Model Name S41B Serial Model S41B ,S41B
Pro,S41C,S41C ,S41C S50 Pro,**S60 Plus** Pro, Report No. NTEK-2015NT0608077F
Prepared for SHENZHEN AEE TECHNOLOGY CO., LTD. AEE Hi-Tech Park,Tangtou
Crossroads,Shiyan To...
lang:en score:17 filesize: 864.41 K page_count: 51 document date: 2015-07-08



[pdf]

S60 1 pnj fr 2017 06 D EMPLOI Aii AMS |||
Aii AMS . SHDOTYOUR ADRINALINI MODE D EMPLOI AEE S60 AEE.COM
Sommaire Prcautions..... ... d utiliser la camra et conservez-le pour consultation
ultrieuire. Ce manuel concerne les camras AEE **S60 Plus**. Veuillez noter que la camra
et les accessoires que vous avez reus peuvent lgrement varier ...
lang:fr score:10 filesize: 1.02 M page_count: 27 document date: 2016-12-09

