

FORSINING WR70

FORSINING WR70 Automatic Watch User Manual

Model: WR70

INTRODUCTION

Thank you for choosing the FORSINING WR70 Automatic Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.

The FORSINING WR70 is a men's luxury automatic watch featuring a stainless steel construction, a complete calendar, and a 21-jewel automatic movement with a tourbillon design on the dial.



Image: Front view of the FORSINING WR70 Automatic Watch, showcasing its gold-tone stainless steel case and band, and intricate dial design.

SETUP AND INITIAL WINDING

Your FORSINING WR70 watch is powered by an automatic mechanical movement, meaning it does not require a battery. It powers automatically with the movement of your arm. For initial setup or if the watch has stopped, follow these steps:

1. **Initial Winding:** To start the watch, gently hand-wind the crown clockwise approximately 15 full turns. This builds up the initial power reserve.
2. **Setting the Time:** Pull the crown out to the furthest position. Turn the crown to set the hour and minute hands to the correct time. Push the crown back in to secure the setting.
3. **Setting the Date:** Pull the crown out to the middle position. Turn the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is engaged and could cause damage. Push the crown back in after setting.



Image: Side view of the FORSINING WR70 Automatic Watch, highlighting the crown and pushers used for setting time and date.

OPERATING YOUR AUTOMATIC WATCH

Once initially wound, your watch will continue to operate as long as it is worn regularly. The movement of your arm keeps the mainspring wound.

- **Daily Wear:** If you wear the watch for more than 10 hours each day, extra winding will generally not be necessary.
- **Power Reserve:** If the watch is not worn for an extended period, it may stop. Simply hand-wind it again as

described in the 'Setup' section to restart it.

- **Calendar Function:** The watch features a complete calendar. All small arrows and sub-dials on the watch face are functional and display calendar information.



Image: Back view of the FORSINING WR70 Automatic Watch, revealing the intricate mechanical automatic movement through the transparent caseback.

CARE AND MAINTENANCE

Proper care will help preserve the appearance and function of your FORSINING WR70 watch.

- **Water Resistance:** This watch features a water-resistant structure. However, it is **not suitable for swimming, diving, showering, or any activities involving immersion in water**. Exposure to excessive moisture or direct water jets can cause damage.
- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth to remove dirt and perspiration. For

stainless steel, a slightly damp cloth can be used, followed by immediate drying.

- **Temperature Extremes:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement's accuracy and seals.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones), which can temporarily affect the accuracy of mechanical watches.
- **Impact:** Avoid dropping the watch or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter issues with your watch, consider the following common solutions:

- **Watch Not Running:** Ensure the watch has been sufficiently wound. Hand-wind the crown 15-20 times, then wear it for several hours to build up the power reserve.
- **Time or Date Incorrect:** Reset the time and date as described in the 'Setup' section. Ensure the crown is fully pushed in after setting.
- **Inaccurate Timekeeping:** Mechanical watches can vary slightly in accuracy. If the watch is consistently gaining or losing significant time, ensure it is fully wound and has not been exposed to strong magnetic fields. If the problem persists, contact customer support.

SPECIFICATIONS

Brand	FORSINING
Model Name	WR70
Movement Type	Chinese Automatic Mechanical (21-Jewels)
Display Type	Analog
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	46 millimeters
Case Thickness	15.2 millimeters
Band Width	20 millimeters
Band Length	18 centimeters
Crystal Material	Hardlex Mineral
Water Resistance Level	Water Resistant (Not suitable for immersion)
Clasp Type	Buckle
Item Weight	0.15 kg (5.29 ounces)

WARRANTY INFORMATION

Your FORSINING WR70 watch comes with a warranty. Please refer to the specific warranty terms provided at the

time of purchase or contact the seller for details.

- **General Warranty:** A 2-year warranty is typically offered for manufacturing defects.
- **Contact Seller:** For all warranty claims and inquiries, please contact the seller of record directly.

CUSTOMER SUPPORT

For further assistance, technical support, or any questions regarding your FORSINING WR70 watch, please contact FORSINING customer service or the seller from whom you purchased the product.

You can visit the official FORSINING store for more information:[FORSINING Store](#)

© 2023 FORSINING. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question