



Manuals.plus /

› iHome /

› iHome Kineta Dual Charging Stereo Alarm White

## iHome IH-IKN95-WH

# iHome Kineta Dual Charging Stereo Alarm User Manual

Model: IH-IKN95-WH

Brand: iHome

## INTRODUCTION

---

The iHome Kineta Dual Charging Stereo Alarm is a versatile device designed to enhance your daily routine with audio and charging capabilities. It features Bluetooth connectivity for wireless music streaming, an FM radio, and multiple alarm options. Additionally, it provides convenient charging for your mobile devices via a USB port and a removable K-CELL battery pack.

This manual provides detailed instructions for setting up, operating, and maintaining your iHome Kineta unit to ensure optimal performance and longevity.

## PACKAGE CONTENTS

---

- iHome Kineta Dual Charging Stereo Alarm Unit
- AC Adapter
- *Note: Charging cable for mobile devices is not included.*

Please ensure all components are present before proceeding with setup.

## SETUP GUIDE

---

### 1. Power Connection

1. Connect the supplied AC adapter to the DC jack located on the back of the iHome Kineta unit.
2. Plug the AC adapter into a standard wall outlet.
3. The unit will power on and the display will illuminate.

### 2. Initial Time Setting

Upon first power-up, the time display may flash. Refer to the "Operating Instructions" section for detailed steps on setting the current time and date.

### 3. K-CELL Battery Pack (Optional)

The iHome Kineta includes a removable K-CELL battery pack for portable charging. To charge the K-CELL:

- Ensure the K-CELL is properly inserted into its designated slot on the unit.
- When the unit is connected to AC power, the K-CELL will charge automatically.
- A battery level indicator on the unit will show the charging status.



Figure 1: Front view of the iHome Kineta Dual Charging Stereo Alarm. The image displays the white unit with a large digital clock showing "10:09 PM" and a charging slot on the left side. The speaker grille covers the front face.

## OPERATING INSTRUCTIONS

### 1. Bluetooth Pairing

1. Press the **Bluetooth button** on the unit to enter pairing mode. The Bluetooth indicator will flash.
2. On your mobile device (iPad, iPhone, iPod touch, Android, Windows, etc.), enable Bluetooth and search for available devices.
3. Select "iHome Kineta" from the list of devices.
4. Once paired, the Bluetooth indicator will glow solid, and you can stream audio wirelessly.
5. **NFC Pairing:** For devices with NFC (Near Field Communication), simply tap your NFC-enabled device to the NFC tag area on the iHome Kineta for instant Bluetooth setup.

### 2. FM Radio Operation

1. Press the **FM button** to switch to FM radio mode.

2. Use the **Tune +/- buttons** to manually tune to a desired station.
3. Press and hold the **Tune +/- buttons** to auto-scan for the next available station.
4. To save a preset station, press and hold the **Preset button**, then use the **Tune +/- buttons** to select a preset number, and press **Preset** again to confirm.

### 3. Setting Alarms

1. Press and hold the **Alarm 1** or **Alarm 2 button** to enter alarm setting mode.
2. Use the **Time +/- buttons** to set the desired alarm time.
3. Press the **Alarm button** again to select the alarm source (Bluetooth audio, FM radio, built-in tones, or buzzer).
4. Continue pressing the **Alarm button** to cycle through other alarm settings like alarm volume and daily/weekday/weekend modes.
5. Press the **Alarm button** one last time or wait for the display to stop flashing to save settings.
6. To activate/deactivate an alarm, press the corresponding **Alarm button** briefly. An alarm icon will appear/disappear on the display.

### 4. Charging Mobile Devices

- Connect your mobile device's charging cable (not included) to the USB port on the iHome Kineta unit.
- Your device will begin charging.
- The removable K-CELL battery pack can also be used to charge devices when detached from the main unit, provided it is charged.

## MAINTENANCE

---

### Cleaning the Unit

- Always unplug the unit from the power source before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, abrasive cleaners, or sprays, as these may damage the finish or internal components.
- Keep the unit away from excessive moisture or extreme temperatures.

### K-CELL Battery Care

- For optimal battery life, avoid fully discharging the K-CELL frequently.
- If the unit will not be used for an extended period, fully charge the K-CELL before storage.
- Do not expose the K-CELL to extreme heat or direct sunlight.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Unit does not power on.	AC adapter not connected or faulty outlet.	Ensure AC adapter is securely plugged into the unit and a working wall outlet. Try a different outlet.
Bluetooth device will not pair.	Bluetooth not enabled on device; unit not in pairing mode; device too far.	Ensure Bluetooth is enabled on your device. Press the Bluetooth button on the unit to enter pairing mode. Move device closer to the unit.
Poor FM radio reception.	Weak signal; interference.	Adjust the unit's position to improve reception. Keep away from other electronic devices that may cause interference.
Alarm does not sound.	Alarm not activated; volume too low; incorrect alarm time.	Verify the alarm icon is displayed. Increase alarm volume. Check that the alarm time is set correctly.
Mobile device not charging.	Charging cable faulty; K-CELL discharged; device not compatible.	Try a different charging cable. Ensure K-CELL is charged or unit is on AC power. Confirm device compatibility with USB charging.

## SPECIFICATIONS

**Brand:** iHome

**Model Number:** IH-IKN95-WH

**Color:** White

**Display Type:** Digital

**Special Feature:** Radio

**Power Source:** Battery Powered (K-CELL) / Electrical (AC Adapter)

**Material:** Metal

**Item Weight:** 1.2 Pounds

**Product Dimensions:** 12.3 x 10.1 x 6.2 inches

**UPC:** 047532908725

## WARRANTY AND SUPPORT

For warranty information and technical support, please visit the official iHome website or contact their customer service department. Keep your purchase receipt as proof of purchase.

You can find more information and support resources by visiting the iHome Store on Amazon.