

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

SoundMAGIC E80

SoundMAGIC E80 Wired Earbuds Instruction Manual

Model: E80

Brand: SoundMAGIC

INTRODUCTION

The SoundMAGIC E80 wired earbuds are designed to deliver high-fidelity audio with a focus on detailed sound reproduction and robust construction. These in-ear headphones feature a durable metal housing, a high-quality twisted cable, and an ergonomic design for comfortable wear and effective noise isolation. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your E80 earbuds.



Image: SoundMAGIC E80 wired earbuds, showcasing the red and black design with the 3.5mm audio jack.

SETUP

1. Unboxing and Included Accessories

Upon opening the SoundMAGIC E80 package, ensure all components are present. The standard package includes:

- SoundMAGIC E80 Earbuds
- Various sizes of silicone ear tips (S/M/L)
- Double flange silicone ear tips
- Foam ear tips (S/M/L)
- Cable clip

- Carrying hardcase



Image: Front view of the SoundMAGIC E80 earbud product box, displaying the earbuds and key features.



Image: Side view of the SoundMAGIC E80 earbud product box, showing a diagram of the earbud cable and plug.




Image: A visual representation of the SoundMAGIC E80 earbuds and their included accessories, such as different ear tip sizes, a cable clip, and a hard carrying case.

2. Ear Tip Selection and Fitting

Proper ear tip selection is crucial for optimal sound quality and comfort, as well as effective noise isolation. Experiment

with the different sizes and types of ear tips provided to find the best fit for your ears.

1. Gently pull the existing ear tip off the earbud nozzle.
2. Select a new ear tip size (Small, Medium, or Large) and material (silicone or foam).
3. Carefully push the new ear tip onto the earbud nozzle until it is securely seated.
4. Insert the earbuds into your ears. The fit should feel snug and comfortable, creating a seal that blocks out external noise. If the sound is thin or lacks bass, try a larger ear tip. If they feel uncomfortable or fall out easily, try a smaller size.



Image: A diagram illustrating the dimensions of the E80 earbuds and how they sit comfortably in the ear, emphasizing light weight and good noise isolation. A person is shown wearing the earbuds correctly.

3. Connecting to Your Device

The SoundMAGIC E80 earbuds feature a standard 3.5mm audio jack for universal compatibility.

- Locate the 3.5mm audio port on your smartphone, tablet, laptop, MP3 player, or other compatible audio device.
- Insert the 3.5mm jack of the E80 earbuds firmly into the audio port until it clicks into place.

- Ensure the connection is secure to prevent audio interruptions or poor sound quality.



Image: A detailed view of the SoundMAGIC E80 earbuds, highlighting the 3.5mm gold-plated audio jack designed for a secure and clear connection.

OPERATING INSTRUCTIONS

1. Audio Playback

Once connected, your SoundMAGIC E80 earbuds will play audio from your device. Start playing music, podcasts, or any other audio content on your connected device.



Image: Individuals wearing SoundMAGIC E80 earbuds, demonstrating typical use for enjoying music or other audio content.

2. Volume Control

The SoundMAGIC E80 earbuds do not feature inline volume controls. Adjust the audio volume directly on your connected playback device (smartphone, tablet, computer, etc.).

3. Noise Isolation

The ergonomic design and proper ear tip fit of the E80 earbuds provide passive noise isolation. This reduces ambient noise, allowing for a more immersive listening experience. Ensure a good seal with your ear canal for the best noise isolation performance.

MAINTENANCE

1. Cleaning Your Earbuds

Regular cleaning helps maintain hygiene and sound quality.

- **Ear Tips:** Remove the ear tips from the earbuds. Wipe them gently with a soft, damp cloth. For silicone tips, you can rinse them with lukewarm water and mild soap, then dry thoroughly before reattaching.
- **Earbud Nozzles:** Use a dry cotton swab or a small, soft brush to carefully remove any earwax or debris from the earbud nozzles. Be gentle to avoid pushing debris further inside.
- **Earbud Body and Cable:** Wipe the metal body and cable with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.

2. Storage

When not in use, store your SoundMAGIC E80 earbuds in the provided hard carrying case. This protects them from dust, dirt, and physical damage, especially the delicate drivers and cable.

3. Cable Care

The E80 features a high-quality twisted cable designed to be tangle-free and reduce radio interference. To prolong its lifespan:

- Avoid sharp bends or kinks in the cable.
- Do not pull the cable forcefully when disconnecting from a device; always grasp the 3.5mm jack.
- Use the included cable clip to manage excess cable length and prevent snagging during use.

High Quality Twisted Cable

No tangle, higher bending reliability and less radio interference




Image: An exploded view of the E80's high-quality twisted cable, detailing its internal structure with enamelled copper wire and Kevlar fiber, designed for durability and tangle resistance. It also shows the 60-degree angled plug.

TROUBLESHOOTING

If you encounter issues with your SoundMAGIC E80 earbuds, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound or sound from only one earbud.	Loose connection, incorrect audio output setting, debris in jack, faulty cable/earbud.	<p>Ensure the 3.5mm jack is fully inserted into the device's audio port.</p> <p>Test with another audio device to rule out device issues.</p> <p>Check your device's audio settings to ensure the correct output is selected and volume is up.</p> <p>Inspect the 3.5mm jack and device port for lint or debris.</p> <p>Gently twist the jack in the port to see if sound returns.</p>
Poor sound quality (e.g., weak bass, muffled sound).	Improper ear tip fit, earwax buildup, low-quality audio source.	<p>Try different sizes or types of ear tips to achieve a secure seal in your ear canal.</p> <p>Clean the earbud nozzles and ear tips as described in the Maintenance section.</p> <p>Ensure the audio source file or streaming quality is high.</p>
Earbuds fall out easily or are uncomfortable.	Incorrect ear tip size.	<p>Experiment with smaller or larger ear tips until you find a comfortable and secure fit.</p> <p>Ensure the earbuds are inserted correctly into your ear canal.</p>

If the issue persists after trying these steps, please contact SoundMAGIC customer support.

SPECIFICATIONS

Detailed technical specifications for the SoundMAGIC E80 Wired Earbuds:

Feature	Detail
Model Name	E80 RED
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Driver Type	Dynamic Driver
Driver Size	10 Millimeters
Frequency Response	2.2 Hz - 20,000 Hz
Impedance	64 Ohm
Sensitivity	102 dB
Noise Control	Sound Isolation

Feature	Detail
Material	Aluminum (earbud housing)
Cable Feature	Tangle Free, Twisting Core
Item Weight	13 Grams (0.459 ounces)
Product Dimensions	2.76 x 0.59 x 0.39 inches
Compatible Devices	Smartphones, tablets, laptops, MP3 players
Manufacturer	SoundMAGIC
Color	Red

10 mm High Quality Full Range Dynamic Driver

To offer large dynamic and very detail music




Image: An exploded diagram illustrating the components of the 10mm high-quality full range dynamic driver, including the NdFeB magnet and 6um vibrating diaphragm, designed for detailed music reproduction.

Professional Sound Quality Tuning

Meet the demands of people who pursue the ultimate delicacy of music.




Image: A frequency response graph demonstrating the professional sound quality tuning of the SoundMAGIC E80 earbuds, showing the balanced audio output across the frequency spectrum.

Aluminium Construction For Durable

Precision parts manufacturing and rigorous assembly process to ensure stable product quality



Image: An exploded view illustrating the robust aluminum construction of the E80 earbud housing, highlighting the precision parts manufacturing for stable product quality.

WARRANTY AND SUPPORT

Warranty Information

SoundMAGIC products are manufactured to high quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official SoundMAGIC website. Keep your proof of

purchase for warranty claims.

Customer Support

If you have any questions, require technical assistance, or need to make a warranty claim, please contact SoundMAGIC customer support through their official channels. You can find more information and contact details on the official SoundMAGIC website:

www.soundmagic.com.cn

For general inquiries or to explore other SoundMAGIC products, you may also visit the SoundMAGIC store on Amazon: [SoundMAGIC Amazon Store](#).

© 2023 SoundMAGIC. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

	<p>SoundMAGIC T80BT ANC Wireless Noise Canceling Headphones User Manual</p> <p>Comprehensive user manual for the SoundMAGIC T80BT ANC wireless noise-canceling in-ear headphones, covering setup, operation, features like ANC and ambient sound modes, troubleshooting, and technical specifications.</p>
	<p>SoundMAGIC T60BT True Wireless Earphones User Manual</p> <p>This user manual provides instructions for the SoundMAGIC T60BT True Wireless Earphones, covering setup, operation, features, troubleshooting, and specifications. Learn how to pair, play music, manage calls, and charge your T60BT earphones.</p>



[pdf] User Manual Guide

Mariusz Bartnicki soundmagic e80 guide PL manual superata

INSTRUKCJA OBSŁUGI SŁUCHAWKI PRZEWODOWE DOUSZNE

SoundMAGIC **E80** www.soundmagic.pl V1.0 rodki ostronoci 1. Stosuj odpowiedni poziom głośności aby chronić słuch. 2. Nie używaj i nie przechowuj słuchawek w skrajnie wilgotnym otoczeniu. 3. Dla własnego bezpieczeństwa nie używaj słuchawek w niebezpiecznym r...

lang:pl score:59 filesize: 471.45 K page_count: 4 document date: 2019-09-17




[pdf] Catalog

Experience entertainment like never before with Sony's new *lowest Price Guaranteed We'll beat any genuine advertised price voucher offer or system deal online in store by up to £100! L 3 Products must be brand a similar guarantee and stock rs catalogue richersounds media £3499 Richer Sounds The A1 is really quite impressive this one of the most exciting TVs 2017 it clear that has made something pleasure behold

FREE Valid until 09/06/17 Issue 524 Experience entertainment like never before with Sony's new 4K ... n a Sony UBXP800 4K Blu-ray player worth 399 with this TV. Sony 49 4K HDR Smart LED TV Bravia KD49X**E8004** Sony's picture technology combines with Android TV's Smart operating system to create a fantas...

lang:en score:8 filesize: 5.48 M page_count: 32 document date: 2017-04-28



[pdf]

Natalia Mordaka regulamin k 842 rtv male agd nawet 2500zł taniej mediaexpert pl lp regulaminy ||| Regulamin promocji „Zyskaj nawet 2500 zł rabatu za zakup RTV i AGD male kody rabatowe 1 Definicje ... zaink SMEG KLF01CREU Kremowy 178736 Czajnik SMEG KLF01SSEU Chrom 838579 Radio internetowe PHILIPS **AE8000** DAB /WIFI 838597 Główny mobilny MANTA SPK 204FM 855164 Słuchawki nauszne MARSHALL Major II z m...

lang:pl score:8 filesize: 1.1 M page_count: 72 document date: 2018-08-29

