

Manuals.plus /

› CROFTON /

› CROFTON Stainless Steel Pineapple Slicer Instruction Manual

## CROFTON Pineapple Slicer

# CROFTON Stainless Steel Pineapple Slicer

Instruction Manual

## INTRODUCTION

---

Thank you for choosing the CROFTON Stainless Steel Pineapple Slicer. This manual provides essential information for the safe and efficient use of your new kitchen tool. Please read these instructions carefully before first use and retain them for future reference.



Image: The Crofton Stainless Steel Pineapple Slicer, featuring its ergonomic yellow handle and durable stainless steel coring blade.

## SAFETY INFORMATION

---

- **Sharp Blade:** The slicer features a sharp blade. Handle with care to prevent injury.
- **Adult Use:** This product is intended for adult use. Keep out of reach of children.
- **Proper Use:** Use only for its intended purpose of slicing pineapples. Do not use for other fruits or vegetables.
- **Inspection:** Before each use, inspect the slicer for any damage. Do not use if damaged.
- **Cleaning:** Always clean the slicer immediately after use to prevent food residue buildup.

## PACKAGE CONTENTS

---

- 1 x CROFTON Stainless Steel Pineapple Slicer

## SETUP

---

Before using the pineapple slicer, ensure both the slicer and the pineapple are clean and ready for preparation.

1. **Wash the Slicer:** Wash the pineapple slicer thoroughly with warm, soapy water before its first use and after each subsequent use. Rinse well and dry completely.
2. **Prepare the Pineapple:** Place the pineapple on a stable cutting surface. Using a sharp knife, carefully cut off the top crown and the bottom base of the pineapple. Ensure the pineapple can stand upright and is stable.
3. **Remove Outer Skin:** Carefully slice off the outer skin of the pineapple, working from top to bottom, following the natural curve of the fruit. Ensure all 'eyes' are removed.





Image: A detailed view of the Crofton Pineapple Slicer's stainless steel shaft and circular coring blade, ready for use.

## OPERATING INSTRUCTIONS

---

Follow these steps to efficiently core and slice your pineapple:

1. **Position the Slicer:** Place the center of the slicer's blade over the center of the prepared pineapple.
2. **Apply Pressure and Twist:** Hold the pineapple firmly with one hand. With the other hand, apply gentle downward pressure on the slicer's handle while twisting it clockwise.
3. **Continue Twisting:** Continue twisting and pushing down until you reach the bottom of the pineapple, leaving approximately half an inch from the bottom to keep the shell intact.
4. **Pull Up:** Once you have reached the desired depth, pull the slicer upwards, bringing the cored and sliced pineapple rings with it.
5. **Remove Pineapple:** Detach the handle from the shaft by pressing the release buttons (if applicable to your model) or by pulling it off. Slide the pineapple rings off the shaft.
6. **Serve:** The pineapple is now cored and sliced into perfect rings, ready to be served or stored.



**CROFTON**

PINEAPPLE SLICER

• Rebanadora de piñas



AFTER SALES SUPPORT • SERVICIO POSVENTA

☎ 1800 685 5053 📧 [support@productconcern.com](mailto:support@productconcern.com)

PRODUCT CODE: 47649 06/2015

**2**

YEAR WARRANTY  
AÑOS DE GARANTIA

Image: The Crofton Pineapple Slicer, showcasing its full design with the yellow handle and stainless steel shaft, illustrating the tool's readiness for operation.

## MAINTENANCE AND CLEANING

---

Proper care ensures the longevity and hygiene of your pineapple slicer.

- **Immediate Cleaning:** Clean the slicer immediately after each use to prevent fruit acids from corroding the stainless steel and to avoid food residue drying on the blade.
- **Hand Washing:** Wash with warm, soapy water using a soft sponge or brush. Pay special attention to the blade area. Rinse thoroughly.
- **Dishwasher Safe:** The CROFTON Stainless Steel Pineapple Slicer is dishwasher safe. Place it on the top rack for best results.
- **Drying:** Dry the slicer completely after washing to prevent water spots and maintain its finish.
- **Storage:** Store the slicer in a dry place, away from moisture, and where the blade is protected to prevent accidental cuts.

## TROUBLESHOOTING

---

- **Difficulty Twisting:** If the slicer is hard to twist, ensure the pineapple is properly peeled and the core is centered. Apply steady, even pressure. A slightly riper pineapple may also be easier to slice.
- **Uneven Slices:** Ensure the slicer is centered over the pineapple's core before beginning. Maintain a straight downward motion while twisting.
- **Slicer Gets Stuck:** If the slicer gets stuck, gently twist it back and forth while applying upward pressure to free it. Do not force it, as this could damage the fruit or the slicer.
- **Pineapple Breaks Apart:** This can happen if the pineapple is overripe or if too much force is applied unevenly. Use a firm, ripe pineapple and maintain consistent pressure and twisting.

## SPECIFICATIONS

---

<b>Brand</b>	CROFTON
<b>Blade Material</b>	Stainless Steel
<b>Handle Material</b>	Stainless Steel
<b>Item Weight</b>	10.1 ounces
<b>Product Dimensions</b>	3.5 x 3.5 x 7.5 inches
<b>Dishwasher Safe</b>	Yes
<b>UPC</b>	784672327749
<b>ASIN</b>	B013CL88SO

## WARRANTY AND SUPPORT

---

Your CROFTON Stainless Steel Pineapple Slicer comes with **a2-Year Warranty** from the date of purchase, covering manufacturing defects under normal household use.

For after-sales support, product inquiries, or warranty claims, please contact:

**Phone:** 1-800-555-5057 (Example number, please refer to product packaging for actual contact)

**Email:** support@productconcern.com (Example email, please refer to product packaging for actual contact)

Please have your proof of purchase and product code (if available) ready when contacting support.