

[Manuals.plus](#) /

› [CronusMax](#) /

› CronusMax Plus 2017 with Add On Pack User Manual

CronusMax CronusMax Plus 2017

CronusMax Plus 2017 User Manual

Model: CronusMax Plus 2017

INTRODUCTION

The CronusMax Plus 2017 is a versatile gaming adapter designed to enhance your gaming experience by allowing the use of almost any controller on any console. It provides advanced features such as cross-over gaming, button remapping, and support for custom scripts, all with instant input response.





Image: Front packaging of the CronusMax Plus 2017 with Add On Pack, highlighting its ability to use any controller on any console.

Key Features

- **Universal Controller Compatibility:** Use your favorite controller (Xbox One, PS4, Xbox 360, PS3, Wii, Wii U Pro) on various consoles (Xbox One, PS4, Xbox 360, PS3) and Windows PC.
- **Keyboard & Mouse Support:** Play console games with PC gaming-grade keyboard and mouse using the X-AIM plugin.
- **Lag-Free Performance:** Experience instant controller input response without delay.
- **Button Remapping:** Customize and remap all controller buttons and triggers to any desired configuration.
- **Advanced Modding & Scripting:** Access millions of mod configurations and create custom combos, macros, and scripts using the GPC scripting language. Thousands of free scripts are available and updated daily.
- **Warranty Protection:** Using the CronusMax Plus does not void your console or controller warranty.
- **Undetectable Online:** Utilizes state-of-the-art stealth technology for online use.
- **Audio Support:** Supports in-platform PS4 chat and game audio via the included USB sound card. Xbox One chat requires a second controller or compatible wireless headset.
- **Force Feedback Support:** Now includes FANATEC and LOGITECH force feedback support on PS4.

USE ALMOST

ANY CONTROLLER ON ANY CONSOLE

Use your favorite controller or keyboard & mouse with most major consoles. Easy to use with simple to follow instructions.

XBOX One • PlayStation 4 • XBOX 360 • PlayStation 3 • PC Computers



FULLY MOD YOUR CONTROLLER

Fully mod your controller without voiding the warranty. Loaded with game packs for most major games or create your own. Millions of mod combinations!

Rapid Fire • Quick Scope • Drop Shot • Auto Run • Finishing Moves & More!

Game Packs: Black Ops III • Gears of War 4 • Battlefield 1 & Other Favorites!

COMPLETE FEATURE LIST

- Works with Playstation 4, Xbox One, PlayStation 3, Xbox 360 and Windows PC.
- Works with most major controllers including Xbox One, PS4, Xbox 360, PS3, Wii and Wii U Pro.
- Cross-Over capability. Example: Use a PlayStation 4 controller on your Xbox One, Xbox 360 or PS3.
- Lag-free. Instant response every time.
- Remap all controller buttons or triggers to any custom configuration.
- Game on your PS4, Xbox One, PS3 or Xbox 360 using your favorite PC gaming-grade keyboard and mouse using the powerful X-AIM plugin. PC Required!!
- Millions of mod configurations - No Combo Limit!
- Custom GPC scripting language - create your own combos, macros & mod scripts.
- 1000's of scripts available to download for free - updated daily!
- Does NOT void console or controller warranty.
- 100% undetectable online - state of the art stealth technology.
- Headsets and chat audio support varies by platform. PS4 chat and game audio supported via included USB sound card. XB1 chat requires 2nd controller or compatible wireless headset.



Image: Back packaging of the CronusMax Plus 2017, listing its complete feature set and compatibility.

PRODUCT OVERVIEW

The CronusMax Plus is a compact USB device that acts as an interface between your gaming controller and console. It features multiple ports and indicators for easy setup and operation.



Image: A close-up view of the CronusMax Plus device, showing its sleek black design and USB connectors.

Device Components



Image: A detailed diagram of the CronusMax Plus device, with key components labeled for easy identification.

1. **Input (1):** USB-A female port for connecting your controller or USB hub.
2. **Output (2):** USB-A male connector for plugging into your console or PC.
3. **Memory Slot Button (3):** Used to cycle through stored game packs/scripts.
4. **LED Display (4):** Numeric display showing the active memory slot or status codes.
5. **PC Prog USB Port (5):** Micro-USB port for connecting to a PC for programming and firmware updates.
6. **Reset Button (6):** Small button for resetting the device.
7. **Backlight Ring RGB LED (7):** Illuminates to indicate device status and active profile.

Included Accessories

The CronusMax Plus 2017 with Add On Pack includes a USB sound card for enhanced audio compatibility.



Image: The included 3.5mm audio jack cable, which functions as a USB sound card for audio passthrough.

SETUP GUIDE

Before using your CronusMax Plus, it is recommended to update its firmware and configure it using the official software on a PC. Detailed instructions and software downloads are available on the official CronusMax website.

Initial Setup Steps:

1. **Download Software:** Visit the official CronusMax website and download the latest CronusPro software and firmware.
2. **Connect to PC:** Connect the CronusMax Plus to your PC using the PC Prog USB Port (5).
3. **Update Firmware:** Follow the instructions in the CronusPro software to update the device firmware to the latest version.
4. **Configure Device:** Use CronusPro to configure your desired controller profiles, button remappings, and load game packs or custom scripts onto the device's memory slots.

Connecting to Console/PC:

1. Plug the CronusMax Plus Output (2) into a free USB port on your console (PS4, Xbox One, PS3, Xbox 360) or PC.
2. Connect your desired controller to the CronusMax Plus Input (1) port. For wireless controllers, ensure they are properly paired or connected via a compatible USB adapter (sold separately for some controllers).
3. If using a USB hub for multiple devices (e.g., keyboard and mouse, or multiple controllers), connect the hub to the Input (1) port and then connect your peripherals to the hub.
4. For PS4 chat and game audio, connect the included USB sound card to a free USB port on your console, and then plug your headset into the sound card.
5. For Xbox One chat, a second authorized Xbox One controller or a compatible wireless headset connected directly to the console may be required for chat functionality.

OPERATING INSTRUCTIONS

Selecting Memory Slots:

The CronusMax Plus can store up to 10 different game packs or scripts in its memory slots (0-9). To switch between them:

- Press the Memory Slot Button (3) on the device.
- The LED Display (4) will show the current active memory slot number. Continue pressing to cycle through the available slots.
- Once the desired slot is displayed, release the button. The device will activate the selected profile.

Using Keyboard and Mouse (X-AIM):

To use a keyboard and mouse on your console, the CronusMax Plus requires a PC connection running the X-AIM plugin within CronusPro. This setup allows the PC to translate keyboard and mouse inputs into controller commands.

1. Connect the CronusMax Plus to your PC via the PC Prog USB Port (5).
2. Connect your keyboard and mouse to your PC.
3. Launch CronusPro software and activate the X-AIM plugin.
4. Configure your keyboard and mouse mappings within X-AIM.
5. Ensure the CronusMax Plus is connected to your console via the Output (2) port.

MAINTENANCE

- **Firmware Updates:** Regularly check the official CronusMax website for firmware updates. Keeping your device updated ensures compatibility with new consoles, controllers, and game titles, and provides performance improvements.
- **Software Updates:** Keep your CronusPro software updated to the latest version for optimal performance and access to new features and game packs.
- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the CronusMax Plus in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Handle USB cables and ports gently to prevent damage. Avoid bending cables sharply or forcing connectors.

TROUBLESHOOTING

Common Issues and Solutions:

- **Device Not Recognized by Console/PC:**
 - Ensure the CronusMax Plus is firmly plugged into a working USB port.
 - Try a different USB port on your console/PC.
 - Verify that the firmware is up to date.
 - If using a USB hub, try connecting the CronusMax Plus directly to the console/PC.
- **Controller Not Responding:**
 - Ensure your controller is properly connected to the CronusMax Plus Input (1) port.
 - Check if the controller is powered on and fully charged (if wireless).
 - Verify that the correct memory slot/profile is selected on the CronusMax Plus.
 - For PS4/Xbox One, ensure the console's authentication process is complete (sometimes requires a brief connection of an official controller directly to the console first).
 - If using a wireless controller, ensure its wireless adapter (if applicable) is connected to the CronusMax Plus or a connected USB hub.
- **Lag or Input Delay:**
 - Ensure no other devices are causing interference.
 - Verify that the CronusMax Plus firmware is the latest version, as updates often include performance optimizations.
 - If using a USB hub, try a different hub or connect directly if possible.
- **Game Pack/Script Not Working:**
 - Ensure the correct game pack/script is loaded onto the selected memory slot.
 - Verify that the game pack/script is compatible with your game version and console.
 - Check the official CronusMax forums or community for updated scripts or troubleshooting tips for specific games.
- **Audio Issues (PS4):**
 - Ensure the included USB sound card is properly connected to the console and your headset is plugged into the sound card.
 - Check PS4 audio settings to ensure output is directed to the USB headset.

For more detailed troubleshooting and community support, visit the official CronusMax forums and knowledge base.

SPECIFICATIONS

Feature	Detail
Model Number	CronusMax Plus 2017
Brand	CronusMax
Manufacturer	cronusmax
Product Dimensions	5.39 x 4.09 x 1.5 inches
Item Weight	3.84 ounces

Color	Black
Connector Type	USB (Male-to-female)
Compatible Devices	PC, PlayStation 4, Xbox One, PlayStation 3, Xbox 360, Wii, Wii U Pro (via supported controllers)
ASIN	B013E2KD5M

WARRANTY AND SUPPORT

Warranty Information:

Specific warranty details for the CronusMax Plus 2017 are typically provided at the point of purchase or on the manufacturer's official website. Please refer to your purchase documentation or the CronusMax official website for the most accurate and up-to-date warranty policy.

Note: Using the CronusMax Plus does not void your console or controller warranty.

Customer Support:

For technical support, detailed guides, FAQs, and community forums, please visit the official CronusMax website. The website provides extensive resources, including:

- Comprehensive user guides and tutorials.
- Firmware and software downloads.
- A vibrant community forum for peer-to-peer support and sharing of custom scripts.
- Contact information for direct support inquiries.

Always refer to the official CronusMax resources for the most accurate and reliable information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question