

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image Rechargeable Aluminum Emergency Lamp User Manual

Sharper Image 60 LED Emergency Lamp (2-Pack)

Sharper Image Rechargeable Aluminum Emergency Lamp

Model: 60 LED Emergency Lamp (2-Pack)

INTRODUCTION

Thank you for purchasing the Sharper Image Rechargeable Aluminum Emergency Lamp. This product is designed to provide reliable illumination during power outages and in situations where portable light is needed. Its durable aluminum construction, ultra-bright LEDs, and rechargeable battery make it an essential item for your home or outdoor activities. Please read this manual carefully before use to ensure proper operation and longevity of your device.

LAMPARA DE EMERGENCIA DE ALUMINIO

Prende automáticamente a la falta de energía eléctrica

TWO
PACK

**SHARPER
IMAGE®**

Figure 1: Two Sharper Image Rechargeable Aluminum Emergency Lamps. These lamps are designed to provide bright, reliable light, especially during power interruptions.

PRODUCT FEATURES

- **Automatic Activation:** Automatically turns on when power is lost.
- **Dual Intensity Settings:** Selectable low (14 hours) and high (7 hours) brightness modes.
- **Integrated Rechargeable Battery:** Provides cordless operation.
- **Charge Indicator:** Visual cue for battery charging status.
- **Easy Portability:** Equipped with a convenient carrying handle.
- **Durable Construction:** Made from aluminum and acrylic for longevity.
- **Ultra-Bright LEDs:** Each lamp features 60 high-efficiency LEDs.

LAMPARA DE EMERGENCIA DE ALUMINIO

Prende automáticamente a la falta de energía eléctrica

TWO
PACK

**SHARPER
IMAGE®**

Figure 2: Close-up view of the lamp's carrying handle and the arrangement of its ultra-bright LEDs, highlighting the single control button.

PACKAGE CONTENTS

Your Sharper Image Emergency Lamp package should contain the following items:

- 2 x Sharper Image Rechargeable Aluminum Emergency Lamps
- 1 x Power Cord (for charging)



- Un sólo botón de control
- Asa para fácil transportación



**SHARPER
IMAGE®**



NUEVO LED SMD

Figure 3: Front view of the product packaging, clearly indicating that the package contains two emergency lamps.

PARTS DESCRIPTION

Familiarize yourself with the components of your emergency lamp:



VISTA FRONTAL DEL EMPAQUE (Blister) con 2 lámparas

2 LUMINARIOS DE EMERGENCIA

Figure 4: Detailed diagram illustrating the various parts of the emergency lamp and their respective labels for easy identification.

1. Transparent Cover
2. Charge Indicator
3. 60 LED Board
4. Handle
5. Switch/Light Intensity Selector (High / Off / Low)
6. Power Connector Protective Cover
7. AC Power Input Connector
8. DC Power Input Connector (center positive)

SETUP AND INITIAL CHARGING

Before first use, it is recommended to fully charge the emergency lamp.

1. Ensure the lamp's switch (5) is in the 'Off' position.
2. Open the protective cover (6) for the power connectors.
3. Connect the provided power cord to the AC Power Input Connector (7) on the lamp.
4. Plug the other end of the power cord into a standard 127V AC wall outlet.
5. The Charge Indicator (2) will illuminate, indicating that the lamp is charging.
6. Allow the lamp to charge for approximately 20-24 hours for the initial charge to ensure optimal battery performance.
7. Once fully charged, unplug the power cord and close the protective cover.

The lamp is designed for easy installation and can be placed on a flat surface or hung using its handle.

OPERATING INSTRUCTIONS

Your Sharper Image Emergency Lamp offers versatile operation modes:

Manual Operation

- To turn the lamp **ON** at **High Intensity**, slide the switch (5) to the 'High' position. The lamp will provide approximately 7 hours of light.
- To turn the lamp **ON** at **Low Intensity**, slide the switch (5) to the 'Low' position. The lamp will provide approximately 14 hours of light.
- To turn the lamp **OFF**, slide the switch (5) to the 'Off' (middle) position.

Automatic Emergency Function

The lamp is designed to automatically activate during a power outage when connected to an AC power source and the switch is in either the 'High' or 'Low' position.

1. Connect the lamp to a 127V AC wall outlet using the provided power cord.
2. Slide the switch (5) to either the 'High' or 'Low' position.
3. The lamp will remain off while AC power is present (and charging if needed).
4. In the event of a power failure, the lamp will automatically turn on at the selected intensity.
5. When AC power is restored, the lamp will automatically turn off and resume charging.

CHARGING AND BATTERY CARE

The emergency lamp features an integrated rechargeable battery. Proper charging and care will extend its lifespan.

- **Regular Charging:** For optimal battery health, keep the lamp plugged into an AC outlet when not in use, especially if you intend to use its automatic emergency function.
- **Charge Indicator:** The indicator light (2) will show when the lamp is receiving power and charging.
- **Long-Term Storage:** If storing the lamp for an extended period (more than 3 months), fully charge it every 3 months to prevent battery degradation.
- **Battery Replacement:** The battery is integrated and not user-replaceable. Do not attempt to open the unit.

MAINTENANCE

To keep your emergency lamp in optimal condition:

- **Cleaning:** Wipe the lamp's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Storage:** Store the lamp in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the power cord for any signs of damage. If damaged, discontinue use and replace it with an authorized Sharper Image power cord.

TROUBLESHOOTING


If you encounter issues with your emergency lamp, try the following:

- **Lamp does not turn on:**
 - Ensure the battery is charged. Plug it into an AC outlet and allow it to charge for several hours.
 - Check if the power cord is securely connected to both the lamp and the wall outlet.
 - Verify that the wall outlet is functioning by plugging in another device.
 - Ensure the switch is in the 'High' or 'Low' position for manual or automatic operation.
- **Lamp does not turn on automatically during power outage:**
 - Confirm the lamp is plugged into a live AC outlet.
 - Ensure the switch is set to either 'High' or 'Low' (not 'Off').
 - The battery might be completely depleted. Allow it to charge for a full cycle.
- **Short illumination time:**
 - The battery may not be fully charged. Ensure it has been charged for the recommended duration.
 - Battery capacity may have diminished over time. Ensure regular charging as per maintenance guidelines.

If problems persist, please contact Sharper Image customer support.

SPECIFICATIONS

DESCRIPCION DE PARTES



1. Cubierta transparente
2. Indicador de carga
3. Tableta de 60 leds
4. Asa
5. Interruptor/Selector de intensidad luminosa "Alta / Apagado / Baja"
6. Cubierta protectora de conectores de alimentación
7. Conector de entrada de corriente alterna
8. Conector de entrada de corriente directa (centro positivo) $\ominus - \odot - \oplus$

MEDIDAS DEL LUMINARIOS




Figure 5: Visual representation of the electrical characteristics and key features of the Sharper Image Emergency Lamp.

Attribute	Value
Brand	Sharper Image
Manufacturer	Grupo Nes
Model Number	1 (Manufacturer's Reference)
Dimensions (L x W x H)	5.5 x 39 x 4 cm
Weight	1 kg
Material	Aluminum and Acrylic
Color	Silver
Bulb Type	LEDs (60 ultra-bright LEDs per lamp)
Voltage	127 Volts
Wattage	127 watts (Input)
Run Time (Low Intensity)	Approx. 14 hours

Run Time (High Intensity)	Approx. 7 hours
Special Features	Includes 2 pieces, Flat LEDs, Automatic power outage activation
Certifications	NOM

Safety Information

- This lamp is designed for emergency use and should not be used as a daily primary light source.
- Do not expose the lamp to water or excessive moisture.
- Do not attempt to disassemble or modify the lamp. This will void the warranty and may cause electric shock or injury.
- Keep out of reach of children.
- Use only the provided power cord for charging.
- Avoid looking directly into the LEDs when the lamp is on, as it may cause temporary vision impairment.

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Sharper Image website. Keep your proof of purchase for any warranty claims.

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B013FAOD0Y>

More documents and user manuals: <https://manuals.plus/>