

TWINBIRD TC-EA17W

TWINBIRD 100W Lightweight Stick Cleaner TC-EA17W Instruction Manual

Model: TC-EA17W

INTRODUCTION

The TWINBIRD TC-EA17W is a versatile and lightweight 100W stick cleaner designed for efficient home cleaning. Weighing approximately 2.1 kg, it offers powerful suction and a convenient 2-way design, easily converting from a stick vacuum for floors to a handheld unit for detailed cleaning. Its bagless system features a one-touch dust disposal mechanism and washable dust case and filters, ensuring economical and hygienic use.

SAFETY INFORMATION

Please read all safety instructions carefully before using this appliance to prevent injury or damage. Keep this manual for future reference.

- Do not operate the cleaner with wet hands or in wet conditions.
- Always unplug the cleaner from the power outlet before cleaning, maintenance, or when not in use.
- Do not vacuum liquids, hot ashes, burning cigarettes, or sharp objects.
- Keep children and pets away from the appliance during operation.
- Ensure the power cord is not damaged, kinked, or placed under heavy objects.
- Use only genuine TWINBIRD replacement parts and accessories.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Main Unit (includes upper body, dust case, and floor nozzle)
- Handle
- Aluminum Pipe
- Crevice Nozzle

- Crevice Nozzle Holder

PRODUCT OVERVIEW

Familiarize yourself with the main components of your TWINBIRD stick cleaner.



The TWINBIRD TC-EA17W Stick Cleaner in its full assembly, ready for general floor cleaning.



The cleaner in handheld mode with the crevice nozzle attached, ideal for reaching narrow gaps and edges.



The detached dust case and filter components of the cleaner, highlighting their water-washable design for easy maintenance.

SETUP

Follow these steps to assemble your stick cleaner:

1. **Assemble the Handle:** Insert the handle into the top of the main unit until it clicks securely into place.
2. **Attach the Aluminum Pipe:** For stick mode, connect the aluminum pipe to the main unit.
3. **Attach the Floor Nozzle:** Connect the floor nozzle to the bottom of the aluminum pipe. Ensure all connections are firm.
4. **Handheld Mode:** To use as a handheld cleaner, detach the aluminum pipe and floor nozzle. You can then attach the crevice nozzle directly to the main unit for targeted cleaning.
5. **Crevice Nozzle Storage:** Attach the crevice nozzle holder to the aluminum pipe for convenient storage of the crevice nozzle when not in use.

OPERATING INSTRUCTIONS

Operating your TWINBIRD stick cleaner is simple:

1. **Power Connection:** Plug the power cord into a standard AC100V 50-60Hz electrical outlet. The cord length is approximately 4.5 meters.
2. **Power On/Off:** Locate the push switch on the main body of the cleaner. Press it once to turn the cleaner ON, and press it again to turn it OFF.
3. **Stick Mode Cleaning:** For general floor cleaning, use the cleaner in its stick configuration. The full-flat floor nozzle design allows for easy cleaning under furniture like tables and beds.
4. **Handheld Mode Cleaning:** For detailed cleaning, detach the aluminum pipe and floor nozzle. Use the main unit as a handheld cleaner. This is ideal for stairs, windowsills, sofa gaps, and other narrow or elevated areas.

5. **Using the Crevice Nozzle:** Attach the crevice nozzle to the main unit (in handheld mode) or to the aluminum pipe (in stick mode, if preferred) to clean tight corners, crevices, and sash grooves effectively.



Using the TWINBIRD TC-EA17W in handheld mode to efficiently clean stairs.



The full-flat design of the TWINBIRD TC-EA17W allows for easy cleaning under low furniture like tables.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your cleaner.

Emptying the Dust Case

1. Ensure the cleaner is OFF and unplugged.
2. Hold the main unit over a trash bin.
3. Press the one-touch release button (Rakusute function) on the dust case to open the bottom flap and empty the collected dust.



Demonstration of emptying the dust case of the TWINBIRD TC-EA17W using the one-touch release function.

Cleaning the Dust Case and Filter

The dust case and filter are washable for hygienic use.

1. Ensure the cleaner is OFF and unplugged.
2. Remove the dust case from the main unit.
3. Carefully remove the filter components from the dust case.
4. Rinse the dust case and all filter components under running water until clean.
5. Allow all parts to air dry completely before reassembling. Ensure they are thoroughly dry to prevent mold or damage to the motor.
6. Reassemble the filter components into the dust case, then attach the dust case back to the main unit.

TROUBLESHOOTING

If you encounter any issues with your cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cleaner does not turn on.	Power cord not properly plugged in. No power from outlet.	Check power cord connection. Test outlet with another appliance.
Reduced suction power.	Dust case is full. Filters are clogged. Nozzle or pipe is blocked.	Empty the dust case. Clean the filters thoroughly. Check and clear any blockages in the nozzle, pipe, or main unit inlet.
Unusual noise during operation.	Foreign object caught in the nozzle or fan.	Turn off and unplug the cleaner. Inspect the nozzle and main unit for any foreign objects and remove them carefully.
Cleaner overheats and stops.	Motor overload due to clogged filters or blockages.	Turn off and unplug the cleaner. Allow it to cool down for at least 30 minutes. Clean the dust case and filters, and check for any blockages before resuming use.

SPECIFICATIONS

Detailed technical specifications for the TWINBIRD TC-EA17W stick cleaner:

Feature	Specification
Model Number	TC-EA17W
Dimensions (W×D×H)	230 × 225 × 1050 mm
Weight (including accessories)	Approx. 2.1 kg
Power Source	AC100V, 50/60Hz
Power Consumption	450 W
Suction Power	100 W
Dust Collection Capacity	Approx. 0.9 L
Cord Length	Approx. 4.5 m
Materials	ABS (Upper body, handle, dust case, floor nozzle), Aluminum (Pipe), PP (Crevice nozzle, holder)
Filter Type	Cartridge
Noise Level	70 dB
Country of Origin	China

WARRANTY AND SUPPORT

Warranty: This product comes with a 1-year manufacturer's warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Support: For technical assistance, spare parts, or warranty service, please contact TWINBIRD customer service. Refer to the contact information provided with your product packaging or visit the official TWINBIRD website for details.

