

Brookstone 883594048692

Brookstone Grill Alert Bluetooth Connected Thermometer User Manual

Model: 883594048692

PRODUCT OVERVIEW

The Brookstone Grill Alert Bluetooth Connected Thermometer is designed to help you achieve perfectly cooked meals by monitoring internal food temperatures and alerting you via a connected smart device. This device features dual probes, allowing you to track two different food items simultaneously.



Image: The Brookstone Grill Alert thermometer unit displaying temperatures, accompanied by two color-coded temperature probes (green and orange).

Key Features:

- App-controlled temperature monitoring via Bluetooth 4.0 or Bluetooth Smart Ready devices up to 150 feet away.
- Pre-programmed ideal cooking temperatures for various meats (chicken, turkey, fish) and customizable doneness

settings (rare, medium, etc.) for steak, hamburger, veal, pork, and lamb.

- Customizable target temperature settings.
- Alerts via voice, vibration, or sound notifications.
- Includes two probes for simultaneous monitoring of two different food items.
- Probe wires wrap around handles for tidy storage.
- Magnetic base for secure attachment to grills and optimal viewing angle.
- Powered by 2 AAA batteries (not included).

SETUP

1. Battery Installation

The Grill Alert thermometer requires 2 AAA batteries for operation. Ensure correct polarity when inserting the batteries.

2. App Download and Pairing

The Grill Alert App is essential for controlling and monitoring the thermometer. It is compatible with select Bluetooth 4.0 or Bluetooth Smart Ready devices.

1. Download the "Grill Alert App" from your device's app store.
2. Press and hold the power/pairing button on your Grill Alert thermometer unit.
3. Open the Grill Alert App on your smart device and tap the Bluetooth symbol within the app.
4. Press the "SCAN" button within the Grill Alert App.
5. Tap "Grill Alert" when it appears on your device screen to complete the pairing process.




Image: A hand holding a smartphone displaying the Brookstone Grill Alert application, showing current and target temperatures for two probes.

OPERATING INSTRUCTIONS

1. Probe Insertion

Carefully insert the metal tip of the temperature probe into the thickest part of the meat, avoiding bones. Connect the probe's cable to the corresponding port on the wireless transmitter unit.



Image: A close-up view of the two temperature probes, one with a green handle and the other with an orange handle, designed for measuring internal food temperatures.

2. Selecting Food Type and Doneness

Within the Grill Alert App on your Bluetooth-enabled device:

- Select the type of food you are cooking (e.g., chicken, beef, pork).
- Choose your desired level of doneness (e.g., rare, medium, well-done) if applicable for the selected food type.
- Alternatively, you can set a custom target temperature.

3. Monitoring and Alerts

The app will display real-time temperature progress. When the target temperature is reached, the device will alert you via voice, vibration, or sound, as configured in the app settings.

MAINTENANCE

Cleaning Instructions

After each use, allow the probes to cool. Wipe the probes and the main unit with a damp cloth. Do not immerse the main unit in water. The probes are not dishwasher safe. Ensure all components are dry before storage.

Storage

Store the thermometer and probes in a clean, dry place. The probe wires can be wrapped around the probe handles for neat storage.

TROUBLESHOOTING

• Device Not Pairing:

Ensure Bluetooth is enabled on your smart device. Confirm the Grill Alert thermometer is powered on and within range (up to 150 feet). Restart both the app and the thermometer. Verify your smart device is Bluetooth 4.0 or Bluetooth Smart Ready compatible.

• Inaccurate Temperature Readings:

Ensure the probe is inserted correctly into the thickest part of the meat, avoiding bones. Check that the probe cable is securely connected to the unit. Clean probes thoroughly after each use to prevent residue buildup affecting readings.

- **No Alerts:**

Check app notification settings on your smart device and within the Grill Alert App. Ensure the volume is up and that the device is not in silent or do-not-disturb mode. Verify the target temperature has been set correctly.

- **Short Battery Life:**

Ensure you are using fresh AAA alkaline batteries. Battery life can vary based on usage and environmental conditions.

SPECIFICATIONS

Attribute	Detail
Brand	Brookstone
Model Number	883594048692
Connectivity Technology	Bluetooth 4.0 / Bluetooth Smart Ready
Special Feature	Dual Probe
Included Components	2 probes
Power Source	2 AAA Batteries (not included)
Upper Temperature Rating	572 Degrees Fahrenheit (300 Degrees Celsius)
Resolution	0.1°C or 0.1°F
Product Dimensions	10.24 x 3.15 x 6.3 inches
Item Weight	14.4 ounces
Care Instructions	Wipe Clean
Indoor/Outdoor Usage	Outdoor

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Brookstone website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Manufacturer: Brookstone

Website: www.brookstone.com (Note: This is a placeholder URL, please refer to official product documentation for exact support links.)