

Jysk 3770704

Jysk Bloxus Bistro Table Instruction Manual

Model: 3770704

1. PRODUCT OVERVIEW

The Jysk Bloxus Bistro Table is a stylish and functional round table designed for indoor use. It features a durable iron frame and a clear glass tabletop, making it suitable for various settings such as small dining areas or as an accent piece. This manual provides essential information for safe assembly, proper use, and maintenance of your table.



Figure 1.1: Jysk Bloxus Bistro Table shown with two chairs. This image illustrates the complete product setup.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Assembly may require tools and careful handling. Ensure you have adequate space and assistance if

needed.

- This table is round and features a glass surface. Glass can be fragile and may break if not handled with care or if subjected to impact.
- Always ensure the table is correctly and stably assembled before placing any items on it or using it. An unstable table can tip over, causing injury or damage.
- Do not place excessively heavy objects on the glass tabletop.
- Avoid sudden temperature changes on the glass surface, as this can cause it to crack or shatter.
- Keep small children and pets away from the assembly area to prevent accidents.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Tabletop (Glass)
- Table Frame (Iron)
- Hardware for assembly (screws, washers, Allen key, etc.)

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your Jysk Bloxus Bistro Table. It is recommended to assemble the table on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Check against the package contents list.
2. **Assemble the Frame:** Attach the table legs to the central support structure using the provided hardware. Ensure all screws are finger-tightened initially.
3. **Secure the Frame:** Once all legs are in place, gradually tighten all screws with the provided Allen key. Do not overtighten. Ensure the frame is stable and level.
4. **Place the Glass Top:** Carefully place the glass tabletop onto the assembled frame. Ensure it is centered and sits securely within any designated grooves or suction cups (if applicable).
5. **Final Check:** Gently test the stability of the table. If it wobbles, re-check all connections and tighten screws as necessary.



Figure 4.1: Assembled Jysk Bloxus Bistro Table. This image shows the table ready for use after assembly.

5. OPERATING INSTRUCTIONS (USAGE)

The Jysk Bloxus Bistro Table is designed for general indoor use. To ensure longevity and safety, please observe the following guidelines:

- Use the table on a flat, stable surface to prevent wobbling or tipping.
- Do not stand or sit on the table.
- Avoid dragging the table across the floor; lift it when moving to prevent damage to legs or floor.
- Place hot items on coasters or protective mats to prevent thermal shock to the glass.
- Keep sharp objects away from the glass surface to avoid scratches.

6. MAINTENANCE

Regular cleaning and maintenance will help preserve the appearance and functionality of your table.

- **Glass Top:** Clean the glass surface with a soft, damp cloth and a mild glass cleaner. Avoid abrasive cleaners or scouring pads, which can scratch the glass. Dry immediately with a clean, lint-free cloth to prevent streaks.
- **Frame:** Wipe the iron frame with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Dry thoroughly to prevent rust.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Storage:** If storing the table, ensure it is in a dry environment to prevent moisture damage to the frame.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your bistro table.

Problem	Possible Cause	Solution
Table is wobbly.	Loose screws; uneven floor.	Check and tighten all assembly screws. Move the table to a flat, even surface.
Glass top appears scratched or dull.	Abrasive cleaning materials; sharp objects.	Use only soft cloths and mild glass cleaner. Avoid placing sharp objects directly on the glass.
Frame shows signs of rust.	Exposure to moisture; outdoor use.	Ensure the table is used and stored indoors in a dry environment. Clean and dry any moisture immediately.

8. SPECIFICATIONS

Detailed specifications for the Jysk Bloxus Bistro Table.

Model Number: 3770704

Model Name: Bloxus

Color: Black

Item Weight: 5.5 kg (5.5 Kilograms)

Frame Material: Iron

Top Material Type: Glass

Shape: Round

Table Design: Dining Table

Style: Contemporary, Casual

Indoor/Outdoor Use: Indoor

Included Components: Hardware for assembly

Dimensions: 70 x 60 x 67 cm (as per product title)

9. WARRANTY AND SUPPORT

Specific warranty information for the Jysk Bloxus Bistro Table is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to your purchase documentation or contact Jysk customer service directly. You can typically find contact information on the retailer's website or on the product packaging.

For further assistance, please visit the official Jysk website or contact their support team:

- **Jysk Official Website:** www.jysk.com (Please check for your regional website)
- **Customer Service:** Refer to your local Jysk store or regional website for contact details.