Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- VTech /
- > VTech Kidizoom Duo Digital Camera User Manual

VTech Kidizoom Duo

VTech Kidizoom Duo Digital Camera User Manual

Model: Kidizoom Duo (80-170800)

INTRODUCTION

The VTech Kidizoom Duo is a durable digital camera designed for children aged 3 to 9 years. It features dual lenses for taking photos and selfies, a color LCD screen, and various creative effects. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Kidizoom Duo camera.



Image: Front view of the VTech Kidizoom Duo Digital Camera, showcasing its dual lens design and colorful faceplate.

GETTING STARTED

Battery Installation

The Kidizoom Duo camera requires 4 AA batteries for operation. These batteries are included for

demonstration purposes only. For regular use, it is recommended to install new, high-quality alkaline batteries.

- 1. Locate the battery compartment on the back of the camera.
- 2. Use a screwdriver to open the battery compartment cover.
- 3. Insert 4 AA batteries, ensuring correct polarity (+/-).
- 4. Replace the battery compartment cover and secure it with the screw.

Note: The camera is not rechargeable. Do not attempt to charge the camera or use rechargeable batteries unless specifically designed for this device.



Image: Rear view of the VTech Kidizoom Duo Digital Camera, illustrating the screen and control buttons, where the battery compartment is located.

Attaching the Wrist Strap

A wrist strap is included to help prevent accidental drops. Attach the strap to the designated loop on the camera body.

Powering On

Press and hold the Power button (usually located on the side or top of the camera) until the screen illuminates. To turn off, press and hold the Power button again.

OPERATING THE CAMERA

Taking Photos and Videos

The Kidizoom Duo features a front-facing camera for general photography and a rear-facing camera ideal for selfies. Use the camera selection button to switch between the two lenses.

- To take a photo: Select the camera mode, aim the camera, and press the Shutter button.
- To record a video: Select the video mode, press the Record button to start, and press it again to stop.



Image: A young child demonstrating how to hold and operate the VTech Kidizoom Duo Digital Camera.

Creative Effects

Enhance your photos and videos with various built-in effects:

- Laugh-Out-Loud Photo Effects: Apply fun distortions and frames to your pictures.
- Cartoon and Collage Effects: Transform your images into cartoon styles or combine multiple photos into a collage.

Playing Games

The camera includes five interactive games, three of which are motion-controlled, offering additional entertainment.



Image: A child engaging with a motion-controlled game displayed on the VTech Kidizoom Duo camera screen.

Connecting to a Computer

To transfer photos and videos to a computer, use the included micro USB cable.

- 1. Connect the micro USB cable to the camera's USB port and to an available USB port on your computer.
- 2. The camera will appear as a removable drive on your computer.
- 3. Drag and drop files to transfer them.

Important: The micro USB cable is for file transferring only and does not charge the camera.



Image: The VTech Kidizoom Duo Digital Camera connected to a laptop, illustrating the process of transferring media files.

Automatic Power Off

To conserve battery life, the camera will automatically power off after approximately three minutes of inactivity.

MAINTENANCE

Cleaning

To clean the camera, wipe it with a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the camera is dry before use.

Storage

When not in use for extended periods, remove the batteries to prevent leakage and store the camera in a cool, dry place away from direct sunlight.



Image: The VTech Kidizoom Duo Digital Camera resting on the floor, highlighting its robust and child-friendly design.

Troubleshooting

- Camera not turning on: Ensure fresh AA batteries are correctly installed.
- Poor image quality: Check lighting conditions. Ensure lenses are clean and free from smudges.
- Cannot transfer files: Verify the micro USB cable is securely connected to both the camera and the computer. Ensure the camera is powered on.
- Camera freezes: Remove and reinsert the batteries to reset the device.

PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Kidizoom Duo
Model Number	80-170800

Feature	Specification
Effective Still Resolution	2 MP
Video Resolution	240p
Screen Size	2.4 Inches
Display Type	LCD
Battery Type	4 AA batteries (not rechargeable)
Connectivity Technology	USB
Flash Memory Type	Micro SD (optional)
Item Dimensions (D x W x H)	6.4" x 3.6" x 2.3"
Item Weight	12.96 ounces
Age Range Description	3-9 years

WARRANTY AND SUPPORT

Limited Warranty

The VTech Kidizoom Duo Digital Camera comes with a 90-day warranty against manufacturer defects from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, product registration, or to view additional resources, please visit the official VTech store or contact VTech customer service.

Visit the VTech Store

Related Documents - Kidizoom Duo



VTech Kidizoom Camera Pix User's Manual

User's manual for the VTech Kidizoom Camera Pix, detailing its features, setup, operation, and troubleshooting for this fun digital camera designed for children.



VTech KidiZoom Duo DX Digital Camera User Manual

Comprehensive user manual for the VTech KidiZoom Duo DX digital camera, covering features, operation, troubleshooting, care instructions, and warranty information.



VTech KidiZoom Duo FX Instruction Manual



User manual for the VTech KidiZoom Duo FX digital camera. Learn how to use its dual lenses, photo effects, video recording, games, and other creative features for children.



VTech KidiZoom Duo FX Instruction Manual



Comprehensive instruction manual for the VTech KidiZoom Duo FX digital camera, detailing features, setup, operation, activities, troubleshooting, and care for young users and parents.



VTech Kidizoom Action Cam HD Parent's Guide - Capture Adventures

Explore the VTech Kidizoom Action Cam HD with this comprehensive Parent's Guide. Learn about features, setup, accessories, and how to capture your child's adventures.



VTech KidiZoom Duo FX Instruction Manual



Comprehensive instruction manual for the VTech KidiZoom Duo FX digital camera, covering features, setup, operation, activities, care, and troubleshooting for young users.