

Manuals.plus /

› Hotpoint /

› Hotpoint FZ175 Freezer Drawer Instruction Manual

Hotpoint FZ175

Hotpoint FZ175 Freezer Drawer Instruction Manual

1. INTRODUCTION

This manual provides essential information for the proper installation, use, and maintenance of your Hotpoint FZ175 freezer drawer. Please read these instructions carefully before installing or using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

The Hotpoint FZ175 freezer drawer is a replacement component designed to fit specific Hotpoint freezer models. It provides organized storage within the freezer compartment, allowing for efficient access to frozen items.



Image 1: Hotpoint FZ175 Freezer Drawer. This image displays the clear plastic construction of the drawer, featuring a molded handle indentation for easy access. The drawer is designed for internal freezer storage.

3. COMPATIBILITY

This freezer drawer is specifically designed for use with the **Hotpoint FZ175** freezer model. To confirm compatibility, locate the model number on your appliance, typically found on a label inside the freezer

compartment or on the back of the unit. Using this drawer with incompatible models may result in improper fit or function.

4. INSTALLATION

1. **Preparation:** Ensure the freezer is empty and, if necessary, defrosted and cleaned before installation.
2. **Remove Old Drawer (if applicable):** Gently pull out the old drawer until it reaches its stop. Lift the front of the drawer slightly and pull it completely out of the freezer compartment.
3. **Insert New Drawer:** Align the new Hotpoint FZ175 freezer drawer with the runners or guides inside the freezer compartment. Push the drawer in smoothly until it is fully seated. Do not force the drawer.
4. **Test Fit:** Open and close the drawer a few times to ensure it slides freely and securely.

5. OPERATING INSTRUCTIONS

The freezer drawer is designed for organized storage of frozen food items. To use:

- Open the freezer door.
- Gently pull the drawer out using the integrated handle.
- Place or retrieve frozen items. Avoid overfilling the drawer, as this can impede proper closure and air circulation.
- Push the drawer back into the freezer until it is fully closed. Ensure the freezer door is also properly sealed after use.

6. MAINTENANCE

Regular cleaning of the freezer drawer helps maintain hygiene and extends its lifespan.

- **Cleaning:** Remove the drawer from the freezer. Wash it with warm water and a mild detergent. Rinse thoroughly with clean water.
- **Drying:** Allow the drawer to air dry completely or wipe it with a soft, clean cloth before returning it to the freezer.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic material.

7. TROUBLESHOOTING

If you encounter issues with your freezer drawer, consider the following:

- **Drawer Not Sliding Smoothly:** Check for ice buildup on the runners or guides inside the freezer. Defrosting and cleaning the freezer may resolve this. Ensure no items are obstructing the drawer's path.
- **Drawer Not Fitting:** Double-check that you have the correct model (Hotpoint FZ175). Ensure the drawer is aligned properly with the runners during installation.
- **Cracks or Damage:** If the drawer is cracked or damaged, it may need to be replaced. Avoid placing excessively heavy or sharp objects in the drawer.

8. SPECIFICATIONS

Feature	Detail
Brand	Hotpoint
Model Compatibility	FZ175
Dimensions (Approx.)	430 mm (Width) x 200 mm (Depth)
Material	Clear Plastic
ASIN	B0147C0PXS

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided with your original Hotpoint FZ175 freezer appliance or contact Hotpoint customer service directly. This replacement part typically adheres to the standard warranty terms for genuine Hotpoint spare parts.