

## Logitech M535

# Logitech M535 Bluetooth Mouse User Manual

Model: M535

## INTRODUCTION

The Logitech M535 Bluetooth Mouse is a compact and versatile wireless mouse designed for productivity on various devices. It connects via Bluetooth, eliminating the need for a USB receiver and keeping your ports free. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your M535 mouse.

The M535 is compatible with a wide range of operating systems, including Windows 7, Windows 8, Windows 10 or later, Mac OS X 10.8 or later, Chrome OS, and Android 3.2 or later, provided the device has Bluetooth wireless capability.

## WHAT'S IN THE BOX

- Logitech M535 Bluetooth Mouse
- 1 AAA Battery (pre-installed or included)
- User Information Document



Figure 1: Packaging of the Logitech M535 Bluetooth Mouse, showing the mouse and its contents.

## PRODUCT OVERVIEW





**Figure 2:** Top view of the Logitech M535 Bluetooth Mouse, highlighting the scroll wheel, left/right click buttons, and the navigation button.



**Figure 3:** Angled view of the Logitech M535 Bluetooth Mouse, showcasing its ergonomic design and side profile.

The Logitech M535 features a standard mouse layout with additional functionalities:

- **Left and Right Click Buttons:** Standard mouse functions.
- **Scroll Wheel:** For vertical scrolling. The scroll wheel also supports tilt-scrolling (horizontal scrolling) and acts as a middle click button.
- **Navigation Button:** Located below the scroll wheel, this button can be customized for various functions, such as opening the Start Menu on Windows or Mission Control on macOS, using Logitech Options software.
- **LED Indicator:** A small LED light indicates connection status and battery level.
- **Power Switch:** Located on the bottom of the mouse to turn it on or off.
- **Battery Compartment:** Located on the bottom, holds one AAA battery.



**Figure 4:** Diagram illustrating the compact dimensions of the Logitech M535 Bluetooth Mouse, approximately 3 inches in length and 2 inches in width.

## SETUP

### 1. Battery Installation

1. Locate the battery compartment cover on the bottom of the mouse.
2. Slide the cover open.
3. Insert one AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.
5. Turn on the mouse using the power switch located on the bottom. The LED indicator should light up.

## 2. Bluetooth Pairing

To connect your Logitech M535 mouse to your device, follow these steps:

1. Ensure the mouse is turned on.
2. Press and hold the **Connect button** (usually located on the bottom of the mouse, near the power switch) for 3-5 seconds until the LED indicator starts blinking rapidly. This indicates the mouse is in pairing mode.
3. On your computer or tablet, navigate to the Bluetooth settings:
  - **Windows:** Go to *Settings > Devices > Bluetooth & other devices* Ensure Bluetooth is turned on. Click "Add Bluetooth or other device" and select "Bluetooth".
  - **macOS:** Go to *System Preferences > Bluetooth*. Ensure Bluetooth is turned on.
  - **Chrome OS:** Click the status area (bottom-right corner) and then click "Bluetooth".
  - **Android:** Go to *Settings > Connected devices > Bluetooth* Ensure Bluetooth is turned on.
4. Your device will search for available Bluetooth devices. Select "Logitech M535" from the list of discovered devices.
5. Follow any on-screen prompts to complete the pairing process. Once successfully paired, the LED indicator on the mouse will glow solid blue for a few seconds and then turn off.

*Note: The M535 supports pairing with one device at a time. To switch devices, you will need to re-enter pairing mode and connect to the new device.*

## OPERATING THE MOUSE

Once paired, your Logitech M535 mouse is ready for use. It functions like a standard mouse with additional customizable features.

- **Basic Navigation:** Move the mouse on a flat surface to control the cursor. Use the left button for primary clicks and the right button for secondary (context menu) clicks.
- **Scrolling:** Roll the scroll wheel up or down for vertical scrolling. Press the scroll wheel for middle-click functionality. Tilt the scroll wheel left or right for horizontal scrolling (if supported by your application).
- **Customizing the Navigation Button:** For advanced customization of the navigation button and other mouse settings, download and install the **Logitech Options** software from the official Logitech website. This software allows you to assign various functions to the navigation button, adjust pointer speed, and more.

## MAINTENANCE

- **Cleaning:** To clean your mouse, gently wipe its surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure no liquid enters the mouse.
- **Battery Replacement:** When the mouse's performance degrades or the LED indicator signals low battery (e.g., by blinking slowly), replace the AAA battery following the "Battery Installation" steps in the Setup section.
- **Storage:** When not in use for extended periods, turn off the mouse using the power switch on the bottom to conserve battery life.

## TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Mouse does not turn on.	<ul style="list-style-type: none"><li>◦ Ensure the power switch on the bottom of the mouse is in the "ON" position.</li><li>◦ Check if the AAA battery is inserted correctly with the correct polarity.</li><li>◦ Replace the AAA battery with a new one.</li></ul>
Mouse is not connecting or frequently disconnects.	<ul style="list-style-type: none"><li>◦ Ensure Bluetooth is enabled on your computer/tablet.</li><li>◦ Move the mouse closer to your device.</li><li>◦ Re-pair the mouse: Turn off the mouse, remove it from your device's Bluetooth list, then re-enter pairing mode on the mouse and pair again.</li><li>◦ Check for interference from other wireless devices.</li><li>◦ Ensure your device's Bluetooth drivers are up to date.</li><li>◦ For Windows users, check power management settings for your Bluetooth adapter to ensure it's not being turned off to save power.</li></ul>
Cursor movement is erratic or unresponsive.	<ul style="list-style-type: none"><li>◦ Ensure the mouse sensor on the bottom is clean and free of debris.</li><li>◦ Try using the mouse on a different surface. Highly reflective or uneven surfaces can affect tracking.</li><li>◦ Check battery level and replace if low.</li></ul>
Buttons or scroll wheel are not working.	<ul style="list-style-type: none"><li>◦ Check battery level and replace if low.</li><li>◦ Re-pair the mouse with your device.</li><li>◦ If using Logitech Options software, ensure button assignments are correct.</li></ul>

SPECIFICATIONS

Feature	Detail
Model	M535
Connectivity Technology	Bluetooth
Movement Detection Technology	Optical
Wireless Type	802.11a/b/g/n (Note: This refers to general wireless standards, Bluetooth is the specific connection type for the mouse)
Power Source	Battery Powered
Battery Type	1 x AAA battery
Average Battery Life	Up to 6 months (may vary based on usage)
Item Weight	2.89 ounces (approx. 82 grams)



Feature	Detail
Product Dimensions (LxWxH)	3 x 2 x 1 inches (approx. 7.6 x 5.1 x 2.5 cm)
Color	Black
Hardware Platform Compatibility	Tablet, PC, Mac
Operating System Compatibility	Windows 7/8/10+, Mac OS X 10.8+, Chrome OS, Android 3.2+

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Logitech website. Logitech provides customer support and resources for their products.

**Official Logitech Support:** For further assistance, FAQs, and driver downloads (like Logitech Options software), please visit the [Logitech Support Website](#).






© 2024 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners.

Related Documents - M535

	<p><a href="#">Logitech M535 Bluetooth Mouse: Features, Setup, and Compatibility Guide</a></p> <p>Discover the Logitech M535 Bluetooth Mouse. This guide covers its features, Bluetooth connection steps, customization with Logitech Options software, and compatibility with Windows, Mac OS, Chrome OS, and Android devices.</p>
	<p><a href="#">Logitech M337 Bluetooth Mouse: Features, Setup, and Compatibility Guide</a></p> <p>A comprehensive guide to the Logitech M337 Bluetooth Mouse, detailing its features, setup process, gesture controls, power management, and system compatibility for Windows, macOS, Chrome OS, and Android devices.</p>
	<p><a href="#">Logitech Marathon Mouse M705: Getting Started Guide &amp; Features</a></p> <p>Comprehensive guide to setting up and using the Logitech Marathon Mouse M705, including features, troubleshooting, and Unifying receiver setup.</p>



	<p><a href="#">Logitech LIFT Vertical Ergonomic Mouse User Guide and Setup</a></p> <p>Comprehensive guide to setting up, connecting, and using the Logitech LIFT Vertical Ergonomic Mouse. Learn about its features like SmartWheel, Easy-Switch, and Logitech Flow.</p>
	<p><a href="#">Logitech MX Anywhere 3S Getting Started Guide and Features</a></p> <p>Comprehensive guide to setting up, connecting, and using the Logitech MX Anywhere 3S mouse, including features like MagSpeed scroll wheel, SmartShift, Logitech Flow, and app-specific settings.</p>
	<p><a href="#">Logitech MX Ergo S Setup Guide   Ergonomic Trackball Mouse</a></p> <p>Set up and connect your Logitech MX Ergo S ergonomic trackball mouse. Discover features like adjustable angle, precision scroll wheel, easy-switch, and Logitech Flow technology for seamless multi-device productivity. Includes Bluetooth and Logi Bolt setup instructions.</p>