

[Manuals.plus](#) /

› [Homeleader](#) /

› Homeleader Towel Warmer and Drying Rack (Model: B014CNC3IW) Instruction Manual

Homeleader B014CNC3IW

Homeleader Towel Warmer and Drying Rack (Model: B014CNC3IW) Instruction Manual

Brand: Homeleader | Model: B014CNC3IW

PRODUCT OVERVIEW

The Homeleader Towel Warmer and Drying Rack is designed to provide warm and dry towels, robes, and other items. It features a built-in thermostat to maintain an optimal temperature and offers versatile installation options.

STAY DRY & COMFORTABLE



Humid weather



Cold weather

Image: The Homeleader Towel Warmer and Drying Rack with two towels, illustrating its use in humid and cold weather conditions to keep towels dry and comfortable.

Your browser does not support the video tag.

Video: An overview of the Homeleader Towel Warmer and Drying Rack, demonstrating its features and functionality.

SAFETY INFORMATION

- Ensure the towel warmer is installed on a stable surface or securely mounted to a wall.
- The waterproof switch design ensures safety during operation. However, avoid immersing the unit in water.
- Do not cover the towel warmer with items that could obstruct heat dissipation, such as plastic sheets or non-breathable materials.
- Keep out of reach of children and pets.
- Always unplug the unit when not in use or before cleaning.
- This appliance is designed for warming and drying towels and robes; it is not intended for heating rooms.

SETUP AND INSTALLATION

The Homeleader Towel Warmer offers two installation options: freestanding or wall-mounted. All necessary hardware and tools for assembly are included.

Freestanding Installation:

1. Attach the two floor stands to the main frame using the provided screws. Ensure they are securely fastened.
2. Place the assembled unit on a flat, stable surface in your desired location.

Wall-Mounted Installation:

1. Identify a suitable wall location, ensuring it is near a power outlet and away from direct water spray.
2. Use the provided mounting hardware to securely attach the towel warmer to the wall. Follow the detailed instructions in the included manual for precise measurements and drilling.




Image: Illustration of the Homeleader Towel Warmer in both its floor-standing and wall-mountable configurations, highlighting its versatile design.

Your browser does not support the video tag.

Video: A demonstration of the freestanding towel warmer installation process.

OPERATING INSTRUCTIONS

To operate your Homeleader Towel Warmer, follow these steps:

1. **Placement:** Drape towels or robes over the bars of the warmer. For optimal warming, ensure items are spread out to maximize contact with the heated bars. Folding towels to create layers can help trap more heat for faster warming.
2. **Power On:** Plug the unit into a standard electrical outlet. Locate the in-line on/off switch and press it to turn the warmer on. A light indicator will illuminate when the unit is active.
3. **Warming Process:** The built-in thermostat will heat the bars to an optimum temperature of 131-141°F (55-61°C) within approximately 30 minutes. The primary function is to warm and dry towels, not to rapidly increase their temperature to a high heat.
4. **Power Off:** When finished, press the in-line on/off switch to turn the unit off and unplug it from the outlet.




Image: Detail of the in-line on/off switch with its light indicator and protective cover, located on the base of the towel warmer.



131-141°F / 55-61°C
Gentle Warmth

Useful for keeping towels
warm and dry on cold or
rainy days

Image: The towel warmer in a bathroom, displaying its gentle warming capability within the 131-141°F (55-61°C) range, ideal for cold or rainy days.

Your browser does not support the video tag.

Video: A display video showcasing the freestanding towel warmer in operation, demonstrating how towels are placed and warmed.

MAINTENANCE

To ensure the longevity and optimal performance of your towel warmer:

- **Cleaning:** Before cleaning, ensure the unit is unplugged and completely cool. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals, as these can damage the lacquer finish.
- **Storage:** If storing the unit for an extended period, ensure it is clean, dry, and stored in a cool, dry place.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If any damage is found, discontinue use and contact customer service.

TROUBLESHOOTING

If you encounter issues with your Homeleader Towel Warmer, consider the following:

- **Unit Not Heating:**
 - Ensure the power cord is securely plugged into a functional electrical outlet.
 - Check if the in-line on/off switch is in the "on" position and its indicator light is illuminated.
 - Verify that the electrical outlet is receiving power (test with another appliance).
- **Insufficient Warming:**
 - Ensure towels are spread out and making good contact with the heated bars.
 - Allow sufficient time (up to 30 minutes) for the unit to reach its optimal temperature.
 - The unit is designed for warming and drying, not for rapid high-temperature heating.

For issues not resolved by these steps, please contact customer service.

SPECIFICATIONS

Feature	Detail
Brand	Homeleader
Model Number	B014CNC3IW
Power	120W
Optimal Temperature	131-141°F / 55-61°C
Heating Time	Within 30 minutes
Product Dimensions	24.8 x 2.4 x 31.8 inches
Item Weight	6.8 pounds
Finish Type	Lacquer
Mounting Options	Wall Mount, Free Standing
Batteries Required	No




Image: A diagram illustrating the key dimensions of the Homeleader Towel Warmer, including its height and width.

WARRANTY AND SUPPORT

Homeleader provides reliable customer service and support for this product.

- **Warranty:** The product includes 12 months replacements for all parts.
- **Customer Service:** For any inquiries, assistance, or warranty claims, customer service is ready to respond within a

24-hour timeframe. Please refer to the contact information provided in your product packaging or on the official Homeleader website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question