

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ADLER](#) /

› [Adler AD 2823 Animal Clippers User Manual](#)

ADLER Adler_AD 2823

Adler AD 2823 Animal Clippers User Manual

Model: Adler_AD 2823

1. INTRODUCTION

Welcome to your new Adler AD 2823 Animal Clippers. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your device. Please read it thoroughly before first use to ensure optimal performance and longevity of the product.

2. SAFETY WARNINGS

To prevent injury or damage to the device, always adhere to the following safety guidelines:

- **Caution:** Do not use on babies. This device is intended for animal grooming only.
- Keep the device away from water sources and do not immerse it in water or any other liquid.
- Do not operate the clipper with a damaged cord or plug. If the device malfunctions or has been damaged in any way, discontinue use and contact customer support.
- Always unplug the clipper from the power outlet before cleaning, performing maintenance, or when not in use.
- Ensure the power voltage matches the specifications indicated on the charger.
- Keep out of reach of children and pets.
- Follow the recommended cleaning and maintenance instructions to ensure safe operation.

3. PACKAGE CONTENTS

Your Adler AD 2823 Animal Clippers package should contain the following items:

- 1 x Hair Clipper Unit
- 2 x Rechargeable Batteries (one pre-installed, one spare)
- 1 x Charger
- 4 x Attachment Combs (3mm, 6mm, 9mm, 12mm)
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle



Image: All components included in the Adler AD 2823 Animal Clippers package.

4. PRODUCT FEATURES

The Adler AD 2823 Animal Clippers are designed for efficient and comfortable grooming of various animal fur types. Key features include:

- **Versatile Use:** Suitable for all types of fur, including dogs, cats, horses, and sheep.
- **High-Quality Blades:** Equipped with a durable ceramic cutting blade and a titanium shaving head for professional results.
- **Adjustable Cutting Lengths:** Offers 25 different cutting lengths when combining the integrated adjustment with the four attachment combs.
- **Quiet Operation:** Engineered to operate very quietly, making it ideal for sensitive animals.
- **Powerful Motor:** Features a robust 35-watt motor for effective grooming.
- **Dual Battery System:** Comes with two rechargeable batteries for extended cordless operation.





Image: Detail of the clipper's adjustable cutting length dial.

5. SETUP

5.1 Initial Charging

Before first use, fully charge both batteries. Connect the charger to the clipper and plug it into a suitable power outlet. The charging indicator light will illuminate (refer to Section 8 for details). A full charge typically takes several hours.

5.2 Battery Installation

To install or replace a battery, ensure the clipper is turned off. Locate the battery compartment at the bottom of the clipper. Insert the battery, ensuring the contacts align correctly, and push until it clicks into place. To remove, press the release button (if present) and pull the battery out.



Image: The clipper unit alongside its two rechargeable batteries.

5.3 Attaching Combs

Select the desired attachment comb (3mm, 6mm, 9mm, or 12mm). Align the comb with the clipper head and slide it on until it securely clicks into position. To remove, gently push the comb upwards from the back and slide it off.






Image: Side view of the clipper, illustrating the attachment comb area.

6. OPERATING INSTRUCTIONS

6.1 Preparation for Grooming

Before clipping, ensure the animal's fur is clean, dry, and free of tangles or mats. Brush the fur thoroughly to remove any loose hair or debris. This will help prevent the blades from snagging and ensure a smoother cut.

6.2 Powering On/Off

To turn the clipper on, slide the power switch located on the front of the unit to the 'ON' position. To turn it off, slide the switch back to the 'OFF' position.

6.3 Clipping Technique

Hold the clipper firmly and comfortably. Always clip in the direction of hair growth for a smoother finish and to avoid irritating the animal's skin. Use gentle, even strokes. For sensitive areas, proceed with extra caution and ensure the animal is calm.



Image: The clipper held in a typical operating position.

7. ADJUSTING CUTTING LENGTHS

The Adler AD 2823 offers a wide range of cutting lengths for various grooming needs:

- **Integrated Adjustment (0.8mm - 2.0mm):** The clipper features a rotating dial near the blade that allows for fine adjustment of cutting lengths from 0.8mm to 2.0mm without any attachments. Rotate the dial to select your desired length.
- **Attachment Combs (3mm, 6mm, 9mm, 12mm):** For longer cutting lengths, use the provided attachment combs. These combs can be used in conjunction with the integrated adjustment for even more precise length control, offering a total of 25 possible cutting lengths.






Image: Detailed view of the clipper's integrated length adjustment dial.

8. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your clippers.

8.1 Cleaning

After each use, turn off and unplug the clipper. Use the provided cleaning brush to remove any trapped hair from the blades and the clipper head. For thorough cleaning, the ceramic blade can be carefully removed (refer to the diagram or specific instructions if provided with the product for blade removal). Ensure all hair is removed before reassembling.



Image: Close-up of the clipper blade, highlighting areas for cleaning.

8.2 Oiling

Regular oiling of the blades is crucial for smooth operation and to prevent wear. After cleaning, apply a few drops of the included lubricating oil to the teeth of the blades. Turn the clipper on for a few seconds to distribute the oil evenly. Wipe off any excess oil with a soft cloth.

9. BATTERY INFORMATION

The Adler AD 2823 comes with two rechargeable batteries, allowing for extended cordless use. The clipper can also be operated directly from the charger when plugged into a power outlet.

- **Charging Indicator:** The clipper features a battery indicator light that shows the charging status. A red light typically indicates charging, while a green or off light indicates a full charge or no charging.
- **Battery Life:** Each battery provides a significant amount of operating time when fully charged. Actual run time may vary based on fur type and thickness.
- **Battery Care:** To maximize battery life, avoid completely draining the battery before recharging. Store the clipper and batteries in a cool, dry place.





Image: The battery indicator light on the clipper unit.

10. TROUBLESHOOTING

If you encounter issues with your Adler AD 2823 Animal Clippers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is not charged or not inserted correctly.	Ensure battery is fully charged and properly inserted. Try operating with the charger plugged in.
Poor cutting performance or snagging.	Blades are dull, dirty, or not oiled. Fur is tangled or matted.	Clean blades thoroughly and apply lubricating oil. Ensure fur is clean and detangled before clipping. Consider replacing blades if excessively dull.
Clipper becomes hot during use.	Extended continuous use. Blades are dirty or not oiled, causing friction.	Allow the clipper to cool down. Clean and oil the blades. Avoid prolonged continuous operation.
Clipper is unusually loud.	Blades require oiling.	Apply lubricating oil to the blades.

If the problem persists after trying these solutions, please contact ADLER customer support for further assistance.

11. SPECIFICATIONS

Brand	ADLER
Model Number	Adler_AD 2823
Power	35 Watts
Blade Material	Ceramic, Titanium
Cutting Lengths (Clipper Only)	0.8mm, 1.1mm, 1.4mm, 1.7mm, 2.0mm
Attachment Combs	3mm, 6mm, 9mm, 12mm
Dimensions (L x W x H)	30 x 30 x 10 cm
Item Weight	579.99 g (approx. 1.28 Pounds)
Color	Silver, Black
Power Source	Corded Electric, Battery

12. WARRANTY AND SUPPORT

ADLER products are manufactured to high-quality standards and are guaranteed against manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official ADLER website.


For technical support, spare parts, or any inquiries regarding your Adler AD 2823 Animal Clippers, please contact ADLER customer service. Contact information can typically be found on the ADLER website or on your product packaging.

Visit the ADLER Store: [ADLER EUROPE Store on Amazon](#)

Copyright © 2024 ADLER. All rights reserved.

Related Documents - Adler_AD 2823

 AD 2836 <small>(DE) user manual - 3 (EN) user manual - 5 (ES) manual del usuario - 7 (FR) manuel de l'utilisateur - 11 (IT) manuale utente - 13 (NL) gebruiksaanwijzing - 15 (PL) instrukcja obsługi - 17 (RO) instrucție de utilizare - 19 (SV) användarhandledning - 21 (HU) használati útmutató - 23 (CS) uživatelská příručka - 25 (PT) manual de utilização - 27 (GR) οδηγίες χρήσης - 29 (SK) používateľská príručka - 31 (FI) käyttöohje - 33 (HR) uporabna navodila - 35 (EL) οδηγίες χρήσης - 37 (UK) користувачка інструкція - 39 (UA) користувачка інструкція - 39</small>	<p>Adler AD 2836 Hair Trimmer User Manual and Safety Instructions Comprehensive user manual for the Adler AD 2836 hair trimmer, covering safety instructions, operation, charging, cleaning, and technical specifications in multiple languages.</p>
 AD 2936 <small>(DE) user manual - 3 (EN) user manual - 5 (ES) manual del usuario - 7 (FR) manuel de l'utilisateur - 11 (IT) manuale utente - 13 (NL) gebruiksaanwijzing - 15 (PL) instrukcja obsługi - 17 (RO) instrucție de utilizare - 19 (SV) användarhandledning - 21 (HU) használati útmutató - 23 (CS) uživatelská příručka - 25 (PT) manual de utilização - 27 (GR) οδηγίες χρήσης - 29 (SK) používateľská príručka - 31 (FI) käyttöohje - 33 (HR) uporabna navodila - 35 (EL) οδηγίες χρήσης - 37 (UK) користувачка інструкція - 39 (UA) користувачка інструкція - 39</small>	<p>ADLER AD 2936 User Manual and Safety Instructions Comprehensive user manual and safety guide for the ADLER AD 2936 electric shaver, covering operation, cleaning, and important safety precautions in multiple languages.</p>
 AD 2112 <small>(DE) user manual - 3 (EN) user manual - 5 (ES) manual del usuario - 7 (FR) manuel de l'utilisateur - 11 (IT) manuale utente - 13 (NL) gebruiksaanwijzing - 15 (PL) instrukcja obsługi - 17 (RO) instrucție de utilizare - 19 (SV) användarhandledning - 21 (HU) használati útmutató - 23 (CS) uživatelská příručka - 25 (PT) manual de utilização - 27 (GR) οδηγίες χρήσης - 29 (SK) používateľská príručka - 31 (FI) käyttöohje - 33 (HR) uporabna navodila - 35 (EL) οδηγίες χρήσης - 37 (UK) користувачка інструкція - 39 (UA) користувачка інструкція - 39</small>	<p>Adler AD 2112 Hair Curler User Manual Comprehensive user manual for the Adler AD 2112 hair curler, providing safety instructions, operating guidelines, and maintenance tips in multiple languages.</p>
 AD 2270 <small>(DE) user manual - 3 (EN) user manual - 5 (ES) manual del usuario - 7 (FR) manuel de l'utilisateur - 11 (IT) manuale utente - 13 (NL) gebruiksaanwijzing - 15 (PL) instrukcja obsługi - 17 (RO) instrucție de utilizare - 19 (SV) användarhandledning - 21 (HU) használati útmutató - 23 (CS) uživatelská příručka - 25 (PT) manual de utilização - 27 (GR) οδηγίες χρήσης - 29 (SK) používateľská príručka - 31 (FI) käyttöohje - 33 (HR) uporabna navodila - 35 (EL) οδηγίες χρήσης - 37 (UK) користувачка інструкція - 39 (UA) користувачка інструкція - 39</small>	<p>ADLER AD 2270 Hair Dryer User Manual and Safety Instructions Comprehensive user manual for the ADLER AD 2270 hair dryer, featuring detailed safety instructions, device operation, cleaning, and maintenance guidelines for optimal performance and user safety.</p>



AD 2318

[ADLER AD 2318 Hair Straightener User Manual](#)

Comprehensive user manual for the ADLER AD 2318 hair straightener, covering safety instructions, device description, usage guidelines, and cleaning procedures. Includes technical specifications and environmental disposal information.



AD 2326

[ADLER AD 2326 Hair Straightener User Manual](#)

Comprehensive user manual for the ADLER AD 2326 hair straightener, detailing safety instructions, device description, usage for straightening and curling, cool air function, automatic shut-off, cleaning, and technical specifications.