

Manuals.plus /

› Swarovski /

› Swarovski SK 5148 Eyeglasses User Manual

## Swarovski SK 5148

# Swarovski SK 5148 Eyeglasses User Manual

## INTRODUCTION

This user manual provides essential information for the proper use, care, and maintenance of your Swarovski SK 5148 eyeglasses. Please read these instructions carefully to ensure the longevity and optimal performance of your eyewear. The Swarovski SK 5148 eyeglasses feature a durable metal frame and are designed for daily wear.



Image: Front view of the Swarovski SK 5148 eyeglasses, showcasing the gold metal frame and clear lenses.

## SETUP AND INITIAL FITTING

---

Upon receiving your new Swarovski SK 5148 eyeglasses, it is recommended to have them professionally fitted by an optician. Proper fitting ensures comfort, stability, and correct optical alignment.

### Unboxing

1. Carefully remove the eyeglasses from their protective case.
2. Inspect the frames for any visible damage or loose components.
3. Retain the original packaging and case for safe storage when not in use.

### Professional Adjustment

An optician can adjust the frame temples, nose pads, and overall fit to conform to your facial structure. This prevents slippage and discomfort.



Image: Angled side view of the Swarovski SK 5148 eyeglasses, showing the temple arm design and nose pads.

## OPERATING INSTRUCTIONS

---

Proper handling of your eyeglasses will help maintain their shape and integrity.

### Wearing and Removing

- Always use both hands to put on and take off your eyeglasses. Grasp the temples near the hinges to avoid bending the frame or misaligning the lenses.
- Avoid pushing the eyeglasses onto your head or hanging them on your shirt collar, as this can distort the frame.

## Adjusting Nose Pads

The nose pads are designed to distribute weight evenly and prevent slippage. If they feel uncomfortable or the glasses slide down, a minor adjustment can be made. For significant adjustments, consult an optician.



Image: Side view of the Swarovski SK 5148 eyeglasses, highlighting the temple arm with Swarovski branding and crystal embellishments.

## MAINTENANCE AND CARE

Regular cleaning and proper storage are crucial for maintaining the clarity of your lenses and the condition of your frame.

### Cleaning Instructions

- **Hand wash only:** As per manufacturer specifications, clean your eyeglasses by hand.
- Rinse your lenses under lukewarm running water to remove dust and debris.
- Apply a small drop of mild dish soap to each lens. Gently rub both sides of the lenses and all parts of the frame.
- Rinse thoroughly with lukewarm water.
- Dry the lenses and frame with a clean, lint-free microfiber cloth specifically designed for eyewear. Avoid using paper towels or clothing, which can scratch the lenses.

- Do not use harsh chemicals, ammonia-based cleaners, or abrasive materials.

## Storage

When not wearing your eyeglasses, always store them in their protective case. This prevents scratches, bending, and exposure to extreme temperatures.



Image: Rear angled view of the Swarovski SK 5148 eyeglasses, showing the inner side of the temple arms and the frame's curvature.

## TROUBLESHOOTING

Here are some common issues and general advice:

- **Loose Screws:** Small screws can sometimes loosen. If you have an eyewear repair kit, you can gently tighten them. Avoid overtightening.
- **Bent Frame:** If the frame becomes bent or misaligned, do not attempt to forcefully straighten it yourself, as this can cause breakage.
- **Scratched Lenses:** Scratches on lenses cannot be removed. To prevent scratches, always clean with appropriate materials and store in a case.
- **Persistent Discomfort:** If your eyeglasses continue to feel uncomfortable or cause pressure points after initial fitting, revisit your optician for further adjustments.

For any significant repairs or adjustments, it is always recommended to consult a professional optician.



Image: Top-down view of the Swarovski SK 5148 eyeglasses, showing the frame's upper rim and the hinge mechanism.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Swarovski
Model Number	SK 5148 (Internal Model: 664689664894)
Generic Name	Eyeglasses (listed as sunglasses in some specifications)
Material Composition	Metal
Department	Men
Product Dimensions (LxWxH)	15.24 x 5.08 x 5.08 cm
Item Weight	272 g
Care Instructions	Hand wash only
Date First Available	27 September 2015



Image: Three-quarter view of the Swarovski SK 5148 eyeglasses from above, showing the overall shape and temple arms.

## WARRANTY INFORMATION

---

Specific warranty details for your Swarovski SK 5148 eyeglasses are typically provided at the point of purchase or directly by the manufacturer. Please refer to any documentation included with your product or contact the retailer where the item was purchased for comprehensive warranty terms and conditions.

## CUSTOMER SUPPORT

---

For further assistance, product inquiries, or service requests, please contact your authorized Swarovski retailer or visit the official Swarovski website. You can also visit the Swarovski Store on Amazon for more information.