

[Manuals.plus](#) /

› [Hamilton Beach](#) /

› Hamilton Beach 18-Inch Stand Fan Model H01SF015 Instruction Manual

Hamilton Beach H01SF015

Hamilton Beach 18-Inch Stand Fan Instruction Manual

Model: H01SF015

1. INTRODUCTION

Thank you for purchasing the Hamilton Beach 18-Inch Stand Fan, Model H01SF015. This manual provides important information regarding the safe operation, assembly, maintenance, and troubleshooting of your new fan. Please read these instructions thoroughly before use and retain them for future reference.






Image: The Hamilton Beach 18-Inch Stand Fan in black, featuring its round base, adjustable pole, and fan head with a metal grill.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Use this fan only as described in this manual. Other uses not recommended may cause fire, electric shock, or injury to persons.
- To protect against electrical shock, do not immerse unit, plug, or cord in water or spray with liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as it may cause an electric shock or fire, or damage the fan.
- Do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always place the fan on a stable, flat, level surface during operation to prevent the fan from tipping over.
- This product is intended for household use ONLY and not for commercial or industrial use.

3. PACKAGE CONTENTS

Please check the contents of the package. If any parts are missing or damaged, do not attempt to assemble or operate the fan. Contact customer support for assistance.

- Fan Motor Unit with Control Panel
- Front Grill
- Rear Grill
- Fan Blade
- Grill Retaining Nut
- Blade Retaining Nut
- Adjustable Height Pole (Upper and Lower sections)
- Round Base
- Base Screws (typically 3-4)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Hamilton Beach Stand Fan:

1. **Assemble the Base:** Place the round base on a flat surface. Insert the lower section of the adjustable height pole into the center hole of the base. Secure it from underneath with the provided base screws.
2. **Attach the Upper Pole:** Insert the upper section of the adjustable height pole into the lower section. Adjust to your desired height and tighten the height adjustment knob.
3. **Mount the Motor Unit:** Place the fan motor unit onto the top of the adjustable pole. Ensure it is securely seated and tighten any securing screws or knobs.
4. **Install the Rear Grill:** Remove the grill retaining nut from the motor unit shaft. Position the rear grill against the motor unit, aligning the mounting holes or clips. Secure it with the grill retaining nut, turning clockwise.
5. **Attach the Fan Blade:** Slide the fan blade onto the motor shaft, ensuring the notch on the blade aligns with the pin on the shaft. Secure the blade with the blade retaining nut, turning counter-clockwise to tighten.
6. **Secure the Front Grill:** Place the front grill over the rear grill, aligning the clips or securing tabs. Fasten the front grill to the rear grill using the provided clips or screws around the perimeter. Ensure the grill is firmly closed and secured.

Note: Ensure all parts are securely fastened before operating the fan.

5. OPERATING INSTRUCTIONS

Your Hamilton Beach Stand Fan is designed for ease of use. Follow these steps to operate your fan:

- **Power Connection:** Plug the fan's power cord into a standard 120V, 60Hz electrical outlet.
- **Adjust Height:** Loosen the height adjustment knob on the pole, raise or lower the fan to your desired height, and then firmly tighten the knob.
- **Adjust Tilt:** The fan head can be tilted up or down. Loosen the tilt adjustment knob (usually on the side of the motor unit), adjust the angle, and then tighten the knob.
- **Select Speed:** Use the control buttons or rotary switch on the fan motor unit to select your desired speed setting. The fan typically offers three speeds: 1 (Low), 2 (Medium), and 3 (High).
- **Oscillation Function:** To activate the oscillation feature (where the fan head moves from side to side), press down the oscillation knob located on top of the motor unit. To stop oscillation, pull the knob up.
- **Power Off:** To turn off the fan, select the '0' or 'OFF' setting on the control panel, then unplug the fan from the electrical outlet when not in use.

6. CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and efficient operation of your fan.

- **Cleaning:** Always unplug the fan before cleaning. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or harsh chemicals. For cleaning the fan blades and inside the grill, you may need to carefully remove the front grill (refer to assembly instructions in reverse). Ensure all parts are completely dry before reassembling and operating the fan.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.
- **No Lubrication:** The fan motor is permanently lubricated and requires no additional lubrication.

7. TROUBLESHOOTING

If your fan is not operating correctly, please refer to the following common issues and solutions:

| Problem | Possible Cause | Solution |
|---|--|---|
| Fan does not turn on. | Not plugged in; power outlet not working; fan switch is off. | Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker. Turn the fan switch to an ON position. |
| Fan makes unusual noise (e.g., rattling). | Loose fan blades or grill components; foreign object inside grill. | Unplug the fan. Check that the fan blades and both grills are securely fastened. Remove any foreign objects. |
| Fan oscillates but does not blow air effectively. | Grills are blocked; fan blades are dirty. | Unplug the fan. Ensure air intakes and exhausts are not blocked. Clean fan blades and grills as per maintenance instructions. |

| Problem | Possible Cause | Solution |
|---|-------------------------------------|--|
| Fan head is unstable or detaches from base. | Pole or base connections are loose. | Unplug the fan. Re-tighten all screws and knobs securing the pole to the base and the motor unit to the pole. Ensure all assembly steps were followed correctly. |

If the problem persists after checking these points, please contact customer support.

8. SPECIFICATIONS

- **Brand:** Hamilton Beach
- **Model Number:** H01SF015
- **Color:** Black
- **Fan Type:** Pedestal Fan
- **Blade Diameter:** 18 inches
- **Number of Speeds:** 3
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Frequency:** 60 Hz
- **Wattage:** 30 watts
- **Number of Blades:** 3
- **Material:** Metal (grill), Plastic (blades)
- **Product Dimensions (D x W x H):** 19.5" x 19.5" x 46.5"
- **Special Feature:** Lightweight, Oscillating, Adjustable Height
- **GTIN/UPC:** 794560180158

9. WARRANTY AND SUPPORT

Limited Warranty: The manufacturer warrants that your Hamilton Beach 18-inch stand fan, Model No. H01SF015, for a period of one year from the date of original purchase, will be free from all defects in material and workmanship. This limited warranty is granted only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. Warranty is valid in the USA and Canada only.

Customer Support: For warranty claims, technical assistance, or any questions regarding your product, please contact Hamilton Beach customer service. Refer to the official Hamilton Beach website or product packaging for the most current contact information.