

[Manuals.plus](#) /

› [Hamilton Beach](#) /

› Hamilton Beach 16-Inch Oscillating Pedestal Fan User Manual

Hamilton Beach H01SF010

Hamilton Beach 16-Inch Oscillating Pedestal Fan User Manual

Model: H01SF010

INTRODUCTION

Thank you for purchasing the Hamilton Beach 16-inch Oscillating Pedestal Fan. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your fan. Please read it thoroughly before use and retain it for future reference.






Image: The Hamilton Beach 16-inch Oscillating Pedestal Fan, featuring a black finish, a round base, an adjustable height pole, and a fan head with a metal grill and three blades. The control panel is visible on the fan's main body.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Always unplug the fan from the power outlet before cleaning or servicing.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.

- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not block air openings or operate with any openings blocked. Keep all air openings free of dust, lint, hair, and anything that may reduce airflow.
- Do not use outdoors.
- This fan is intended for household use only and not for commercial or industrial use.

SETUP AND ASSEMBLY

The Hamilton Beach 16-inch Pedestal Fan requires some assembly before first use. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: fan head assembly (motor, blades, grills), adjustable pole, and round base.
2. **Assemble the Base:** Place the round base on a flat, stable surface. Insert the bottom part of the adjustable pole into the center opening of the base. Secure it firmly, typically with a large screw or knob from underneath the base.
3. **Attach Fan Head:** Connect the fan head assembly to the top of the adjustable pole. Ensure it clicks into place or is secured with the provided fastening mechanism.
4. **Adjust Height:** Loosen the height adjustment knob on the pole, extend the pole to your desired height, and then tighten the knob securely.
5. **Positioning:** Place the assembled fan on a firm, level surface where it cannot be easily tipped over. Ensure the power cord is not obstructed or in a high-traffic area.

Note: Assembly is required for this product. Refer to the included assembly diagram for visual guidance if available.

OPERATING INSTRUCTIONS

Your Hamilton Beach Pedestal Fan is designed for ease of use. Follow these steps to operate your fan:

1. **Power Connection:** Plug the fan's power cord into a standard 120V, 60Hz electrical outlet.
2. **Turn On/Off:** Locate the control buttons on the fan's body. Press the appropriate button to turn the fan ON.
3. **Select Speed:** This fan features three adjustable speeds. Press the corresponding speed button (1, 2, or 3) to select your desired airflow intensity. Speed 1 is the lowest, and Speed 3 is the highest.
4. **Activate Oscillation:** To enable the oscillating function (where the fan head sweeps from side to side), pull up the oscillation knob located on top of the motor housing. To stop oscillation, push the knob down.
5. **Adjust Tilt:** The fan head can be tilted up or down to direct airflow. Gently push or pull the fan head to the desired angle.
6. **Turn Off:** To turn off the fan, press the '0' or 'OFF' button, or unplug the fan from the power outlet.

CARE AND MAINTENANCE

Regular cleaning and proper storage will help prolong the life of your Hamilton Beach fan.

- **Cleaning:**
 - Always unplug the fan before cleaning.
 - Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
 - To clean the fan blades and inside the grill, you may need to carefully remove the front grill. Refer to the

assembly instructions for reverse steps. Use a soft cloth or vacuum cleaner with a brush attachment to remove dust and debris from the blades and motor housing.

- Ensure all parts are completely dry before plugging the fan back in.

- **Storage:**

- When not in use, store the fan in a cool, dry place.
- It is recommended to store the fan in its original packaging or cover it to protect it from dust.

TROUBLESHOOTING GUIDE

If your fan is not operating correctly, please consult the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in. No power at outlet. Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker or try another outlet. Press the 'ON' or desired speed button.
Fan is noisy or vibrates.	Loose parts. Fan not on a level surface. Dust buildup on blades.	Check that all assembly screws and connections are tight. Place the fan on a stable, level surface. Clean the fan blades and grills as per maintenance instructions.
Oscillation not working.	Oscillation knob not pulled up.	Ensure the oscillation knob on top of the motor housing is pulled up.

If the problem persists after trying these solutions, please contact customer support.

PRODUCT SPECIFICATIONS

Model: H01SF010

Brand: Hamilton Beach

Type: Oscillating Pedestal Fan

Size: 16 Inches (40.6 cm)

Color: Black

Speeds: 3 Adjustable Speeds

Power Source: Corded Electric

Voltage: 120V, 60Hz

Dimensions (assembled): Approximately 18 x 18 x 48.5 inches (45.72 x 45.72 x 123.19 cm)

Weight: Approximately 9 lbs (4.08 kg)

Material: Metal grill, plastic blades, plastic base

Special Features: Lightweight, Oscillating, Adjustable Height

Assembly Required: Yes

WARRANTY AND SUPPORT

Hamilton Beach provides a limited warranty for this product. The manufacturer guarantees that your Hamilton Beach 16-inch fan, model H01SF010, will be free from defects in material and workmanship for a period of **one year** from the original purchase date.

This limited warranty is granted only to the original purchaser or gift recipient. Please retain your original sales receipt as proof of purchase is required to make a claim. The warranty is valid only in the United States and Canada.

For warranty claims, technical support, or replacement parts, please contact Hamilton Beach customer service. Contact information can typically be found on the Hamilton Beach official website or on the product packaging.

For more information, please refer to the official Hamilton Beach website: www.hamiltonbeach.com

