

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Swan](#) /

› [Swan SWKA1020BN Retro Kitchen Storage Canisters User Manual](#)

## Swan SWKA1020BN

# Swan SWKA1020BN Retro Kitchen Storage Canisters User Manual

Model: **SWKA1020BN** | Brand: **Swan**

## INTRODUCTION

This manual provides instructions for the safe and effective use of your Swan Retro Kitchen Storage Canisters. This set includes three iron canisters designed for storing kitchen perishables like tea, coffee, and sugar. Featuring a retro-inspired design with elegant chrome detailing, these canisters offer both functionality and style for your kitchen.

Each canister has a generous 1-liter capacity, providing ample storage space. The durable iron construction ensures longevity, while the snap closure helps maintain an airtight seal for your stored items.

## SETUP

- Unpacking:** Carefully remove all three canisters and their lids from the packaging. Inspect for any damage during transit.
- Initial Cleaning:** Before first use, hand wash each canister and lid with warm, soapy water. Rinse thoroughly to remove all soap residue.
- Drying:** Dry all components completely with a soft, clean cloth to prevent water spots and potential rust.
- Placement:** Place the canisters on a stable, flat surface in your kitchen, away from direct heat sources or excessive moisture.



Image: The Swan Retro Kitchen Storage Canisters in use, showcasing their design and capacity for items like tea bags.

## OPERATING INSTRUCTIONS

- **Opening:** To access the contents, gently lift the lid from the canister.
- **Filling:** Fill the canister with your desired dry goods, such as tea, coffee, or sugar. Do not overfill.
- **Closing:** To close, align the lid with the canister opening and press down firmly around the edges until the snap closure engages. This creates an airtight seal to keep contents fresh.
- **Intended Use:** These canisters are designed for dry food storage only. Do not use for liquids or items requiring refrigeration.

## MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Swan Retro Kitchen Storage Canisters.

- **Cleaning:** Hand wash only. *Do not use a dishwasher.* Wash with warm, soapy water using a soft sponge or cloth.
- **Drying:** Rinse thoroughly and dry immediately with a soft, lint-free cloth. Ensuring complete dryness is crucial to

prevent water spots and rust, especially on the iron body and chrome detailing.

- **Avoid Abrasives:** Do not use abrasive cleaners, harsh chemicals, or scouring pads, as these can scratch the finish and damage the chrome.
- **Storage:** Store in a dry environment. Avoid areas with high humidity.

## TROUBLESHOOTING

- **Lid not sealing properly:** Ensure the lid is correctly aligned with the canister body. Press down firmly around the entire rim until the snap closure engages. Check for any food particles or debris on the rim that might obstruct the seal.
- **Appearance of rust spots:** These canisters are made of iron. To prevent rust, always hand wash and dry immediately after cleaning. Avoid leaving them wet or in highly humid conditions. Minor rust spots can often be gently removed with a mild metal polish or a paste of baking soda and water, followed by thorough drying.
- **Scratches on surface:** Avoid using abrasive cleaning tools or harsh chemicals. Handle with care to prevent impacts that could chip or scratch the finish.

## SPECIFICATIONS

- **Model Number:** SWKA1020BN
- **Product Dimensions (each):** 4.72" L x 4.72" W x 6.89" H (12cm L x 12cm W x 17.5cm H)
- **Item Volume (each):** 1 Liter
- **Unit Count:** 3 Canisters
- **Material:** Iron with chrome detailing
- **Color:** Black
- **Container Shape:** Square
- **Closure Type:** Snap, Air Tight
- **Care Instructions:** Hand Wash Only
- **Dishwasher Safe:** No
- **Microwaveable:** No
- **Item Weight (set):** Approximately 2.84 pounds (1.29 Kilograms)

## WARRANTY

This Swan product is covered by a 2-year guarantee from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your proof of purchase for any warranty claims.

The warranty does not cover damage resulting from:

- Misuse or abuse of the product.
- Neglect or failure to follow the care and maintenance instructions provided in this manual.
- Accidental damage, alterations, or repairs not authorized by Swan.
- Normal wear and tear.

## SUPPORT

For further assistance, product information, or to make a warranty claim, please visit the official Swan website. You can find contact details for customer support on their website or within the product packaging.

Official Swan Website: [www.swan-brand.co.uk](http://www.swan-brand.co.uk) (Please note: This link is for informational purposes and may vary by region.)

