

NEFF B014SAVR2M

NEFF Daily Woven Watch User Manual

Model: B014SAVR2M

1. INTRODUCTION

Thank you for choosing the NEFF Daily Woven Watch. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new timepiece. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.



Figure 1: Front view of the NEFF Daily Woven Watch. It features a black watch case with a black dial, red hour markers, and red hands. The watch is fitted with a multi-colored woven fabric strap, displaying patterns in black, white, purple, green, blue, and orange hues.

2. SETUP

2.1 Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the first click position. The watch hands will stop moving.
3. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position. The watch hands will resume movement.

2.2 Wearing the Watch

Adjust the woven strap to fit comfortably around your wrist. Ensure it is snug but not too tight to allow for proper circulation.

3. OPERATING THE WATCH

The NEFF Daily Woven Watch is a simple analog timepiece designed for straightforward timekeeping. Once the time is set, no further adjustments are typically needed unless the time zone changes or the watch stops.

- **Reading the Time:** The large red numbers at 12, 3, and 9 o'clock, along with the red hour and minute hands, provide clear visibility for reading the current time.
- **Daily Use:** This watch is designed for everyday wear. While durable, avoid exposing it to extreme conditions or impacts.

4. MAINTENANCE

4.1 Cleaning

- To clean the watch case, gently wipe it with a soft, dry cloth.
- For the woven strap, a slightly damp cloth can be used to remove surface dirt. Allow the strap to air dry completely before wearing. Do not immerse the strap in water.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or strap material.

4.2 Water Resistance

This watch is designed for daily wear and can withstand minor splashes or rain. *It is not suitable for swimming, showering, or diving.* Avoid prolonged exposure to water to prevent damage to the internal components and the woven strap.

4.3 Battery Replacement

The watch is powered by a standard watch battery. When the watch stops, it indicates the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not running	Dead battery	Replace battery (professional service recommended).
Time is incorrect	Time not set correctly or crown pulled out	Reset the time using the crown. Ensure crown is fully pushed in.
Condensation inside crystal	Exposure to moisture	Avoid further moisture exposure. Seek professional service if condensation persists.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact NEFF customer support.

6. SPECIFICATIONS

- **Model:** B014SAVR2M
- **Department:** Unisex-adult
- **Movement:** Quartz (Battery-powered)
- **Case Material:** Durable Plastic/Resin
- **Strap Material:** Woven Fabric
- **Water Resistance:** Splash resistant (not for swimming/showering)

7. WARRANTY AND SUPPORT

NEFF products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official NEFF website. For technical support or service inquiries, please contact NEFF customer service through their official channels.

You can find more information and contact details on the [NEFF Store on Amazon](#).

Related Documents



[Neff Microwave Oven User Manual: Operation, Safety, and Cooking Guide](#)

Comprehensive user manual for Neff Microwave Ovens (models C1AMG84N0, C1AMG84N0B, C1CMG84N0) covering safety, operation, cleaning, troubleshooting, and cooking tips.




[NEFF S247HDS01A Dishwasher User Manual](#)

Official user manual for the NEFF S247HDS01A dishwasher by Constructa Neff Vertriebs-GmbH. Provides comprehensive guidance on installation, operation, safety features, programmes, basic settings, troubleshooting, and maintenance for optimal appliance performance.



[NEFF Extractor Hood User Manual and Installation Guide](#)

Comprehensive user manual and installation guide for NEFF extractor hood models D49PU54X1, D49PU54X1B, and D46PU54X1, covering operation, safety, cleaning, and installation.



[Neff S195HCX02G Dishwasher Quick Reference Guide | Neff Appliances](#)

Concise guide for the Neff S195HCX02G dishwasher, covering setup, water hardness, programmes, usage, cleaning, and troubleshooting. Learn how to operate your Neff dishwasher efficiently.