

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [myTouchSmart](#) /

› [myTouchSmart Programmable Indoor Digital Timer Instruction Manual](#)

## myTouchSmart 26892

# myTouchSmart Programmable Indoor Digital Timer Instruction Manual

BRAND: MYTOUCHSMART

Model: 26892

## Introduction

The myTouchSmart Plug-In Digital Timer is designed to help you save time, money, and energy by automating the scheduling of your indoor lights, lamps, small appliances, electronics, and seasonal lighting. This timer allows you to set specific ON/OFF times, choose from convenient presets, or utilize a custom countdown feature to suit your daily schedule and needs. It features a single polarized outlet, a large digital display, and blue LED indicators for active programs, ensuring ease of use and reliable performance.

## Setup

Setting up your myTouchSmart Digital Timer is straightforward. Follow these steps to get started:

1. **Plug In:** Insert the timer into a standard indoor wall outlet. Ensure it is securely plugged in.
2. **Set Current Time:** Use the up and down arrow buttons (▲ and ▼) to scroll and set the current time on the digital display.
3. **Program Settings:** You can choose from preset options or set custom ON/OFF times.

Indoor Digital

myTOUCH  
SMART™

# Simple Set Plug-In Timer

Schedule indoor lights or other devices



3 Daily  
Preset Options



Custom Daily  
On/Off Time



Custom Countdown  
up to 24 hours



Backup Battery  
Saves Settings



LED, CFL, Incandescent  
and Halogen Compatible

See back for details\*



## SIMPLE SETUP

- 1 Just scroll to set the current time.
- 2 Simply set your custom on & off time and pick any of the presets that suit your schedule!



Polarized Outlet

Image: Fast, Easy Setup Guide. This image illustrates the two main steps for setting up the timer: scrolling to set the current time and then setting custom ON/OFF times or choosing presets.



Image: Timer Plugged In. The myTouchSmart Digital Timer is shown plugged into a standard wall outlet, with a red canister and wooden spoon in the foreground, indicating indoor use.

**Your browser does not support the video tag.**

Video: myTouchSmart 26892 Indoor Digital Timer Overview. This video demonstrates the basic setup and programming options of the myTouchSmart timer, including setting the current time and utilizing preset and custom ON/OFF functions.

## Operating Instructions

The myTouchSmart Digital Timer offers various programming options for flexible control:

- **Custom ON/OFF Times:** Use the "my on time" and "my off time" buttons to set specific daily turn-on and turn-off times. You can create up to two distinct custom daily ON/OFF times.
- **Daily Presets:**
  - **Evening (5pm-12am):** Automatically turns on in the evening and off at midnight.

- **Morning (5am-8am):** Automatically turns on in the morning and off after a few hours.
- **All Night (6pm-6am):** Keeps the connected device on throughout the night.

• **Countdown Feature:** Use the "countdown" button to set a specific duration (up to 24 hours in 1-minute intervals) after which the connected device will turn off.



Image: Programming Options. This image highlights the custom ON/OFF time buttons, simple daily preset options (Evening, Morning, All Night), and the custom countdown feature on the timer's interface.

my  
TOUCH  
SMART




Image: Display and Button Functions. This image details the digital display, indicating clock vs. countdown mode, and points out the scroll buttons for time setting, custom ON/OFF time buttons, and the active program indicator.

## Features

- Energy and Cost Savings:** Automate your lighting and appliance schedules to reduce energy consumption and save on electricity bills.
- Versatile Scheduling:** Offers both custom daily ON/OFF times and three convenient daily presets (Evening, Morning, All Night) for various needs.
- Countdown Timer:** Set a countdown from 1 minute up to 24 hours for temporary control.
- Single Polarized Outlet:** Equipped with one polarized outlet located on the right side of the timer.
- Broad Compatibility:** Works with LED, CFL, Incandescent, and Halogen bulbs, including dimmable LED and CFL bulbs.
- Digital Display & LED Indicators:** Features a large digital display for easy reading and blue LED indicator lights to

show active programs.

- **Backup Battery:** An internal backup battery preserves your settings during power outages or if the timer is temporarily disconnected from the outlet.



## Schedule indoor lights or other devices



Lamps



Small Appliances



Electronics



Seasonal

Image: Schedule Indoor Devices. This image highlights the versatility of the timer for scheduling various indoor devices, including lamps, small appliances, electronics, and seasonal lighting.



# FAST, EASY SETUP

**1** Just scroll to set the current time.

**2** Simply set custom ON/OFF times and pick any of the presets that suit your schedule!



Image: Deters Crime. This image shows the timer being used to automate lights, creating the impression of an occupied home to deter potential intruders.

## Maintenance

To ensure the longevity and optimal performance of your myTouchSmart Digital Timer, follow these simple maintenance guidelines:

- Cleaning:** Disconnect the timer from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- Storage:** When not in use for extended periods, store the timer in a cool, dry place away from direct sunlight and extreme temperatures.
- Environmental Conditions:** This timer is designed for indoor use only. Avoid exposing it to moisture, humidity, or extreme temperatures.

## Troubleshooting

If you encounter issues with your myTouchSmart Digital Timer, consider the following common solutions:

- **Timer Not Turning On/Off:**

- Ensure the timer is securely plugged into a working outlet.
- Verify that the connected appliance or light is properly plugged into the timer's outlet and is in working condition.
- Check that the programmed ON/OFF times or preset options are correctly set and active (indicated by blue LED lights).

- **Settings Lost After Power Outage:**

- The timer has a backup battery designed to retain settings during brief power interruptions. If settings are lost, the battery may be depleted or the power outage was prolonged. Re-program the desired settings.

- **Display Not Working:**

- Ensure the timer is receiving power. If the display remains blank, try plugging it into a different outlet.

## Specifications

<b>Brand</b>	myTouchSmart
<b>Model Number</b>	26892
<b>Color</b>	White
<b>Material</b>	Plastic
<b>Product Dimensions</b>	2.55"D x 5.92"W x 7.3"H
<b>Item Weight</b>	4 ounces
<b>Electrical Ratings</b>	125V 50/60 Hz, 15A 1875W General Purpose / Resistive, 10A 1250W Tungsten ½ HP
<b>Number of Settings</b>	4 (Custom ON/OFF, Evening, Morning, All Night, Countdown)
<b>UPC</b>	030878268929
<b>Certification</b>	UL Listed (Note: Product information also mentions CSA listed)
<b>Included Components</b>	Mytouchsmart(tm) Indoor Plug-in Digital Timer

## Warranty and Support

The myTouchSmart Digital Timer comes with a **One-year limited warranty** from the manufacturer.



For detailed information, troubleshooting, or support, please refer to the official user guide:

[Download User Manual \(PDF\)](#)

You can also visit the manufacturer's website for more information: [jascoproducts.com](http://jascoproducts.com)

© 2024 myTouchSmart. All rights reserved.

## Related Documents - 26892

	<p><a href="#">myTouchSmart Simple Set Indoor Plug-In Digital Timer - User Guide</a></p> <p>Learn how to set up and program your myTouchSmart Simple Set Indoor Plug-In Digital Timer for automated lighting control. Includes instructions for custom schedules, preset times, and countdown features.</p>
	<p><a href="#">myTouchSmart SunSmart Plug-In Timer User Manual</a></p> <p>User manual for the myTouchSmart SunSmart Plug-In Timer, detailing setup, programming options, and specifications for indoor digital timing. Learn how to automate your indoor lighting and appliances.</p>
	<p><a href="#">myTouchSmart Simple Set Plug-In Timer: Setup and Programming Guide</a></p> <p>A concise guide to setting up and programming the myTouchSmart Simple Set Plug-In Timer for automated control of lights and appliances. Learn how to set on/off times, understand features, and follow safety instructions.</p>
	<p><a href="#">myTouchSmart Simple Set Plug-In Timer - User Guide</a></p> <p>Instructions and specifications for the myTouchSmart Simple Set Plug-In Timer, an outdoor/indoor digital timer for automating lights and appliances. Learn how to mount, set the time, program on/off times, and understand safety warnings.</p>

User Manual of Product 1:  
My TouchSmart In-Wall Digital Timer - 4 Programmable On/Off  
Buttons, 2 Easy On/Off Buttons, 24 Hour Daily Cycles, Blue  
LED Indicators, with Battery Backup, for Indoor/Outdoor Lights,  
Fans, 2019.

### [myTouchSmart In-Wall Digital Timer 26893 User Manual & Installation Guide](#)

Comprehensive user manual and installation guide for the myTouchSmart In-Wall Digital Timer (Model 26893). Learn how to safely install and use this programmable timer for indoor/outdoor lights and fans.



### [myTouchSmart Wi-Fi Smart Devices Setup and Integration Guide](#)

Comprehensive guide for setting up myTouchSmart Wi-Fi smart plugs and switches, including app integration, voice assistant compatibility with Alexa and Google Assistant, and product details.