Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Thrustmaster /
- ThrustMaster T150 RS Force Feedback Racing Wheel User Manual

Thrustmaster 4169080

ThrustMaster T150 RS Force Feedback Racing Wheel User Manual

Model: 4169080

INTRODUCTION

The ThrustMaster T150 RS Force Feedback Racing Wheel is designed to provide an immersive and realistic racing experience across multiple platforms. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your racing wheel.

The T150 features a responsive and precise Force Feedback system, an 11-inch (28 cm) wheel rim, and 100% metal sequential paddle shifters. It is compatible with PlayStation 3, PlayStation 4, PlayStation 5, and PC systems.

WHAT'S IN THE BOX

Upon unboxing your ThrustMaster T150 RS Force Feedback Racing Wheel, please ensure all components are present:

- ThrustMaster T150 RS Racing Wheel
- 2-Pedal Set (Accelerator and Brake)
- Instruction Manual



Image: The ThrustMaster T150 RS Racing Wheel and its accompanying 2-pedal set, showcasing the main components included in the package.

SETUP GUIDE

Follow these steps to properly set up your ThrustMaster T150 RS Racing Wheel:

1. Mounting the Racing Wheel:

Place the racing wheel on a stable, flat surface such as a desk or a racing cockpit. Secure the wheel using the integrated clamping system. Tighten the clamp firmly to prevent movement during use.



Image: A user demonstrating how to securely mount the T150 RS Racing Wheel to a desk using its built-in clamping mechanism.

2. Connecting the Pedal Set:

Connect the pedal set cable to the dedicated port on the back of the racing wheel base.



Image: A close-up view of the T150 RS pedal set, showing the accelerator and brake pedals, which connect to the racing wheel base.

3. Power Connection:

Connect the power adapter to the racing wheel base and then plug it into a wall outlet.

4. USB Connection to Console/PC:

Connect the USB cable from the racing wheel base to an available USB port on your PlayStation console (PS3, PS4, PS5) or PC.

Your browser does not support the video tag.

Video: A review of the Thrustmaster T150 RS Racing Wheel, demonstrating its features and compatibility with PS3, PS4, PS5, and PC. This video highlights the wheel's force feedback and pedal functionality, providing a visual guide to its operation.

5. Platform Selection (for PS3/PS4/PS5):

On the racing wheel base, locate the PS3/PS4 switch and set it to the appropriate position for your console. For PS5 compatibility, ensure the switch is set to PS4 mode, as PS5 compatibility has been tested and endorsed by Thrustmaster.

OPERATING INSTRUCTIONS

Once set up, you can begin using your T150 RS Racing Wheel for an enhanced gaming experience.

Force Feedback

The T150 RS features a powerful Force Feedback system that simulates realistic sensations such as road texture, impacts, and loss of grip. This system is responsive, precise, and silent, thanks to its belt-pulley mechanism.

Wheel Rotation

The wheel offers up to 1080 degrees of rotation, allowing for optimal precision in various racing simulations. The optical reading system provides 12-bit resolution (4,096 values on the steering axis) for accurate in-game mirroring of your movements.



Image: A user's hands gripping the ThrustMaster T150 RS Racing Wheel, demonstrating the ergonomic design and paddle shifters during an active racing game session.

Paddle Shifters

The 100% metal sequential paddle shifters provide smooth and distinct gear changes, ensuring optimal accuracy during gameplay.

Pedal Set

The included 2-pedal set (accelerator and brake) allows for precise control over your vehicle's speed and braking. Ensure the pedal set is placed on a non-slip surface or secured to prevent movement during intense racing.

MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your ThrustMaster T150 RS Racing Wheel.

- Cleaning: Use a soft, dry cloth to clean the wheel and pedal surfaces. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- Storage: When not in use, store the racing wheel and pedals in a clean, dry environment away from direct sunlight and extreme temperatures.
- Cable Management: Ensure all cables are neatly organized and not tangled or pinched to prevent damage.

Troubleshooting

If you encounter issues with your T150 RS Racing Wheel, refer to the following common solutions:

Problem	Possible Cause	Solution
Wheel not recognized by console/PC	Incorrect platform switch setting, loose USB connection, outdated drivers (PC)	Check PS3/PS4 switch position. Ensure USB cable is securely connected. For PC, download and install the latest drivers from the Thrustmaster support website.
No Force Feedback or weak Force Feedback	Game settings, power issue, driver issue (PC)	Verify Force Feedback settings within the game. Ensure the power adapter is correctly connected and receiving power. For PC, reinstall drivers and calibrate the wheel.
Pedals not responding	Loose pedal connection, calibration issue	Check the connection between the pedal set and the wheel base. Recalibrate the pedals through the game or driver settings.

SPECIFICATIONS

Feature	Detail
Model Number	4169080
Wheel Diameter	11 inches (28 cm)
Wheel Rotation	Up to 1080 degrees
Force Feedback System	Belt-pulley system
Optical Reading Resolution	12-bit (4,096 values on steering axis)

Feature	Detail
Paddle Shifters	100% metal sequential
Pedal Set	2-pedal (Accelerator, Brake)
Compatibility	PlayStation 3, PlayStation 4, PlayStation 5, PC
Product Dimensions	12.6 x 12.99 x 11.81 inches
Item Weight	11.25 pounds

WARRANTY INFORMATION

Thrustmaster products are covered by a warranty against defects in materials and workmanship. For detailed warranty terms and conditions, please refer to the official Warranty (PDF) document provided by Thrustmaster. It is recommended to retain your proof of purchase for warranty claims.

SUPPORT AND CONTACT

For further assistance, technical support, or to download the latest drivers and firmware updates, please visit the official Thrustmaster support website or refer to the User Manual PDF.

- Official User Manual: User Manual (PDF)
- Thrustmaster Store: Visit the Thrustmaster Store on Amazon

© 2024 Thrustmaster. All rights reserved.

Related Documents - 4169080



Thrustmaster T150 Firmware Update Guide

Step-by-step guide for manually updating the firmware on the Thrustmaster T150 FORCE FEEDBACK racing wheel for PC and console compatibility.



Thrustmaster T300RS GT Edition User Manual

User manual for the Thrustmaster T300RS GT Edition racing wheel, compatible with PlayStation 5, PlayStation 4, and PC. Includes technical features, setup instructions, and safety warnings.



Thrustmaster T248 User Manual: Setup, Configuration & Features

Comprehensive user manual for the Thrustmaster T248 racing wheel and T3PM pedal set. Learn about setup, installation, configuration, features, and troubleshooting for PlayStation 5, PlayStation 4, and PC.



Thrustmaster T300RS GT Edition Racing Wheel User Manual

Comprehensive user manual for the Thrustmaster T300RS GT Edition racing wheel and pedal set. Includes setup guides, technical features, compatibility information for PlayStation 5, PlayStation 4, and PC, and safety instructions.



Thrustmaster T-GT II Racing Wheel User Manual - Setup and Operation Guide

Comprehensive user manual for the Thrustmaster T-GT II racing wheel, covering setup, technical features, safety warnings, and operational guidelines for PlayStation 5 and PlayStation 4 consoles.



Thrustmaster T300RS GT Edition Racing Wheel User Manual

Comprehensive user manual for the Thrustmaster T300RS GT Edition racing wheel, covering setup, features, safety warnings, and maintenance for PlayStation 3, PlayStation 4, and PC.