

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Thrustmaster](#) /
- › [Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On User Manual](#)

Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On

Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On User Manual

Model: F599XX EVO 30 Wheel Alcantara Edition Add-On

Brand: Thrustmaster

PRODUCT OVERVIEW

The Thrustmaster F599XX EVO 30 Wheel Add-On Alcantara Edition is an 8:10 scale replica of the Ferrari 599XX EVO wheel, officially licensed by Ferrari. It features a hand-stitched Alcantara wrapping, identical to the material used on real Ferrari wheels, providing an authentic feel and enhanced comfort. The wheel's structure includes polyurethane molding and an internal steel hoop for improved transmission of Force Feedback effects. This detachable wheel is designed for precise control and an immersive racing experience.



Image: Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On.

Key Features

- **Realistic Materials:** 8:10 scale replica with hand-stitched Alcantara wrapping, imported from Italy, for an authentic feel.
- **Durable Construction:** Automotive-standard structure with polyurethane molding and an internal steel hoop for flexible touch, comfort, and improved Force Feedback.
- **Optimal Size:** 11.8-inch (30 cm) diameter for greater immersion.
- **Lightweight Design:** Weighs less than 2.6 lbs (1.2 kg) for responsive Force Feedback.
- **Advanced Controls:** Two large 5.1-inch (13 cm) wheel-mounted paddle shifters, six action buttons, a 3-position rotary switch with push function, and a multidirectional D-pad.
- **Thrustmaster Quick Release System:** Allows for quick and easy switching between compatible Thrustmaster wheels.

Product Video Overview

Video: Official overview of the Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On, showcasing its features and design.

WHAT'S INCLUDED

The package contains the following items:

- Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On
- Instruction Manual



Image: Packaging of the Thrustmaster F599XX EVO 30 Wheel Add-On, showing the wheel and box contents.

SETUP INSTRUCTIONS

Compatibility

This add-on wheel is compatible with all Thrustmaster racing wheels featuring a detachable wheel, including:

- T500 RS
- Ferrari F1 Integral T500
- T300 RS

- T300 Ferrari GTE
- TX Racing Wheel Ferrari 458 Italia Edition
- Compatible with PS4, PS5, Xbox One, Xbox Series X/S, and PC.

Attaching the Wheel

1. Ensure your Thrustmaster wheel base is powered off and disconnected from the power supply.
2. Align the Quick Release system on the F599XX EVO 30 wheel with the corresponding mechanism on your Thrustmaster wheel base.
3. Gently push the wheel onto the base until it clicks into place.
4. Tighten the locking ring clockwise until it is secure. Do not overtighten.
5. Reconnect your wheel base to the power supply and your gaming system.

Video: Demonstration of attaching and detaching a Thrustmaster wheel, highlighting the Quick Release system.

OPERATING INSTRUCTIONS

Controls Overview

The F599XX EVO 30 wheel features a comprehensive set of controls for an optimized racing experience:

- **Paddle Shifters:** Two large, 5.1-inch (13 cm) wheel-mounted sequential paddle shifters made of brushed metal with metallic paint. These provide precise and responsive gear changes.
- **Action Buttons:** Six easy-access, clearly identified action buttons for various in-game functions.
- **Rotary Switch:** A 3-position rotary switch with a push function in the central position, allowing for quick adjustments during gameplay.
- **D-Pad:** A multidirectional D-pad for menu navigation and additional controls.



Image: Close-up view of the F599XX EVO 30 wheel's central controls, including buttons, D-pad, and rotary switch.

In-Game Configuration

Refer to your specific game's control settings to customize the functions of the buttons, paddle shifters, and rotary switch to best suit your driving style and preferences. Ensure your wheel base drivers are up-to-date for optimal performance.

MAINTENANCE

Cleaning the Alcantara Surface

To maintain the quality and feel of the Alcantara, follow these cleaning guidelines:

- **Regular Cleaning:** Gently brush the Alcantara surface with a soft brush or a dry cloth to remove dust and light dirt.
- **Spot Cleaning:** For minor stains, lightly dampen a clean, soft cloth with water (or a mild, pH-neutral soap solution if necessary) and gently dab the affected area. Avoid rubbing vigorously.
- **Drying:** Allow the Alcantara to air dry completely. Do not use direct heat.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the Alcantara material.

General Care

- Store the wheel in a clean, dry environment away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the wheel to strong impacts.
- Periodically check the Quick Release mechanism for any signs of wear and ensure it is securely fastened during use.

TROUBLESHOOTING

Common Issues and Solutions

- **Wheel Not Detected:** Ensure the wheel add-on is securely attached to the wheel base. Verify that the wheel base is properly connected to your console/PC and power supply. Update your wheel base drivers if on PC.
- **Buttons Not Responding:** Check in-game control settings to ensure buttons are correctly mapped. If using on PC, ensure the latest drivers are installed.
- **Force Feedback Issues:** Confirm that Force Feedback settings are enabled in your game and wheel base control panel (if applicable). Ensure the wheel base firmware is up-to-date.
- **Loose Connection:** If the wheel feels loose on the base, ensure the Quick Release locking ring is fully tightened.

If you encounter persistent issues, please refer to the official Thrustmaster support website for detailed troubleshooting guides and contact information.

TECHNICAL SPECIFICATIONS

Brand Name	Thrustmaster
Model Name	Thrustmaster F599XX EVO 30 Wheel Alcantara Edition Add-On
Compatible Devices	Playstation 4, Playstation 5, Windows, Xbox One, Xbox Series X
Controller Type	Racing accessory
Connectivity Technology	USB
Additional Features	Ergonomic
Button Quantity	16
Item Weight	3.1 Pounds (1.4 kg)
Item Dimensions (L x W x H)	13.39 x 13.31 x 4.69 inches (34 x 33.8 x 11.9 cm)
Color	Black
GTIN / UPC	663296420251

WARRANTY AND SUPPORT

Warranty Information

This Thrustmaster product is covered by a **one-year warranty** from the date of purchase. The warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, driver updates, or further support, please visit the official Thrustmaster support website:

[**Thrustmaster Official Product Page**](#)

You can also find FAQs and troubleshooting guides on their support portal.