

[Manuals.plus](#) /

› [Nintendo](#) /

› Nintendo Wii Sports Game Manual (Renewed)

Nintendo Wii Sports

Nintendo Wii Sports Game Manual (Renewed)

Model: Wii Sports | Brand: Nintendo

INTRODUCTION

This manual provides essential instructions for the Nintendo Wii Sports game, a renewed product. Wii Sports offers five distinct sports experiences: Tennis, Baseball, Bowling, Golf, and Boxing, designed for interactive play using the Wii Remote. This renewed version has been cleaned and tested to ensure functionality.

Please note that this renewed product typically includes the game disc only, without the original case or manual. It will be provided in generic packaging.

PRODUCT OVERVIEW



NINTENDO
SELECTS

Wii™



Wii Sports



Nintendo

This image displays the front cover of the Wii Sports game, featuring illustrations of the five included sports: Tennis, Baseball, Bowling, Golf, and Boxing. The Nintendo Selects logo is visible in the top left corner, and the ESRB rating 'E for Everyone' is at the bottom left.

SETUP

1. **Insert the Game Disc:** Ensure your Nintendo Wii console is powered off. Open the disc drive cover and carefully insert the Wii Sports game disc with the label facing up. Close the disc drive cover.
2. **Power On Console:** Turn on your Nintendo Wii console.
3. **Connect Wii Remote:** If your Wii Remote is not already connected, press the SYNC button inside the battery compartment of the Wii Remote and then the SYNC button on the Wii console (usually behind the front panel). The player indicator lights on the Wii Remote will flash and then light up steadily when connected.
4. **Select Game:** On the Wii Menu, navigate to the Disc Channel and select Wii Sports to start the game.

OPERATING AND GAMEPLAY

Wii Sports features five distinct sports. Upon starting the game, you will be prompted to select a Mii character and then choose a sport from the main menu.

- **Tennis:** Use the Wii Remote to swing like a tennis racket. The game automatically moves your Mii character, allowing you to focus on timing your swings.
- **Baseball:** Batting involves swinging the Wii Remote. Pitching requires a throwing motion. Fielding is largely automated.
- **Bowling:** Hold the Wii Remote and perform a bowling motion, releasing the 'B' button at the peak of your swing to release the ball.
- **Golf:** Swing the Wii Remote like a golf club. The power and direction of your swing determine the shot.
- **Boxing:** Use both the Wii Remote and Nunchuk to punch and block. Hold them like boxing gloves and mimic punching motions.

Each sport includes tutorials and training modes to help you learn the controls and improve your skills.

MAINTENANCE

- **Disc Care:** Handle the game disc by its edges. Avoid touching the reflective surface.
- **Cleaning:** If the disc becomes dirty, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive cleaners or solvents.
- **Storage:** Store the disc in its protective case when not in use to prevent scratches and dust accumulation.

TROUBLESHOOTING

Disc Not Reading:

- Ensure the disc is clean and free of scratches.
- Verify the disc is inserted correctly into the Wii console.
- Restart the Wii console.
- If issues persist, the disc or console drive may require service.

Wii Remote Not Responding:

- Check the batteries in the Wii Remote and replace if necessary.
- Ensure the Wii Remote is properly synced with the console (refer to the Setup section).
- Confirm the Sensor Bar is correctly connected and positioned.

Game Freezes or Crashes:

- Restart the console.
- Ensure the game disc is clean and undamaged.
- If the problem is frequent, it may indicate an issue with the disc or console hardware.

SPECIFICATIONS

Feature	Detail
Product Type	Video Game (CD-ROM)
Brand	Nintendo
Model Name	Wii Sports
Compatible Consoles	Nintendo Wii, Nintendo Wii Mini, Nintendo Wii U
ESRB Rating	Everyone
Language	English
Item Model Number	SG_B014VC8F0O_US
Product Dimensions	5.71 x 4.96 x 0.28 inches
Item Weight	1.12 ounces
Date First Available	September 3, 2015

WARRANTY AND SUPPORT

As this is a renewed product, specific warranty terms may vary. Please refer to the seller from whom you purchased this item for details regarding their return policy or any applicable warranty.

For general support related to Nintendo Wii consoles or accessories, you may visit the official Nintendo support website or contact their customer service.

